

(RG40V1G-042K)

CONTENTS


◆ RGV3402010000K DRIVING AXLE ASSEMBLY.....	1
◆ RGV1104010000K REEL BRACKET ASSEMBLY.....	32
◆ RGV1409000000K PARKING BRAKE.....	36
◆ RGV1102020000K HEADER ASSEMBLY.....	39
◆ RV01103000000 CUTTER ASSEMBLY.....	57
◆ RGV1105020000K FEEDING AUGER ASSEMBLY.....	70
◆ RV01106010000K LEFT DIVIDER ASSEMBLY.....	78
◆ RGV1108010000K BRIDGE ASSEMBLY.....	81
◆ RGV3101030000 REEL ASSEMBLY.....	99
◆ RGV1107020000K DIVIDER ASSEMBLY, RIGHT.....	109
◆ RGV1407020000K STEPLESS SPEED CHANGING CONTROL ASSEMBLY.....	112
◆ DG2001. 20 FAN ASSEMBLY.....	116
◆ RGV1201020000K THRESHING BODY ASSEMBLY.....	123
◆ RV01202020000 CYLINDER COVER ASSEMBLY.....	146
◆ RV01208010000 SIEVE BOX ASSEMBLY.....	152
◆ DV01214030000 MAIN ENGINE TRANSMISSION ASSEMBLY.....	171
◆ DV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY.....	174
◆ RV01301020000 GRAIN CLIMB MACHINE ASSEMBLY.....	188
◆ RV01302010000K ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF.....	201
◆ RGV1303030000K GRAIN TANK ASSEMBLY.....	216
◆ RGV1305010000K UNLOADING BOTTOM AUGER ASSEMBLY.....	228

◆ RGV1306030000K UNLOADING CANISTER ASSEMBLY.....	235
◆ DG2001. 31A REARVIEW MIRROR ASSEMBLY.....	256
◆ RGV1401080000K WHEEL SYSTEM ASSEMBLY.....	259
◆ RGV1403160000K CHASSIS FRAME ASSEMBLY.....	274
◆ RGV1405020000K STEERING LIFTING CONTROL UNIT.....	279
◆ RGV3406000000 SPEED CHANGING CONTROL ASSEMBLY.....	283
◆ DV01410000000 HANDLE THROTTLE ASSEMBLY.....	286
◆ DV01411000000 FLAMEOUT MECHANISM.....	289
◆ RV01412010000 CLUTCH CONTROL ASSEMBLY.....	292
◆ RV01413020000 UNLOADING CLUTCH CONTROL.....	298
◆ DV01414020000 MAIN TRANSMISSION ASEMBLY.....	306
◆ RV01416000000K HEADER CLUTCH CONTROL ASSEMBLY.....	310
◆ RGV1205010000K AXIAL FLOW ROLLER ASSEMBLY.....	313
◆ RV01501190000 ENGINE ASSEMBLY.....	325
◆ DV01502000000 RADIATOR ASSEMBLY.....	404
◆ RV01503010000 DUST REMOVAL COVER ASSEMBLY.....	407
◆ RGV1504030000K FUEL SUPPLY COMBINATION.....	413
◆ DV01505000000 MANIFOLDS & INDUCTION SYSTEM.....	419
◆ RV01506000000K MANIFOLDS & EXHAUST SYSTEM.....	422
◆ D1681. 53 FIRE EXTINGUISHER.....	425
◆ DV01601000000 HEADER HYDRAULIC PRESSURE ASSEMBLY.....	428
◆ DV01602000000 STEERING HYDRAULIC PRESSURE ASSEMBLY.....	431
◆ RGV3603080000 MULTI-WAY VALVE ASSEMBLY.....	434
◆ RV03604030000 STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY.....	446

◆ RV01605050000 HYDRAULIC PRESSURE ASSEMBLY OF GEAR PUMP.....	453
◆ RGV1701050000 ELECTRICAL ASSEMBLY OF CAB.....	456
◆ RGV1702060000 ELECTRICAL ASSEMBLY OF BODY.....	460
◆ RGV1703010000 ELECTRICAL ASSEMBLY OF GRAIN BOX.....	463
◆ DV01704020000 HARNESS ASSEMBLY.....	466
◆ RGV1705020000 ELECTRICAL ASSEMBLY OF ENGINE.....	469
◆ RGV1706000000 ACCUMULATOR ASSEMBLY.....	472
◆ RGV3709020000 AWNING FAN ASSEMBLY.....	475
◆ RGV3801020000K AWNING ASSEMBLY.....	478
◆ RGV1802050000K DRIVER' S PANEL ASSEMBLY.....	481
◆ RGV1803030000K SEAT ASSEMBLY.....	485
◆ RV01804060000 COVER ASSEMBLY.....	488
◆ RV01806030000 REAR TAIL LADDER ASSEMBLY.....	492

LOVOL
9ZR D22327

RGV3402010000K DRIVING AXLE ASSEMBLY-1




RGV3402010000K DRIVING AXLE ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3402010000K	DRIVING AXLE ASSEMBLY	001	1	
1	RV01402040001	V-BELT SB65. 5		3	
2	DV01402080011	WASHER		4	
3	GBT6171-M12X1. 25-8-A2L	TYPE 1 HEX NUT		4	
4	GBT93-12-A3L	STANDARD SPRING WASHER		8	
5	GBT93-10-A3L	STANDARD SPRING WASHER		4	
6	GBT5783-M10X30-8. 8-A3L	HEX HEAD BOLTS		4	
7	RGV3402010001K	GEARBOX ASSEMBLY		1	
8	RV01402110003	BRAKE BRACKET ASSEMBLY		1	
8.1	GBT5783-M8X20-8. 8-A2L	HEX HEAD BOLTS		2	
8.2	GBT93-8-A3L	STANDARD SPRING WASHER		2	
8.3	GBT97. 1-8-A3L	FLAT WASHERS		2	
8.4	DG2001. 28. 3. 4	LOCATION SHAFT WELDMENT		2	
8.5	DG2001. 28. 3. 3	ROTARY SHAFT WELDMENT 2		1	
8.6	DG2001. 28. 3. 2	ROTARY SHAFT WELDMENT 1		1	
8.7	DG2001. 28. 3-01	RETURN SPRING OF BRAKE		1	
8.8	DG2001. 28. 3. 1	BRACKET WELDING		1	
8.9	GBT97. 1-16-A3L	FLAT WASHERS		2	
8.10	GBT91-4X36-A3L	COTTER PIN		2	
9	GBT5783-M8X35-8. 8-A2L	HEX HEAD BOLTS		2	
10	GBT93-8-A3L	STANDARD SPRING WASHER		8	
11	GBT97. 1-8-A3L	FLAT WASHERS		6	
12	GBT5783-M8X20-8. 8-A2L	HEX HEAD BOLTS		4	

RGV3402010000K DRIVING AXLE ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
13	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		4	
14	DV01402080010	CONNECTION PLATE		1	
15	GBT96. 1-8-A3L	LARGE WASHER		4	
16	GBT5783-M8X25-8. 8-A2L	HEX HEAD BOLTS		2	

RGV3402010000K DRIVING AXLE ASSEMBLY-2



RGV3402010000K DRIVING AXLE ASSEMBLY-2


No.	Part No.	Description	Version	QTY.	Remark
	RGV3402010000K	DRIVING AXLE ASSEMBLY		1	
1	RV01402010001K	RUNNING TENSION WHEEL COMBINATION		1	
1.1	DV01402040005	SPACER BUSH		1	
1.2	DV01402040026	ADJUSTMENT MATS		2	
1.3	DV01402040006	GASKET		1	
1.4	GBT93-10-A3L	STANDARD SPRING WASHER		1	
1.5	GBT5783-M10X20-8.8-A3L	HEX HEAD BOLTS		1	
1.6	RV01402010002K	RUNNING TENSION WHEEL COMBINATION		1	
1.6.1	TD800.311C.1-01	DUSTPROOF CAP OF OIL CUP		1	
1.6.2	JBT7940.1-M6	STRAIGHT-THROUGH PRESSURE OIL CUP		1	
1.6.3	DV01402000064	SPACER SLEEVE 3		1	
1.6.4	RGV1903160001K	BEARING		4	
1.6.5	DV01402040004	SPACER		1	
1.6.6	DV01402000061	TENSION BRACKET WELDMENT		1	
1.6.7	DV01402000067	SUPPORTING SHAFT		1	
1.6.8	GBT6170-M12-8-A3L	TYPE 1 HEX NUT		1	
1.6.9	GBT893.1-47	RETAINING RING FOR HOLE		2	
1.6.10	DV01402000066	SPACER BUSH 1		1	
1.6.11	DG2001.28.2b-03	RUNNING TENSION BELT PULLEY		1	
1.6.12	DV01402000065	SPACER BUSH 2		1	
1.6.13	GBT93-12-A3L	STANDARD SPRING WASHER		1	
1.7	GBT97.1-10-A3L	FLAT WASHERS		1	
1.8	GBT91-3.2X16-A3L	COTTER PIN		1	

RGV3402010000K DRIVING AXLE ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
2	DG2002.28-03	SPRING		1	
3	RV01402060005	TIE ROD		1	
4	GBT6170-M12-8-A3L	TYPE 1 HEX NUT		3	
5	GBT93-12-A3L	STANDARD SPRING WASHER		8	
6	GBT97.1-12-A3L	FLAT WASHERS		3	
7	DV01402080004	CONNECTING SEAT WELDMENT OF GEARBOX		1	
8	GBT849-12	SPHERICAL WASHER		1	
9	GBT5783-M12X80-8.8-A2L	HEX HEAD BOLTS		1	
10	GBT5783-M12X30-8.8-A3L	HEX HEAD BOLTS		2	

LOVOL
9ZR D22327

RGV3402010000K DRIVING AXLE ASSEMBLY-3



RGV3402010000K DRIVING AXLE ASSEMBLY-3


No.	Part No.	Description	Version	QTY.	Remark
	RGV3402010000K	DRIVING AXLE ASSEMBLY		1	
	RGV3402010002K	GEARBOX ASSEMBLY		1	
1	RGV3402010013K	HST SEAT ASSEMBLY		1	
1.1	GBT5789-M10X25-10.9-A2L	HEX FLANGE BOLTS		1	
1.2	GBT1096-10X8X40	FLAT KEY		1	
1.3	RV02402000027	WASHER		1	
1.4	RGV3402060005	INPUT BELT PULLEY		1	
1.5	RGV3402010014K	HST CONNECTION BASE ASSEMBLY		1	
1.5.1	RGV3402060021	BREATHING PLUG		1	
1.5.2	GL07102010064	CONNECTING HOSE		1	
1.5.3	RGV3402060004A	HST CONNECTING SEAT		1	
1.5.4	Q617B08	HEXAGON PLUG		1	
1.5.5	JBT982-8	COMBINATION GASKET		1	
1.5.6	GBT9877.1-FB38X62X8D	ROTARY SHAFT LIP SEAL WITH INNER FRAME		1	
1.5.7	DV01402010087	ADJUSTING SHIM-IV SHAFT BEARING		1	
1.5.8	RGV3402060006	INPUT SHAFT		1	
1.5.9	GBT276-6305	DEEP GROOVE BALL BEARING		1	
1.5.10	GBT283-NJ206E	COLUMN ROLLER BEARING		1	
1.5.11	GBT893.1-62	RETAINING RING FOR HOLE		1	
1.5.12	RV02402000026	INPUT SHAFT OIL SEAL RACE		1	
1.5.13	RGV3402060023	SPACER BUSH OF INPUT SHAFT		1	
1.5.14	Q673B23	STEEL BAND ELASTIC HOOP		1	
2	GL05501020011	BOLT CAP		1	

RGV3402010000K DRIVING AXLE ASSEMBLY-3 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
3	GBT5783-M12X35-8. 8-A3L	HEX HEAD BOLTS		1	
4	S0110A010061AC	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
5	RGV3402000019	HST GASKET		1	
6	TD904. 311K. 1-13	SCREW PLUG		1	
7	GBT3452. 1-21. 2X2. 65G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
8	RGV3402000004	GEARBOX HOUSING		1	
9	GBT119. 1-10m6X20-A0P	CYLINDRICAL PIN		1	
10	GBT70. 1-M12X40-10. 9-A3L	HEXAGON SOCKET HEAD CAP SCREW		2	
11	GBT93-12-A0P	STANDARD SPRING WASHER		1	
12	CP4D304010028	SCREW PLUG		1	
13	GBT893. 1-22	RETAINING RING FOR HOLE		2	
14	DV01402010086	SPLINE SHAFT BUSH		2	
15	DV01402040020	HST CONNECTING SEAT GUARD PLATE		1	

LOVOL
9ZR D22327

RGV3402010000K DRIVING AXLE ASSEMBLY-4



RGV3402010000K DRIVING AXLE ASSEMBLY-4


No.	Part No.	Description	Version	QTY.	Remark
	RGV3402010000K	DRIVING AXLE ASSEMBLY		1	
	RGV3402010002K	GEARBOX ASSEMBLY		1	
1	DV01402010102	PLUG COVER		1	
2	GBT893. 1-52	RETAINING RING FOR HOLE		1	
3	RGV3402060021	BREATHER PLUG		1	
4	GBT93-8-A0P	STANDARD SPRING WASHER		1	
5	GBT283-NJ305E	COLUMN ROLLER BEARING		1	
6	RV01402160021	FIRST SHAFT SPACER BUSH		1	
7	DV01402010120	I & II SHAFT LEFT COVER		1	
8	RV01402160064	FRONT COVER GASKET		1	
9	RGV3402010015K	1ST SHAFT ASSEMBLY		1	
9.1	GBT283-NJ2205E	COLUMN ROLLER BEARING		1	
9.2	RV01402160017	THRUST PAD		1	
9.3	RGV3402000006	NORMALLY ENGAGED GEAR		1	
9.4	GBT20056-K32X38X20	NEEDLE AND CARRIER COMBINATION		1	
9.5	RV01402160008	FIRST GEAR DRIVING GEAR ASSEMBLY		1	
9.6	RV01402160013	GEAR BUSH		1	
9.7	RGV3402000018	1ST SHAFT		1	
9.8	RV01402160020	NEEDLE BEARING		1	
9.9	RV01402160012	3RD DRIVING GEAR		1	
9.10	RGV3402000017	BUSH		1	
9.11	RGV3402000011L	GEAR II DRIVING GEAR		1	
9.12	GBT20056-K38X43X27	NEEDLE AND CARRIER COMBINATION		1	

RGV3402010000K DRIVING AXLE ASSEMBLY-4 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
9. 13	RGV3402000021	SECOND GEA HUB SLEEVE		1	
10	RGV3402000015	FRONT COVER		1	
11	GBT5783-M8X16-8. 8-A2L	HEX HEAD BOLTS		1	
12	RGV3402060022	VENT PLUG		1	
13	GBT893. 1-42	RETAINING RING FOR HOLE		1	
14	RV03402000022	SPACER		1	
15	GBT276-6008	DEEP GROOVE BALL BEARING		1	
16	RGV3402000005	INPUT GEAR		1	
17	GBT894. 1-24	RETAINING RING FOR SHAFT		1	
18	RGV3402040039	INNER SKELETON ROTARY SHAFT LIP SEAL RING		2	
19	JBT8870-d20	HOSE CLAMP		1	

LOVOL
9ZR D22327


RGV3402010000K DRIVING AXLE ASSEMBLY-5



RGV3402010000K DRIVING AXLE ASSEMBLY-5

No.	Part No.	Description	Version	QTY.	Remark
	RGV3402010000K	DRIVING AXLE ASSEMBLY		1	
	RGV3402010002K	GEARBOX ASSEMBLY		1	
1	DV01402010104	PLUG COVER		1	
2	DV01402010103	O-RING		1	
3	GBT893. 1-62	RETAINING RING FOR HOLE		1	
4	GBT283-NJ305E	COLUMN ROLLER BEARING		1	
5	RV01402160026	TWO AXLE SPACER 1		1	
6	RV01402160023	1ST DRIVEN GEAR		1	
7	RV01402160025	THIRD GEAR DRIVEN GEAR		1	
8	RV01402160024	II GEAR DRIVEN GEAR		1	
9	RV01402160022	SECOND SHAFT		1	
10	RV01402160027	TWO AXLE SPACER 2		1	
11	RV01402160028	TWO AXLE SPACER 3		1	
12	S0114A010044AC	PLUG COVER		1	
13	RGV3402010003K	RIGHT HALF SHAFT ASSEMBLY		1	
14	RGV3402010004K	LEFT HALF SHAFT ASSEMBLY		1	

RGV3402010000K DRIVING AXLE ASSEMBLY-6




RGV3402010000K DRIVING AXLE ASSEMBLY-6

No.	Part No.	Description	Version	QTY.	Remark
	RGV3402010000K	DRIVING AXLE ASSEMBLY		1	
	RGV3402010002K	GEARBOX ASSEMBLY		1	
1	GBT879.1-4X26	ELASTIC CYLINDRICAL PIN		1	
2	GBT879.1-6X26	ELASTIC CYLINDRICAL PIN		1	
3	DV01402010088	OUTSIDE GEARSHIFT ROCKER		1	
4	GBT1235-24X2.4	RUBBER O-SEAL RING		1	
5	DV01402010068	GEARSHIFT SHAFT BUSH		1	
6	GBT1235-16X2.4	RUBBER O-SEAL RING		1	
7	DV01402010079	OUTSIDE GEARSHIFT ROCKER WELDMENT		1	
8	GBT308-6.35-G100-b	STEEL BALL		1	
9	RV02402000086	SELF-LOCKING SPRING		1	
10	RGV3402000025	LEVER FORK		1	
11	RGV3402000013	FORK SHAFT		1	
12	GBT5783-M8X25-A2L	HEX HEAD BOLTS		1	
13	DV01402010108	BAFFLE		1	
14	DV01402010093	FORK SHAFT COVER		1	
15	GBT93-8-A0P	STANDARD SPRING WASHER		1	
16	GBT5783-M8X20-8.8-A2L	HEX HEAD BOLTS		1	
17	RV01402160041	FIXED PLATE		2	
18	GBT6170-M8	TYPE 1 HEX NUT		1	
19	JBT982-8	COMBINATION GASKET		1	

LOVOL
9ZR D22327


RGV3402010000K DRIVING AXLE ASSEMBLY-7



RGV3402010000K DRIVING AXLE ASSEMBLY-7

No.	Part No.	Description	Version	QTY.	Remark
	RGV3402010000K	DRIVING AXLE ASSEMBLY		1	
	RGV3402010002K	GEARBOX ASSEMBLY		1	
1	GL02501010080	ADJUSTING WASHER		1	
2	RV01402160038	SPRING		1	
3	RV01402160042	WASHER		1	
4	RV01402160040	WASHER		1	
5	GBT297-30207	TAPERED ROLLER BEARING-30211-J2-Q		1	
6	RV01402160036	LEFT BEARING SEAT		1	
7	GBT93-10-A0P	STANDARD SPRING WASHER		1	
8	GBT5783-M10X35-8. 8-A3L	HEX HEAD BOLTS		1	
9	RV01402160046	RETAINING RING		1	
10	RV01402160033	THREE AXLE SLIDING GEAR ASSEMBLY		1	
11	RV01402160030	DENTAL CHIMERA		1	
12	RV01402160037	RIGHT BEARING SEAT		1	
13	RV01402160029	THREE SHAFT CONSTANT CLOSING GEAR		1	
14	GBT5783-M8X20-8. 8-A2L	HEX HEAD BOLTS		1	
15	GBT93-8-A0P	STANDARD SPRING WASHER		1	
16	RV01402160039	BEARING COVER		1	
17	RV01402160045	BRAKE PRESSING PLATE		1	
18	RGV3402000008	FRICTION PIECE ASSEMBLY		2	
18.1	RV01402160043	INNER CLUTCH PATH		7	
18.2	RV01402160044	O. CLUTCH DISC		8	

RGV3402010000K DRIVING AXLE ASSEMBLY-8




RGV3402010000K DRIVING AXLE ASSEMBLY-8

No.	Part No.	Description	Version	QTY.	Remark
	RGV3402010000K	DRIVING AXLE ASSEMBLY		1	
	RGV3402010002K	GEARBOX ASSEMBLY		1	
1	DV01402010087	ADJUSTING SHIM-IV SHAFT BEARING		1	
2	GBT297-32207	TAPERED ROLLER BEARING-30211-J2-Q		1	
3	RV01402160072	THRUST PAD		1	
4	RV01402160049	GEAR		1	
5	GBT894. 1-78	RETAINING RING FOR SHAFT		1	
6	RV01402160063	4-AXIS GLAND GASKET		1	
7	RV01402160052	SIDE GEAR		1	
8	RV01402160050	COVER		1	
9	RV01402160051	SPACER SLEEVE		1	
10	RV01402160048	SHAFT IV		1	
11	GBT5783-M8X25-A2L	HEX HEAD BOLTS		1	
12	GBT93-8-A0P	STANDARD SPRING WASHER		1	
13	RGV3402000010	BEARING		1	
14	JBT7918-K40X47X40-ZW	NEEDLE AND CARRIER COMBINATION		1	
15	GBT893. 1-68	RETAINING RING FOR HOLE		1	
16	RV01402160071	LEFT PRESSURE COVER		1	

LOVOL
9ZR D22327

RGV3402010000K DRIVING AXLE ASSEMBLY-9




RGV3402010000K DRIVING AXLE ASSEMBLY-9

No.	Part No.	Description	Version	QTY.	Remark
	RGV3402010000K	DRIVING AXLE ASSEMBLY		1	
	RGV3402010002K	GEARBOX ASSEMBLY		1	
1	GBT93-12-A0P	STANDARD SPRING WASHER		1	
2	GBT5783-M8X25-A2L	HEX HEAD BOLTS		1	
3	GBT93-8-A0P	STANDARD SPRING WASHER		1	
4	RV01402160066	RIGHT BRAKE ROCKER		1	
5	RV01402160065	LEFT BRAKE ROCKER		1	
6	GBT70. 3-M8X20-8. 8-A2L	HEX SOCKET COUNTERSUNK HEAD SCREW		1	
7	9YFD190220300222	OIL PLUG ASSEMBLY		1	
8	GBT893. 1-42	RETAINING RING FOR HOLE		1	
9	GBT276-6004	DEEP GROOVE BALL BEARING		1	
10	DV01402010011	FORK SPACER		1	
11	RV01402160073a	FORK WELDMENT		1	
12	RV01402160062	STEERING DIAL BLOCK		1	
13	GBT3452. 1-100X2. 65G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
14	GBT899-AM12-M12X1. 25X60-8. 8-A2 L	DOUBLE END STUDS		1	
15	GBT5783-M12X35-8. 8-A3L	HEX HEAD BOLTS		1	
16	GBT3452. 1-17. 0X2. 65G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
17	GBT119. 1-8h8X22-A0P	CYLINDRICAL PIN		1	

LOVOL
9ZR D22327

RGV1104010000K REEL BRACKET ASSEMBLY



RGV1104010000K REEL BRACKET ASSEMBLY


No.	Part No.	Description	Version	QTY.	Remark
	RGV1104010000K	REEL BRACKET ASSEMBLY	001	1	
1	RV03104010041a	BRACKET WELDMENT		1	
2	RV03104010046a	SUPPORTING ARM WELDED PART		1	
2.1	DG2002. 8. 2a-01	SET		2	
2.2	RV03104010047a	TENSIONER WELDED PART		1	
3	RGV1104010001K	SPEED CHANGING BELT PULLEY		1	
3.1	DF2881. 4. 6-01	SPROCKET		1	
3.2	GBT893. 1-47	RETAINING RING FOR HOLE		2	
3.3	RGV1903160001K	BEARING		2	
3.4	DV01104000168	SPACING SLEEVE		1	
3.5	GBT6170-M6-8-A2L	TYPE 1 HEX NUT		6	
3.6	GBT93-6-A3L	STANDARD SPRING WASHER		6	
3.7	RV03104010012	VARIABLE SPEED PULLEY		1	
3.8	GBT5783-M6X25-8. 8-A2L	HEX HEAD BOLTS		6	
4	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		2	
5	GBT96. 1-10-A3L	LARGE WASHER		2	
6	D1801. 4. 3-01	TENSIONER		2	
7	DV01104000051	RETAINING RING		5	
8	DV01104000004	SLEEVE		4	
9	DV01104010007	TENSION PULL ROD		1	
10	DV01104000002	TENSION SPRING		1	
11	GBT5789-M6X12-8. 8-A2L	HEX FLANGE BOLTS		5	
12	RV03104010050	ADJUSTMENT MATS		1	

RGV1104010000K REEL BRACKET ASSEMBLY (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
13	GBT894.1-15	RETAINING RING FOR SHAFT		2	
14	RV03104010010	COVER WITHIN 1		1	
15	RV03104010035	BONNET		1	
16	RV03104010005	SHIELD		1	
17	DV01104000162	AXIS		1	
18	DV01104000163	SHAFT END RETAINING RING		1	
19	GBT93-8-A3L	STANDARD SPRING WASHER		1	
20	GBT5783-M8X20-8.8-A2L	HEX HEAD BOLTS		1	
21	GBT879.1-8X35	ELASTIC CYLINDRICAL PIN		1	
22	GBT1171-B2860	V-BELT		1	
23	GBT5789-M8X16-8.8-A2L	HEX FLANGE BOLTS		4	

RGV1409000000K PARKING BRAKE

LOVOL
gZR D22327




RGV1409000000K PARKING BRAKE

No.	Part No.	Description	Version	QTY.	Remark
	RGV1409000000K	PARKING BRAKE	001	1	
1	DV01409010001	PEDAL LOCKING HOOK ASSEMBLY		1	
1.1	DA18027. 40-04	HANDLEBALL		1	
1.2	DV01409010002	PEDAL LOCKING ROD		1	
1.3	DG2002. 40. 1. 2	PEDAL LOCKING HOOK		1	
1.4	GBT93-6-A3L	STANDARD SPRING WASHER		2	
1.5	GBT5783-M6X12-8. 8-A2L	HEX HEAD BOLTS		2	
2	D20011. 40-02	PEDAL LOCKING SPRING		1	
3	GBT97. 1-10-A3L	FLAT WASHERS		1	
4	GBT91-3. 2X25-A3L	COTTER PIN		1	
5	GBT882-B8X24-A3L	PIN		2	
6	GBT97. 1-8-A3L	FLAT WASHERS		2	
7	GBT91-2X25-A3L	COTTER PIN		2	
8	GBT5783-M8X20-8. 8-A2L	HEX HEAD BOLTS		2	
9	GBT93-8-A3L	STANDARD SPRING WASHER		2	
10	DG2002. 40. 4	PEDAL WELDMENT		1	
11	DG2007. 40. 1	PEDAL SUPPORT WELDMENT		1	
12	DG2002. 40-01	PEDAL RETURN SPRING		1	
13	GBT894. 1-18	RETAINING RING FOR SHAFT		1	
14	DV01409010004	PARKING BRAKE STEEL WIRE ASSEMBLY		1	

LOVOL
9ZR D22327

RGV1102020000K HEADER ASSEMBLY-1




RGV1102020000K HEADER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV1102020000K	HEADER ASSEMBLY	003	1	
1	DV01102000100	PRESSURE PLATE WELDMENT 1		2	
2	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		6	
3	DV01102000102	PRESSURE PLATE WELDMENT 2		1	
4	GBT97. 1-10-A3L	FLAT WASHER		12	
5	GBT93-10-A3L	STANDARD SPRING WASHER		14	
6	GBT5783-M10X25-8. 8-A3L	HEXAGON BOLT		8	
7	DV01102000103	PRESSURE PLATE 2		1	
8	RGV1102020004K	HEADER		1	
9	RV01102000074	TRANSMISSION SHAFT BONNET		1	
10	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		12	
11	GBT93-8-A3L	STANDARD SPRING WASHER		12	
12	GBT96. 1-8-A3L	BIG WASHER		14	
13	GBT93-12-A3L	STANDARD SPRING WASHER		3	
14	RV01102000041	ROCK ARM		1	
15	GBT5786-M12X1. 5X40-8. 8-A3L	HEXAGON BOLT		1	
16	GBT97. 1-12-A3L	FLAT WASHER		2	
17	GBT5783-M12X45-8. 8-A3L	HEXAGON BOLT		2	
18	RGV1102020001K	SWING RING TRANSMISSION		1	
19	RV01102010001K	CHAIN-198/10A		1	
20	DV01102000111	LIMIT PLATE		1	
21	DV01102030043	COVER WELDMENT		1	
22	GBT5783-M10X30-8. 8-A3L	HEXAGON BOLT		2	

RGV1102020000K HEADER ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	RV01102010005	CHAIN-76/10A		1	
24	RGV1102020012K	TENSION ORGANIZATION ASSEMBLY		1	
25	GBT5783-M10X20-8. 8-A3L	HEXAGON BOLT		2	
26	RV01104010002	CHAIN 122/08B		1	

RGV1102020000K HEADER ASSEMBLY-2




RGV1102020000K HEADER ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV1102020000K	HEADER ASSEMBLY		1	
1	GBT6170-M6-8-A2L	HEXAGON NUT, TYPE-1		4	
2	GBT93-6-A3L	STANDARD SPRING WASHER		10	
3	GBT96. 1-6-A3L	BIG WASHER		4	
4	RV01102000059	SHIELD		2	
5	GBT96. 1-8-A3L	BIG WASHER		14	
6	DV01102000138	PRESSING SPRING		1	
7	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		2	
8	G15. 2-13	STRAW FENDER PLATE		2	
9	GBT97. 1-6-A3L	FLAT WASHER		6	
10	GBT5783-M6X12-8. 8-A2L	HEXAGON BOLT		4	
11	GBT5783-M6X20-8. 8-A2L	HEXAGON BOLT		2	
12	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		6	
13	GBT5783-M10X70-8. 8-A3L	HEXAGON BOLT		1	
14	RV03102010001	HEADER COVER WELDMENT		1	
15	GBT93-8-A3L	STANDARD SPRING WASHER		12	
16	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		12	

LOVOL
9ZR D22327

RGV1102020000K HEADER ASSEMBLY-3




RGV1102020000K HEADER ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RGV1102020001K	SWING RING TRANSMISSION		1	
	RGV1102020000K	HEADER ASSEMBLY		1	
1	GBT894. 1-25	CIRCLIP FOR SHAFT		1	
2	GBT276-6305-2RS	DEEP GROOVE BALL BEARING		1	
3	DV01102100001	DRIVING SPROCKET		1	
4	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		2	
5	GBT84-M8X25-33H	LOCKING BOLT		2	
6	RGV3102050004	SWING RING TRANSMISSION SHAFT		1	
7	DV01102000074	BEARING SEAT		1	
8	RV01102020002	WASHER		1	
9	GBT276-6206-2RS	DEEP GROOVE BALL BEARING		1	
10	RV01102000035	SPROCKET, W/ 16 TEETH		1	
11	GBT93-8-A3L	STANDARD SPRING WASHER		2	
12	GBT70. 1-M8X12-8. 8-A2L	INNER HEXAGON SCREW		2	
13	RGV3102040018	THE ECCENTRIC SHAFT HEAD WELD		1	
14	RGV1102010002K	SWING RING ASSEMBLY		1	
14. 1	RGV3102040016	SWING ROD WELDMENT		1	
14. 2	GBT893. 1-35	CIRCLIPS FOR HOLE		2	
14. 3	GBT276-6202-2RS	DEEP GROOVE BALL BEARING		2	
14. 4	GBT893. 1-80	CIRCLIPS FOR HOLE		1	
14. 5	GBT276-6208-2RS	DEEP GROOVE BALL BEARING		2	
14. 6	RV01102000037	PENDULUM RING SEAT		1	
15	JBZQ4342-40	HEAVY SHAFT WITH ELASTIC RING		1	

RGV1102020000K HEADER ASSEMBLY-3 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
16	DV01102000139	BEARING		1	
16.1	DV01102000140	BEARING SEAT		1	
16.2	GBT3882-UE206	BEARING		1	
17	GBT1096-8X7X45	FLAT KEY		1	

RGV1102020000K HEADER ASSEMBLY-4



RGV1102020000K HEADER ASSEMBLY-4


No.	Part No.	Description	Version	QTY.	Remark
	RGV1102020000K	HEADER ASSEMBLY		1	
1	RV01102000041	ROCK ARM		1	
1.1	GBT6170-M14-8-A3L	HEXAGON NUT, TYPE-1		1	
1.2	GBT93-14-A3L	STANDARD SPRING WASHER		1	
1.3	RV01103000021	SHAFT SLEEVE		2	
1.4	RV01103000019	OIL SEAL 20 X42X6		2	
1.5	GBT893.1-42	CIRCLIPS FOR HOLE		2	
1.6	RV01102000042	SWING ARM		1	
1.7	GBT276-6302-2RS	DEEP GROOVE BALL BEARING		1	
1.8	RV01103000018	CONNECTING BOLT		1	
2	RGV1102020012K	TENSION ORGANIZATION ASSEMBLY		1	
2.1	GBT91-4X28-A3L	SPLIT PIN		2	
2.2	GBT97.1-16-A3L	FLAT WASHER		3	
2.3	DG2002.2A.2-06	GASKET		4	
2.4	DV01102000113	INSTALLATION PLATE		1	
2.5	DG2002.2A.2-05	TORSION SPRING		1	
2.6	RGV3102040023	SUPPORT ROD WELDMENT		1	
2.7	RV01102000072	BRACKET WELDMENT		1	
2.8	RGV1102020013K	TENSION SPROCKET ASSEMBLY		1	
2.9	RGV1108010006K	TENSION SPROCKET ASSEMBLY		1	
2.10	DG2002.2A.2-03	SPRING		1	
2.11	DG2002.12.6b-01	BOLT		1	

RGV1102020000K HEADER ASSEMBLY-4 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
2. 12	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		2	
2. 13	GBT894.1-17	CIRCLIP FOR SHAFT		3	

LOVOL
9ZR D22327

RGV1102020000K HEADER ASSEMBLY-5



RGV1102020000K HEADER ASSEMBLY-5

No.	Part No.	Description	Version	QTY.	Remark
	RGV1102020000K	HEADER ASSEMBLY		1	
	RGV1102020004K	HEADER		1	
1	GBT5789-M8X16-8. 8-A2L	HEXAGON FLANGE NUT		5	
2	GBT96. 1-8-A3L	BIG WASHER		5	
3	DV01102000099	SHORT GRASSPROOF COVER		1	
4	DV01102000098	LONG GRASSPROOF COVER		1	
5	RGV1102020014K	HEADER WELDMENT		1	

NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com

NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com


NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com

NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com

LOVOL

9ZR D22327


RV01103000000 CUTTER ASSEMBLY-1



RV01103000000 CUTTER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RV01103000000	CUTTER ASSEMBLY	004	1	
1	GBT5783-M10X25-8. 8-A3L	HEX HEAD BOLTS		8	
2	GBT93-10-A3L	STANDARD SPRING WASHER		8	
3	RV01103000025	WASHER		8	
4	RV01103000001	CUTTER		1	

RV01103000000 CUTTER ASSEMBLY-2



RV01103000000 CUTTER ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RV01103000001	CUTTER		1	
	RV01103000000	CUTTER ASSEMBLY		1	
1	GBT5783-M8X16-8.8-A2L	HEX HEAD BOLTS		4	
2	RV01103000011	LEFT TOOTHED PLATE		1	
3	RV01103000002	MOVING CUTTER COMBINATION		1	
4	GBT93-8-A3L	STANDARD SPRING WASHER		6	
5	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		6	
6	RV01103000010	RIGHT AID CONVEYOR		1	
7	GBT12-M10X30-8.8-A3L	BOLT		15	
8	RV01103000012a	KNIFE BEAM		1	
9	DV01103010017	KNIFE GUARD		14	
10	GBT93-10-A3L	STANDARD SPRING WASHER		30	
11	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		30	
12	GBT12-M10X40-8.8-A3L	BOLT		10	
13	DV01103010015	CUTTER GUARD		5	
14	DG2004.3.1-04	GASKET		5	
15	DV01103010012	BRAKE DISC		7	
16	GBT12-M10X35-8.8-A3L	BOLT		5	
17	DV01103010016	CUTTER GUARD		1	
18	RV01103000013	SUPPORT PLATE		1	
19	RV01103000015	HALF THE BLADE GUARD		1	
20	RV01103000014	HALF THE BLADE SPACER		2	

RV01103000000 CUTTER ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
21	RV01103000016	ADJUSTMENT MATS		1	
22	GBT5783-M8X25-8. 8-A2L	HEX HEAD BOLTS		2	

NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com

NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com


NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com

NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com

LOVOL

9ZR D22327


RV01103000000 CUTTER ASSEMBLY-3



RV01103000000 CUTTER ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RV01103000000	CUTTER ASSEMBLY		1	
	RV01103000001	CUTTER		1	
1	GBT6170-M14-8-A3L	TYPE 1 HEX NUT		1	
2	GBT93-14-A3L	STANDARD SPRING WASHER		1	
3	RV01103000020	LINK		2	
4	RV01103000021	SLEEVE		2	
5	GBT893.1-42	RETAINING RING FOR HOLE		2	
6	RV01103000019	OIL SEAL 20 X42X6		2	
7	GBT276-6302-2RS	DEEP GROOVE BALL BEARING		1	
8	RV01103000018	CONNECTING BOLT		1	

RV01103000000 CUTTER ASSEMBLY-4




RV01103000000 CUTTER ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RV01103000002	MOVING CUTTER COMBINATION		1	
	RV01103000001	CUTTER		1	
	RV01103000000	CUTTER ASSEMBLY		1	
1	GBT867-6X20	RIVET		16	
2	RV01103000009	HALF BLADE 2		1	
3	GBT867-6X16	RIVET		40	
4	RV01103000006	HELP SHIP THE BRACKET		4	
5	DV01103010003	KNIFE SECTION		26	
6	RV01103000003	BIT WELDED		1	
7	RV01103000007	HALF BLADE 1		1	
8	RV01103000008	KNIFE BACK		1	

LOVOL
9ZR D22327

LOVOL
9ZR D22327

RGV1105020000K FEEDING AUGER ASSEMBLY-1




RGV1105020000K FEEDING AUGER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV1105020000K	FEEDING AUGER ASSEMBLY		1	
1	GBT5783-M10X30-8.8-A3L	HEXAGON BOLT		1	
2	GBT93-10-A3L	STANDARD SPRING WASHER		18	
3	DG2002.5-07	RETAINER PLATE		1	
4	RV03105010025	AUGER CHAIN PULLEY WELDMENT		1	
5	GBT97.1-10-A3L	FLAT WASHER		12	
6	RV01105000022	BEARING SEAT		1	
7	GBT5783-M10X70-8.8-A3L	HEXAGON BOLT		1	
8	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		9	
9	GBT96.1-10-A3L	BIG WASHER		4	
10	RV01105000002	RIGHT ADJUSTING PLATE		1	
11	GBT12-M10X25-8.8-A3L	BOLT		4	
12	GBT5783-M10X25-8.8-A3L	HEXAGON BOLT		13	
13	RV01105000013	DRIVING SHAFT		1	
14	DV01105010034	LEFT DRAW TOOTH SEAT		1	
15	RV03105010015	EXTENSIBLE TOOTH SHAFT		1	
16	GBT97.1-18-A3L	FLAT WASHER		1	
17	GBT93-18-A3L	STANDARD SPRING WASHER		1	
18	GBT6171-M18X1.5-10-A3L	HEXAGON NUT, TYPE-1		1	
19	RV03105010019	DRAW TOOTH ROD COMBINATION		9	
20	GBT1096-C8X7X50	FLAT KEY		1	
21	F103135	BOLT		3	
22	RV01105020011	DIAL THE TOOTH RIGHT HOLDER ASSEMBLY		1	

RGV1105020000K FEEDING AUGER ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	GBT93-8-A3L	STANDARD SPRING WASHER		15	
24	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		5	

RGV1105020000K FEEDING AUGER ASSEMBLY-2



RGV110502000K FEEDING AUGER ASSEMBLY-2


No.	Part No.	Description	Version	QTY.	Remark
1	GBT5783-M10X25-8. 8-A3L	HEXAGON BOLT		13	
2	GBT93-10-A3L	STANDARD SPRING WASHER		18	
3	RV01105020010	BEARING ASSEMBLY - 1		2	
4	RV03105010014	ECCENTRIC ADJUSTING SHAFT		1	
5	GBT1096-8X7X40	FLAT KEY		1	
6	GBT882-B10X90-A3L	PIN SHAFT		1	
7	DV01105010010	FLOATING BLOCK		1	
8	GBT97. 1-10-A3L	FLAT WASHER		12	
9	Q50110	LOCK PIN		1	
10	D20012. 5-05	SPRING		1	
11	HC1801. 28. 2-01	TENSION BOLT		1	
12	GBT96. 1-8-A3L	BIG WASHER		1	
13	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		5	
14	DV01105010049	ADJUSTING BLOCK		1	
15	DV01105010011	FIXED PLATE		1	
16	GBT93-12-A3L	STANDARD SPRING WASHER		2	
17	GBT5783-M12X45-8. 8-A3L	HEXAGON BOLT		2	
18	RV03105010022	DRAW TOOTH BUSH		9	
19	GBT93-8-A3L	STANDARD SPRING WASHER		15	
20	GBT97. 1-8-A3L	FLAT WASHER		12	
21	RV03105010012	AUGER INSTALLATION HOPE CAP WELDMENT		1	
22	RGV1105020001K	AUGER UNIT		1	
22. 1	RGV1105020002K	AUGER WELDMENT		1	

RGV1105020000K FEEDING AUGER ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
22.2	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		6	
22.3	GBT93-8-A3L	STANDARD SPRING WASHER		6	
22.4	GBT96.1-8-A3L	BIG WASHER		6	
22.5	DV01105010054	ANTIWRAP BOARD		2	
23	GBT70.1-M8X16-8.8-A2L	INNER HEXAGON SCREW		12	
24	RV03105010010	AUGER INSTALLATION HOPE CAP WELDMENT		1	
25	GBT9074.17-M8X20-8.8-A2L	HEX BOLT, SPRING WASHER PEACE WASHER ASSEMBL		18	

LOVOL
9ZR D22327

RV01106010000K LEFT DIVIDER ASSEMBLY




RV01106010000K LEFT DIVIDER ASSEMBLY

序号	零件图号	零件名称	版本	数量	备注
	RV01106010000K	左分禾器总成		1	
1	GBT5783-M10X20-8.8-A3L	六角头螺栓		3	
2	GBT93-10-A3L	标准型弹簧垫圈		6	
3	GBT97.1-10-A3L	平垫圈		6	
4	DV01106010001	左支架焊合		1	
5	GBT6170-M8-8-A2L	1型六角螺母		4	
6	GBT93-8-A3L	标准型弹簧垫圈		4	
7	GBT97.1-8-A3L	平垫圈		4	
8	GBT5783-M10X30-8.8-A3L	六角头螺栓		3	
9	GBT96.1-8-A3L	大垫圈		4	
10	GBT5783-M8X20-8.8-A2L	六角头螺栓		4	
11	DV01106000024	左分禾器焊合		1	
12	GBT5783-M12X25-8.8-A3L	六角头螺栓		2	
13	GBT93-12-A3L	标准型弹簧垫圈		2	
14	GBT97.1-12-A3L	平垫圈		2	
15	DV01106010006	分禾杆焊合		1	

LOVOL
9ZR D22327

RGV1108010000K BRIDGE ASSEMBLY-1




RGV1108010000K BRIDGE ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV1108010000K	BRIDGE ASSEMBLY	002	1	
1	DV01108000185	BOLT		6	
2	HE2001. 8A-26	FRONT COVER PLATE		1	
3	RGV1108010001K	BRIDGE WELDMENT		1	
4	RGV1108010006K	TENSION SPROCKET ASSEMBLY		3	
4.1	Q43340	STEEL WIRE RETAINER RING FOR SHAFT		2	
4.2	DG2002. 8. 9-01	TENSIONER SPROCKET		1	
4.3	RGV1108010007K	BEARING		1	
5	GBT97. 1-10-A3L	FLAT WASHER		3	
6	GBT93-10-A3L	STANDARD SPRING WASHER		12	
7	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		12	
8	GBT882-B20X120-A3L	PIN SHAFT		1	
9	GBT97. 1-20-A3L	FLAT WASHER		2	
10	GBT91-5X50-A3L	SPLIT PIN		1	
11	RV01108000069	SAFETY COVER OF OIL CYLINDER ASSEMBLY		1	
12	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		4	
13	DG2006. 8-08	PRESSURE STRIP		1	
14	DV01108020112	SEAL PLATE		1	
15	DV01108000133	REAR COVER WELDMENT		1	
16	DV01108020037	SMALL BONNET		1	
17	GBT96. 1-8-A3L	BIG WASHER		8	
18	GBT93-8-A3L	STANDARD SPRING WASHER		16	
19	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		12	

RGV1108010000K BRIDGE ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
20	Q50108	LOCK PIN		1	
21	GBT97. 1-8-A3L	FLAT WASHER		9	
22	RGV1108010008K	TENSION SPROCKET ASSEMBLY		1	
22.1	RGV1108010009K	BEARING		1	
22.2	DV01108020053	TENSIONER SPROCKET		1	
22.3	Q43342	STEEL WIRE RETAINER RING FOR SHAFT		2	
23	DV01108020051	SPACER BUSH		1	
24	DV01108020050	RETAINER RING		1	
25	DV01108020111	SEAL PLATE		1	

RGV1108010000K BRIDGE ASSEMBLY-2



RGV1108010000K BRIDGE ASSEMBLY-2


No.	Part No.	Description	Version	QTY.	Remark
	RGV1108010000K	BRIDGE ASSEMBLY		1	
1	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		12	
2	GBT93-8-A3L	STANDARD SPRING WASHER		16	
3	GBT96. 1-8-A3L	BIG WASHER		8	
4	DV01108020082	SHIELD		1	
5	DV01108000012	GUIDE RUNNER		1	
6	GBT97. 1-8-A3L	FLAT WASHER		9	
7	GBT5783-M8X30-8. 8-A2L	HEXAGON BOLT		2	
8	DV01108000169	FEED INLET BAFFLE		1	
9	DV01108000139	GUIDE GRASS PLATE		1	
10	DV01108020039	AXLE GASKET		6	
11	GBT93-16-A3L	STANDARD SPRING WASHER		14	
12	GBT5786-M16X1. 5X45-8. 8-A3L	HEXAGON BOLT		6	
13	GBT6170-M14-8-A3L	HEXAGON NUT, TYPE-1		4	
14	RGV1108010010K	TENSION INSTALLATION		1	
14. 1	DG2006. 8. 6. 1	SCREW ROD		1	
14. 2	GBT97. 1-18-A3L	FLAT WASHER		1	
14. 3	GBT91-3. 2X28-A3L	SPLIT PIN		1	
14. 4	GBT882-B16X35-A3L	PIN SHAFT		1	
14. 5	DG2006. 8. 6. 3	TENSION BRACKET ASSEMBLY		1	
14. 5. 1	DG2006. 8. 6. 2	TENSIOING SUPPORT WELDED PART		1	
14. 5. 2	DG2002. 8. 2a-01	BUSH		2	
14. 6	DG2002. 2A. 2-03	SPRING		1	

RGV1108010000K BRIDGE ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
14.7	GBT97.1-16-A3L	FLAT WASHER		1	
14.8	DG2006.8.6-01	CONNECTING PLATE		1	
14.9	DG2006.8.6-02	BUSH		1	
14.10	GBT894.1-17	CIRCLIP FOR SHAFT		2	
14.11	RGV1108010006K	TENSION SPROCKET ASSEMBLY		1	
15	GBT97.1-20-A3L	FLAT WASHER		2	
16	GBT91-4X32-A3L	SPLIT PIN		1	
17	DV01108020085	COVER PLATE		1	
18	GBT5783-M8X16-8.8-A2L	HEXAGON BOLT		2	
19	RV01108000146	SCREW WELDMENT		2	
20	GBT5783-M12X35-8.8-A3L	HEXAGON BOLT		6	
21	GBT93-12-A3L	STANDARD SPRING WASHER		6	
22	GBT6170-M12-8-A3L	HEXAGON NUT, TYPE-1		4	
23	GBT96.1-12-A3L	BIG WASHER		4	

LOVOL
9ZR D22327

RGV1108010000K BRIDGE ASSEMBLY-3



RGV1108010000K BRIDGE ASSEMBLY-3


No.	Part No.	Description	Version	QTY.	Remark
	RGV1108010000K	BRIDGE ASSEMBLY		1	
1	GBT6170-M14-8-A3L	HEXAGON NUT, TYPE-1		4	
2	GBT93-14-A3L	STANDARD SPRING WASHER		2	
3	HG2007. 8-04	RETAINER RING		2	
4	DV01108000148	BELT PULLEY		1	
5	GBT893. 1-62	CIRCLIPS FOR HOLE		2	
6	DG2006. 8-10	ADJUSTING GASKET		1	
7	DV01108000009	RETAINER RING		2	
8	DV01108020114	DEEP GROOVE BALL BEARING		2	
9	GBT5783-M16X50-8. 8-A3L	HEXAGON BOLT		6	
10	GBT93-16-A3L	STANDARD SPRING WASHER		14	
11	DG2002. 8. 4	IDLE GEAR CONNECTING SEAT INSTALLATION		1	
12	DV01108020113	SPROCKET, W/ 13 TEETH		2	
13	DV01108000215	ANTI-WRAP CYLINDER		1	
13. 1	DV01108000216	ANTIWRAP CYLINDER		2	
13. 2	DV01108000218	FIXING PIPE		1	
13. 3	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		6	
13. 4	GBT93-8-A3L	STANDARD SPRING WASHER		6	
13. 5	GBT97. 1-8-A3L	FLAT WASHER		6	
14	GBT1096-C10X8X50	FLAT KEY		1	
15	DV01108000420	DRIVING SHAFT		1	
16	GBT1096-C8X7X70	FLAT KEY		1	
17	DV01108000424	SCREW		2	

RGV1108010000K BRIDGE ASSEMBLY-3 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
18	GBT6171-M12X1.25-8-A2L	HEXAGON NUT, TYPE-1		2	
19	DG2002. 8. 15	IDLE GEAR CONNECTING SEAT INSTALLATION		1	
20	HG2201. 8-03	17-TOOTH CHAIN PULLEY		1	
21	DV01108000004	REVERSAL PULLEY		1	
22	GBT6170-M16-8-A3L	HEXAGON NUT, TYPE-1		2	
23	GBT900-AYM16-M16X40-10. 9-A3L	DOUBLE END STUDS		2	
24	JBT7940. 1-M8X1	STRAIGHT FORCED FILLING OIL CUP		1	
25	DV01102000150	DUSTPROOF CAP OF OIL CUP		1	
26	DV01108000425	ADJUSTING GASKET		1	

LOVOL
9ZR D22327


RGV1108010000K BRIDGE ASSEMBLY-4



RGV1108010000K BRIDGE ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RGV1108010000K	BRIDGE ASSEMBLY		1	
1	RV01108000003K	CHAIN HARROW INSTALLATION		1	
1.1	GBT5783-M10X20-8.8-A3L	HEXAGON BOLT		60	
1.2	RV01108000149	CHAINHARROW		15	
1.3	RV01108000004K	CHAIN HARROW CONVEYOR		2	
1.4	GBT6187.1-M10-8-A3L	FULL METAL HEXAGON FLANGE LOCKING NUT		60	
2	DV01108000509	SPLINT		1	
2.1	GBT65-M10X30-4.8-A3L	SLOTTED COLUMN HEAD SCREW		12	
2.2	D168X.2a-10	NYLON SPLINT		4	
2.3	DG2006.8.3-02	SPLINT BATTEN		2	
2.4	DG2006.8.3-01	GUARD SUPPORT		2	
2.5	DV01108000510	BRACKET WELDMENT		2	
2.6	GBT97.1-10-A3L	FLAT WASHER		12	
2.7	GBT93-10-A3L	STANDARD SPRING WASHER		12	
2.8	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		12	
3	GBT5783-M10X25-8.8-A3L	HEXAGON BOLT		8	
4	GBT96.1-10-A3L	BIG WASHER		8	
5	GBT93-10-A3L	STANDARD SPRING WASHER		12	
6	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		12	

RGV1108010000K BRIDGE ASSEMBLY-5




RGV1108010000K BRIDGE ASSEMBLY-5

No.	Part No.	Description	Version	QTY.	Remark
1	RGV1108010004K	DRIVEN ROLLER		1	
2	RGV1108010005K	CYLINDER BODY WELDMENT		1	
3	RV01108000060	CYLINDER COVER WELDMENT		1	
4	RV01108000063	CYLINDER END COVER WELD 2		1	
5	GBT276-6204-2RS	DEEP GROOVE BALL BEARING		2	

LOVOL
9ZR D22327


RGV3101030000 REEL ASSEMBLY-1



RGV3101030000 REEL ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3101030000	REEL ASSEMBLY	001	1	
1	Q50114	LOCK PIN		2	
2	DV01101000005	CROSS PIN		2	
3	RGV3101030001	REEL WHEEL ASSEMBLY		1	
3.1	RGV3101030002	REEL ASSEMBLY		1	
3.2	CBT3496-JZ300GS	TIE		15	
3.3	RGV3101030004	ANTI ENTANGLEMENT TUBE		3	
3.4	RGV3101030003	ANTI ENTANGLEMENT TUBE		2	

RGV3101030000 REEL ASSEMBLY-2



RGV3101030000 REEL ASSEMBLY-2


No.	Part No.	Description	Version	QTY.	Remark
	RGV3101030001	REEL WHEEL ASSEMBLY		1	
	RGV3101030000	REEL ASSEMBLY		1	
	RGV3101030002	REEL ASSEMBLY		1	
1	DV01101000003	PULL MUSCLE		15	
2	RV01101000003	ECCENTRIC WHEEL SPOKE PLATE WELDMENT		1	
3	GBT889. 1-M8-8-A2L	HEXAGON LOCK NUTS WITH NON-METALLIC INSERT TYPE 1		30	
4	DG2002. 1-02	REEL SHAFT SEAT		15	
5	GBT97. 1-8-A3L	FLAT WASHERS		30	
6	GBT93-8-A3L	STANDARD SPRING WASHER		30	
7	GBT5782-M8X100-8. 8-A2L	HEX HEAD BOLTS		30	
8	DV01101000046	SPOKE PLATE		1	
9	DV01101030001	SPRING TOOTH SHAFT 1		2	
10	DV01101030005	SPRING TOOTH SHAFT 2		3	
11	GBT6170-M10-8-A3L	TYPE 1 HEX NUT		9	
12	GBT93-10-A3L	STANDARD SPRING WASHER		10	
13	GBT97. 1-10-A3L	FLAT WASHERS		6	
14	GBT12-M10X25-8. 8-A3L	BOLT		6	
15	GBT5786-M16X1. 5X40-8. 8-A3L	HEX HEAD BOLTS		1	
16	GBT93-16-A3L	STANDARD SPRING WASHER		1	
17	GBT97. 1-16-A3L	FLAT WASHERS		2	
18	GBT6171-M18X1. 5-8-A3L	TYPE 1 HEX NUT		1	
19	GBT93-18-A3L	STANDARD SPRING WASHER		1	
20	GBT97. 1-18-A3L	FLAT WASHERS		1	

RGV3101030000 REEL ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
21	RV03101020009	PULLEY		1	
22	DG2002.1-01	SLEEVE		4	
23	DV01101000029	WELDED RIGHT BEARING SEAT		1	
24	RV03101020007	ECCENTRIC ADJUSTING DISC WELDMENT		1	
25	DG2002.1-03	ROLLING WHEEL		3	
26	GBT96.1-10-A3L	LARGE WASHER		3	
27	DV01101000123	REEL SHAFT WELDMENT		1	
28	RV01101000001	SPOKE PLATE		1	
29	DV01101000004	RETAINING RING		1	
30	GBT5786-M10X1.25X30-8.8-A2L	HEX HEAD BOLTS		1	
31	GBT6170-M6-8-A2L	TYPE 1 HEX NUT		4	
32	GBT1096-8X7X45	FLAT KEY		1	
33	RGV4101030006	PRESSURE PLATE		2	
34	GBT5783-M6X20-8.8-A2L	HEXAGON BOLT		4	
35	RGV4101030005	ANTIWRAP BOARD		2	
36	DV01101000048	WELDED LEFT BEARING SEAT		1	
37	GBT97.1-6-A3L	FLAT WASHERS		8	
38	GBT93-6-A3L	STANDARD SPRING WASHER		4	

LOVOL
9ZR D22327

RGV3101030000 REEL ASSEMBLY-3




RGV3101030000 REEL ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RGV3101030000	REEL ASSEMBLY		1	
	RGV3101030001	REEL WHEEL ASSEMBLY			
	RGV3101030002	REEL ASSEMBLY			
1	DV01101030001	SPRING TOOTH SHAFT 1		2	
1.1	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		12	
1.2	GBT93-8-A0P	STANDARD SPRING WASHER		12	
1.3	DV01101030008	SPRING TOOTH , TORSION SPRING TYPE		12	
1.4	GBT794-M8X40-8.8	REINFORCED ROUND HEAD SQUARE NECK BOLTS		12	
1.5	DV01101030002	SPRING TOOTH SHAFT WELDMENT I		1	
2	DV01101030005	SPRING TOOTH SHAFT 2		3	
2.1	GBT794-M8X40-8.8	REINFORCED ROUND HEAD SQUARE NECK BOLTS		12	
2.2	GBT93-8-A0P	STANDARD SPRING WASHER		12	
2.3	DV01101030008	SPRING TOOTH , TORSION SPRING TYPE		12	
2.4	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		12	
2.5	DV01101030006	SPRING TOOTH SHAFT WELDMENT II		1	

LOVOL
9ZR D22327

RGV1107020000K DIVIDER ASSEMBLY, RIGHT




RGV1107020000K DIVIDER ASSEMBLY, RIGHT

No.	Part No.	Description	Version	QTY.	Remark
	RGV1107020000K	DIVIDER ASSEMBLY, RIGHT	003	1	
1	GBT5783-M12X25-8.8-A3L	HEXAGON BOLT		2	
2	GBT93-12-A3L	STANDARD SPRING WASHER		2	
3	GBT97.1-12-A3L	FLAT WASHER		2	
4	RGV1107020003K	RH SPIKE-SPLITTER WELDED PART		1	
5	GBT97.1-10-A3L	FLAT WASHER		6	
6	GBT93-10-A3L	STANDARD SPRING WASHER		7	
7	GBT5783-M10X20-8.8-A3L	HEXAGON BOLT		3	
8	GBT5783-M10X25-8.8-A3L	HEXAGON BOLT		1	
9	GBT96.1-10-A3L	BIG WASHER		1	
10	DV01107010006	KNIFE HEAD BONNET WELDMENT		1	
11	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		6	
12	GBT93-8-A3L	STANDARD SPRING WASHER		6	
13	GBT97.1-8-A3L	FLAT WASHER		5	
14	RGV1107020001K	RIGHT BRACKET WELDMENT		1	
15	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		4	
16	GBT96.1-8-A3L	BIG WASHER		5	
17	GBT5783-M10X30-8.8-A3L	HEXAGON BOLT		3	

RGV1407020000K STEPLESS SPEED CHANGING CONTROL ASSEMBLY

LOVOL
9ZR D22327




RGV1407020000K STEPLESS SPEED CHANGING CONTROL ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV1407020000K	STEPLESS SPEED CHANGING CONTROL ASSEMBLY	002	1	
1	DG2001.35.6	HANDLESLEEVE		1	
2	GBT6172.1-M12-04-A3L	HEXAGON THIN NUT		1	
3	DG2001.35.5a	WELDED HANDLE BAR		1	
4	D168X.5.7-04	TORSION SPRING		1	
5	GBT882-B10X90-A3L	PIN SHAFT		1	
6	HG2201.35.2	ROCKER WELDMENT		1	
7	DG2001.35-01	FRICTION PLATE		2	
8	GBT97.1-10-A3L	FLAT WASHER		1	
9	GBT91-3.2X22-A3L	SPLIT PIN		1	
10	DG2001.35-02	PAD BLOCK		1	
11	BA150B2.21.2-02	BUTTERFLY SPRING		3	
12	GBT6172.1-M20-04-A9L	HEXAGON THIN NUT		2	
13	DV01407070001	PULLRODCOMBINATION		1	
13.1	D1681.35.2-01a	SELF LUBRICATING BALL JOINT		1	
13.2	GBT6171-M10X1.25-8-A2L	HEXAGON NUT, TYPE-1		1	
13.3	DV01407070002	PULL ROD		1	
13.4	GBT6171-M10X1.25-LH-8-A2L	HEXAGON NUT, TYPE-1		1	
13.5	DG2001.35.2-01a	LEFT-HAND SELF-LUBRICATION BALL CONNECTOR		1	
14	DV01407000001	CONNECTING PLATE WELDMENT		1	
15	GBT5782-M5X50-8.8-A1L	HEXAGON BOLT		1	
16	GBT93-5-A3L	STANDARD SPRING WASHER		1	
17	GBT6170-M5-8-A2L	HEXAGON NUT, TYPE-1		1	

RGV1407020000K STEPLESS SPEED CHANGING CONTROL ASSEMBLY (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
18	GBT5783-M8X40-8.8-A2L	HEXAGON BOLT		1	
19	GBT93-8-A3L	STANDARD SPRING WASHER		1	

DG2001. 20 FAN ASSEMBLY-1




DG2001. 20 FAN ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	DG2001. 20	FAN ASSEMBLY	016	1	
1	DG2001. 20. 3	BEARING SEAT		1	
1. 1	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	
1. 2	JBT7940. 1-M6	STRAIGHT FORCED FILLING OIL CUP		1	
1. 3	DG2001. 20. 3-01	BEARING SEAT		1	
1. 4	GBT3882-UE206	BEARING		1	
2	DG2001. 20. 5	BEARING SEAT		1	
2. 1	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	
2. 2	JBT7940. 1-M6	STRAIGHT FORCED FILLING OIL CUP		1	
2. 3	DG2001. 20. 3-01	BEARING SEAT		1	
2. 4	GBT3882-UE206	BEARING		1	
3	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		7	
4	GBT93-10-A3L	STANDARD SPRING WASHER		11	
5	GBT97. 1-10-A3L	FLAT WASHER		4	
6	GBT5783-M10X30-8. 8-A3L	HEXAGON BOLT		4	
7	DG2001. 20. 1a	VANE COMPONENT		1	
8	GBT1096-C8X7X40	FLAT KEY		1	
9	DG2001. 20-04a	LEFT FIXING PLATE		1	
10	GBT5783-M10X20-8. 8-A3L	HEXAGON BOLT		4	
11	DG2001. 20-05b	INNER ADJUSTING WASHER		2	
12	DG2001. 20-01b	FIXED PLATE		1	
13	DG2001. 20-03b	ADJUSTING GASKET		2	
14	DG2001. 20-02b	MOVINGPLATE		1	

DG2001. 20 FAN ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
15	DG2001. 20-06	SHAFT END RETAINING RING		1	
16	GBT93-8-A3L	STANDARD SPRING WASHER		1	
17	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		1	
18	GBT5782-M10X40-8. 8-A3L	HEXAGON BOLT		3	
19	DG2001. 20-07	SPACER BUSH		1	

DG2001. 20 FAN ASSEMBLY-2




DG2001. 20 FAN ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	DG2001. 20. 1a	VANE COMPONENT		1	
	DG2001. 20	FAN ASSEMBLY		1	
1	DG2001. 20. 1a-01	SHAFT-FAN		1	
2	DG2001. 20. 1. 3	RIGHT HUB WELDMENT		1	
3	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		4	
4	GBT821-M10X25-33H	TIGHTENING SCREW, W/ SQUARE HEAD FLAT END		4	
5	DG2001. 20. 1. 2	LEFT HUB WELDMENT		1	
6	DG2001. 20. 1-02	FAN BLADE		4	
7	GBT5783-M8X16-8. 8-A2L	HEXAGON BOLT		16	
8	GBT93-8-A3L	STANDARD SPRING WASHER		16	
9	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		16	
10	HE2001. 14. 1-02	BALANCING BLOCK		2	

LOVOL
9ZR D22327

LOVOL
9ZR D22327

RGV1201020000K THRESHING BODY ASSEMBLY-1




RGV1201020000K THRESHING BODY ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV1201020000K	THRESHING BODY ASSEMBLY		1	
1	GBT894. 1-20	CIRCLIP FOR SHAFT		2	
2	GBT97. 1-20-A3L	FLAT WASHER		1	
3	DV01201030016	TENSIONER ASSEMBLING		1	
4	GBT5782-M8X50-8. 8-A2L	HEXAGON BOLT		2	
5	GBT93-8-A3L	STANDARD SPRING WASHER		22	
6	DV01201000182	LIMITING ROD		1	
7	RGV1201020001K	THRESHER BODY WELDMENT		1	
8	GBT5783-M10X30-8. 8-A3L	HEXAGON BOLT		16	
9	GBT93-10-A3L	STANDARD SPRING WASHER		16	
10	GBT5783-M12X25-8. 8-A3L	HEXAGON BOLT		2	
11	GBT93-12-A3L	STANDARD SPRING WASHER		4	
12	GBT5783-M12X30-8. 8-A3L	HEXAGON BOLT		2	
13	GBT97. 1-10-A3L	FLAT WASHER		28	
14	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		12	
15	JBT7274. 4-BM8X32	HANDLE WELDMENT		8	
16	DG2004. 12. 9	COVER		2	
17	GBT62-M8-A2L	BUTTERFLY NUT		5	
18	GBT62-M6-A2L	BUTTERFLY NUT		2	
19	GBT93-6-A3L	STANDARD SPRING WASHER		13	
20	GBT96. 1-6-A3L	BIG WASHER		2	
21	DG2007. 12-09	AIR ADJUSTING BAFFLE 2		2	
22	DG2007. 12-08	AIR ADJUSTING BAFFLE 1		2	

RGV1201020000K THRESHING BODY ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		10	
24	JBT7940.1-M6	STRAIGHT FORCED FILLING OIL CUP		3	
25	GBT97.1-8-A3L	FLAT WASHER		12	
26	GBT5783-M6X12-8.8-A2L	HEXAGON BOLT		3	
27	DG2007.12.5	REINFORCED PLATE		1	

RGV1201020000K THRESHING BODY ASSEMBLY-2



RGV1201020000K THRESHING BODY ASSEMBLY-2


No.	Part No.	Description	Version	QTY.	Remark
	RGV1201020000K	THRESHING BODY ASSEMBLY		1	
1	GBT5783-M6X16-8. 8-A2L	HEXAGON BOLT		6	
2	GBT93-6-A3L	STANDARD SPRING WASHER		13	
3	DV01201010008	PRESSURE PLATE		2	
4	DV01201010007	RETAINER		1	
5	RV01201060004	TENSIONER ASSEMBLING		1	
6	DV01201030011	TENSIONER ASSEMBLING		1	
7	DG2007. 12B. 10	BONNET SUPPORT WELDMENT		1	
8	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		10	
9	GBT894. 1-20	CIRCLIP FOR SHAFT		2	
10	GBT97. 1-10-A3L	FLAT WASHER		28	
11	GBT93-8-A3L	STANDARD SPRING WASHER		22	
12	GBT5783-M8X25-8. 8-A2L	HEXAGON BOLT		5	
13	DG2002. 12-04	LEFT HOLE COVER		1	
14	GBT62-M8-A2L	BUTTERFLY NUT		5	
15	JBT7940. 1-M6	STRAIGHT FORCED FILLING OIL CUP		3	
16	DV01201030007	PULLEY INSTALLATION		1	
17	DV01201030008	TENSION WHEEL INSTALLATION 2		1	
18	GBT894. 1-15	CIRCLIP FOR SHAFT		1	
19	DV01201030010	TENSIONER ASSEMBLING		1	
20	DG2007. 12B. 7	BONNET SUPPORT WELDMENT		1	
21	GBT894. 1-25	CIRCLIP FOR SHAFT		1	
22	GBT5789-M6X20-8. 8-A2L	HEXAGON FLANGE NUT		4	

RGV1201020000K THRESHING BODY ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	RGV1201020007K	PRESSURE PLATE		1	
24	RGV1201020006K	GUARD		1	
25	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		4	

LOVOL
9ZR D22327

RGV1201020000K THRESHING BODY ASSEMBLY-3



RGV1201020000K THRESHING BODY ASSEMBLY-3


No.	Part No.	Description	Version	QTY.	Remark
	RGV1201020000K	THRESHING BODY ASSEMBLY		1	
1	DG2004. 12. 8a	SHIELD		1	
2	GBT5783-M10X30-8. 8-A3L	HEXAGON BOLT		16	
3	GBT97. 1-10-A3L	FLAT WASHER		28	
4	GBT5783-M6X16-8. 8-A2L	HEXAGON BOLT		6	
5	GBT93-6-A3L	STANDARD SPRING WASHER		13	
6	DG2002. 12-07a	PRESSURE PLATE 1		1	
7	DG2007. 12-06	SEAL PRESSNESS PLATE		1	
8	GBT93-10-A3L	STANDARD SPRING WASHER		16	
9	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		3	
10	GBT93-8-A3L	STANDARD SPRING WASHER		22	
11	GBT97. 1-8-A3L	FLAT WASHER		12	
12	DV01201000209	CONNECTING PLATE WELDMENT		1	
13	DV01201000205	PULLEY BRACKET WEDMENT		1	
14	GBT96. 1-8-A3L	BIG WASHER		3	
15	GBT5783-M8X25-8. 8-A2L	HEXAGON BOLT		5	
16	DV01201000119	SIEVE BOX SEAT PLATE		2	
17	DG2007. 12-05	SEAL PLATE		1	
18	DG2002. 12-06	CURTAIN BAFFLE		1	
19	GBT97. 1-6-A3L	FLAT WASHER		5	
20	GBT5783-M6X20-8. 8-A2L	HEXAGON BOLT		4	
21	GBT97. 1-12-A3L	FLAT WASHER		1	
22	GBT6173-M12X1. 5-05-A3L	HEXAGON THIN NUT		2	

RGV1201020000K THRESHING BODY ASSEMBLY-3 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	GBT6171-M12X1.5-8-A3L	HEXAGON NUT, TYPE-1		2	
24	GBT5786-M12X1.5X55-8.8-A3L	HEXAGON BOLT		2	
25	GBT96.1-12-A3L	BIG WASHER		1	
26	DG2007.70E.16-02	ADJUSTING GASKET		2	
27	DV01201000187	SUPPORT WELD		1	
28	GBT6171-M16X1.5-10-A3L	HEXAGON NUT, TYPE-1		2	
29	GBT6173-M16X1.5-05-A3L	HEXAGON THIN NUT		1	
30	DV01201000188	PAD BOARD		2	
31	GBT5783-M6X12-8.8-A2L	HEXAGON BOLT		3	
32	GBT93-16-A3L	STANDARD SPRING WASHER		1	
33	DV01102000149	DUSTPROOF CAP OF OIL CUP		3	
34	GBT96.1-6-A3L	BIG WASHER		2	
35	GBT62-M6-A2L	BUTTERFLY NUT		2	
36	JBT7940.1-M6	STRAIGHT FORCED FILLING OIL CUP		3	
37	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		12	
38	DV01201000132	SIDE RETAINER PLATE, RIGHT		1	
39	GBT62-M8-A2L	BUTTERFLY NUT		5	

LOVOL
9ZR D22327

RGV1201020000K THRESHING BODY ASSEMBLY-4



RGV1201020000K THRESHING BODY ASSEMBLY-4


No.	Part No.	Description	Version	QTY.	Remark
	RGV1201020000K	THRESHING BODY ASSEMBLY		1	
	RGV1201020001K	THRESHER BODY WELDMENT		1	
1	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		27	
2	GBT93-8-A3L	STANDARD SPRING WASHER		30	
3	GBT97.1-8-A3L	FLAT WASHER		46	
4	DV01201000106	PLATE		1	
5	DV01201000107	LEFT PLATE		1	
6	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		19	
7	DG2007.12.9	GUIDE PLATE		1	
8	GBT5783-M8X16-8.8-A2L	HEXAGON BOLT		3	
9	RGV1201020002K	UPPER MACHINE BODY		1	
10	GBT5783-M6X12-8.8-A2L	HEXAGON BOLT		8	
11	GBT93-6-A3L	STANDARD SPRING WASHER		8	
12	DV01201030004	LOWER MACHINE BODY WELDMENT		1	
13	DV01206030000	CONCAVE ASSEMBLY		1	
13.1	GBT5783-M8X25-8.8-A2L	HEXAGON BOLT		8	
13.2	GBT93-8-A0P	STANDARD SPRING WASHER		8	
13.3	GBT97.1-8-A0P	FLAT WASHER		8	
13.4	GBT5782-M10X65-8.8-A3L	HEXAGON BOLT		4	
13.5	DV01206030001	CONCAVE PLATE WELDMENT		4	
13.6	DV01206000019	CONNECTING PLATE		8	
13.7	GBT6183.1-M10-8-A3L	HEXAGON FLANGE LOCKING NUT		4	
14	DG2002.12.5	WIND GUIDE WELDMENT		1	

RGV1201020000K THRESHING BODY ASSEMBLY-4 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
15	GBT93-10-A3L	STANDARD SPRING WASHER		5	
16	GBT97.1-10-A3L	FLAT WASHER		7	
17	GBT5783-M10X25-8.8-A3L	HEXAGON BOLT		3	
18	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		2	
19	GBT5783-M10X30-8.8-A3L	HEXAGON BOLT		2	
20	DG2002.12.8	导风板 合件2		1	

LOVOL
9ZR D22327

RGV1201020000K THRESHING BODY ASSEMBLY-5




RGV1201020000K THRESHING BODY ASSEMBLY-5

No.	Part No.	Description	Version	QTY.	Remark
	RGV1201020000K	THRESHING BODY ASSEMBLY		1	
1	RV01201060004	TENSIONER ASSEMBLING		1	
1.1	GBT893.1-42	CIRCLIPS FOR HOLE		1	
1.2	GBT276-6004-RS	DEEP GROOVE BALL BEARING		2	
1.3	DV01201000234	RETAINER RING		1	
1.4	GBT894.1-25	CIRCLIP FOR SHAFT		1	
1.5	DV01201030013	TENSION WHEEL WELDMENT		1	
1.6	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	
1.7	JBT7940.1-M6	STRAIGHT FORCED FILLING OIL CUP		1	
1.8	DV01201080004	ARM WELDMENT		1	
1.9	DG2002.12.4a-01	TENSION SPRING		1	
1.10	DV01201000177	PULL ROD		1	
1.11	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		2	
2	DV01201030007	PULLEY INSTALLATION		1	
2.1	GBT893.1-52	CIRCLIPS FOR HOLE		1	
2.2	GBT276-6205-RS	DEEP GROOVE BALL BEARING		1	
2.3	DG2002.12.10-01a	PULLEY		1	
2.4	DG2002.12.10-02	SPACER BUSH		1	
2.5	GBT276-6005-RS	DEEP GROOVE BALL BEARING		1	

LOVOL
9ZR D22327

RGV1201020000K THRESHING BODY ASSEMBLY-6



RGV1201020000K THRESHING BODY ASSEMBLY-6


No.	Part No.	Description	Version	QTY.	Remark
	RGV1201020000K	THRESHING BODY ASSEMBLY		1	
1	DV01201030008	TENSION WHEEL INSTALLATION 2		1	
1.1	GBT894. 1-15	CIRCLIP FOR SHAFT		1	
1.2	RV01201000198	支臂组件		1	
1.3	DV01201030009	TENSIONER COMBINATION		1	
1.4	DG2002. 12. 6-03	TENSION SPRING		1	
1.5	DG2002. 12. 6b-02	ADJUSTING BOLT 2		1	
1.6	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		2	
2	DV01201030011	TENSIONER ASSEMBLING		1	
2.1	GBT6170-M16-8-A3L	HEXAGON NUT, TYPE-1		1	
2.2	GBT93-16-A0P	STANDARD SPRING WASHER		1	
2.3	GBT97. 1-16-A0P	FLAT WASHER		1	
2.4	GBT893. 1-52	CIRCLIPS FOR HOLE		2	
2.5	GBT276-6205-2RS	DEEP GROOVE BALL BEARING		1	
2.6	D230D. 11. 3-01	TENSIONER		1	
2.7	DG2007. 12. 8-01	SHAFT SLEEVE		1	
2.8	D1681. 12. 2-03	TOOTHED GASKET		1	
2.9	GBT12-M16X80-8, 8-A3L	BOLT		1	
3	DV01201030016	TENSIONER ASSEMBLING		1	
3.1	JBT7940. 1-M6	STRAIGHT FORCED FILLING OIL CUP		1	
3.2	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	
3.3	GBT894. 1-20	CIRCLIP FOR SHAFT		1	
3.4	DG2002. 12. 4-01	TENSIONER		1	

RGV1201020000K THRESHING BODY ASSEMBLY-6 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
3. 5	GBT893. 1-42	CIRCLIPS FOR HOLE		2	
3. 6	GBT276-6004-RS	DEEP GROOVE BALL BEARING		2	
3. 7	DG2002. 12. 4-02	BUSH		1	
3. 8	DV01201010004	ARM WELDMENT		1	
3. 9	DV01201010006	BUSH		2	
3. 10	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		2	
3. 11	HG2201. 20B. 4a-01	BOLT		1	
3. 12	DG2002. 12. 4a-01	TENSION SPRING		1	

LOVOL
9ZR D22327


RV01202020000 CYLINDER COVER ASSEMBLY-1



RV01202020000 CYLINDER COVER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RV01202020000	CYLINDER COVER ASSEMBLY		1	
1	GBT923-M8-5	CAP NUT		2	
2	GBT93-8-A3L	STANDARD SPRING WASHER		8	
3	GBT97. 1-8-A3L	FLAT WASHER		8	
4	GBT70. 1-M8X20-8. 8-A2L	INNER HEXAGON SCREW		6	
5	DG2007. 13B-07	SCREW ROD		3	
6	DG2007. 13B-08	PAD BOARD		3	
7	DG2002. 13-10	FRONT/BACK SEAL PIECE		2	
8	RV01202020002	CYLINDER COVER WELDMENT		1	
9	DG2002. 13-12	RIGHT SIDE SEALING STRIP-2		2	
10	DG2007. 13B-11	RIGHT SIDE SEALING STRIP-1		2	
11	DG2007. 13B-09	SEAL STRIP		1	
12	DG2002. 13. 7	PNEUMATIC SPRING		1	
13	Q50110	LOCK PIN		2	
14	GBT93-12-A3L	STANDARD SPRING WASHER		3	

RV01202020000 CYLINDER COVER ASSEMBLY-2




RV01202020000 CYLINDER COVER ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RV01202020000	CYLINDER COVER ASSEMBLY		1	
	RV01202020002	CYLINDER COVER WELDMENT		1	
1	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		24	
2	GBT93-8-A3L	STANDARD SPRING WASHER		24	
3	GBT97.1-8-A3L	FLAT WASHER		24	
4	RV01202020001	CYLINDER COVER WELDMENT		1	
5	DG2002.13.5	GUIDE GRASS PLATE WELDMENT 3		1	
6	DG2002.13.4	GUIDE GRASS PLATE WELDMENT 2		4	
7	DG2002.13.3	GUIDE GRASS PLATE WELDMENT 1		3	

LOVOL
9ZR D22327

LOVOL
9ZR D22327


RV01208010000 SIEVE BOX ASSEMBLY-1



RV01208010000 SIEVE BOX ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RV01208010000	SIEVE BOX ASSEMBLY	005	1	
1	GBT5783-M6X16-8. 8-A2L	HEXAGON BOLT		16	
2	GBT93-6-A3L	STANDARD SPRING WASHER		26	
3	DG2002. 18-02	FRONT PRESSURE PLATE		1	
4	DG2002. 18-01	HEADBOARD		1	
5	DV01208000032	GRAIN ADJUSTING PLATE		1	
6	RV01208040003	SIEVE BOX WELDMENT		1	
7	DG2002. 18-14	GLUMES EXTENSION PLATE		1	
8	DG2002. 18-15	PRESSURE PLATE		1	
9	GBT97. 1-6-A3L	FLAT WASHER		17	
10	GBT6170-M6-8-A2L	HEXAGON NUT, TYPE-1		13	
11	DG2002. 18-08	TAIL SIDE PRESSURE PLATE		4	
12	DG2002. 18-09	TAIL SIDE PRESSURE PLATE		2	
13	GBT93-8-A3L	STANDARD SPRING WASHER		52	
14	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		36	
15	DG2002. 18-04	GRAIN PRESSURE PLATE		1	
16	DG2002. 18-06a	GRAIN SLIDE PLATE		1	
17	GBT5783-M8X16-8. 8-A2L	HEXAGON BOLT		4	
18	DV01208000028	GRAIN SLIDE PLATE SEAT		1	
19	GBT96. 1-6-A3L	BIG WASHER		4	

RV01208010000 SIEVE BOX ASSEMBLY-2




RV01208010000 SIEVE BOX ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RV01208010000	SIEVE BOX ASSEMBLY		1	
1	DG2004. 18-02	SIDE RETAINER PLATE, RIGHT		1	
2	DG2004. 18. 4	RIGHT INNER PRESSURE PLATE WELDMENT		1	
3	DG2004. 18. 3	LEFT INNER PRESSURE PLATE WELDMENT		1	
4	GBT5783-M6X16-8. 8-A2L	HEXAGON BOLT		16	
5	GBT93-6-A3L	STANDARD SPRING WASHER		26	
6	GBT97. 1-6-A3L	FLAT WASHER		17	
7	GBT276-6302-2RS	DEEP GROOVE BALL BEARING		2	
8	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		36	
9	GBT93-8-A3L	STANDARD SPRING WASHER		52	
10	GBT97. 1-8-A3L	FLAT WASHER		32	
11	GBT62-M6-A2L	BUTTERFLY NUT		4	
12	DV01208000001	BACKBOARD PLATE		1	
13	DG2002. 18-12	REAR PLASTIC PLATE		1	
14	DG2004. 18. 6	WIRE SIEVE WELDMENT		1	
15	DG2002. 18-18	EXTENSION PLATE		1	
16	GBT5783-M10X30-8. 8-A3L	HEXAGON BOLT		10	
17	GBT93-10-A3L	STANDARD SPRING WASHER		11	
18	GBT97. 1-10-A3L	FLAT WASHER		6	
19	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		5	
20	RV01208040004	SIEVE BOX DRIVE WELDMENT		1	
21	DG2004. 18-03	LH SIDE BAFFLE		1	

LOVOL
9ZR D22327

RV01208010000 SIEVE BOX ASSEMBLY-3




RV01208010000 SIEVE BOX ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RV01208010000	SIEVE BOX ASSEMBLY		1	
1	DG2002. 18-17	LOWER SIEVE		1	
2	DG2002. 18-11	LOWER SIEVE SIDE PLATE		2	
3	GBT93-8-A3L	STANDARD SPRING WASHER		52	
4	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		22	
5	DG2002. 18-10	LOWER SIEVE TRANVERSE PLATE		1	
6	GBT96. 1-8-A3L	BIG WASHER		6	
7	GBT6170-M6-8-A2L	HEXAGON NUT, TYPE-1		13	
8	GBT93-6-A3L	STANDARD SPRING WASHER		26	
9	DB200A1. 18. 5-01	PLATE		3	
10	GBT5783-M6X16-8. 8-A2L	HEXAGON BOLT		16	
11	DG2002. 18-19	LOWER SIEVE SPLINT		1	
12	GBT97. 1-8-A3L	FLAT WASHER		32	

LOVOL
9ZR D22327

RV01208010000 SIEVE BOX ASSEMBLY-4




RV01208010000 SIEVE BOX ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RV01208010000	SIEVE BOX ASSEMBLY		1	
1	DV01208000005	UPPER SCREEN ASSEMBLY		1	
1.1	GBT91-1.6X16-A3L	SPLIT PIN		64	
1.2	GBT97.1-6-A3L	FLAT WASHER		64	
1.3	DG2004.18.10.3	SIEVE LOWER CONNECTING PLATE WELDMENT		2	
1.4	DG2004.18.10.1	SIEVE UPPER CONNECTING PLATE WELDMENT		2	
1.5	DV01208000011	SIEVE PIECE WELDMENT		16	
1.6	DV01208000006	ADJUSTING SIEVE PIECE WELDMENT		1	
2	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		22	
3	GBT93-8-A3L	STANDARD SPRING WASHER		52	
4	GBT97.1-8-A3L	FLAT WASHER		32	
5	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		36	
6	GBT96.1-8-A3L	BIG WASHER		6	
7	DV01208000002	GUIDE PLATE WELDMENT		1	

LOVOL
9ZR D22327

RV01208010000 SIEVE BOX ASSEMBLY-5



RV01208010000 SIEVE BOX ASSEMBLY-5


No.	Part No.	Description	Version	QTY.	Remark
	RV01208010000	SIEVE BOX ASSEMBLY		1	
1	RV01208010001	TAILING SCREEN ASSEMBLY		1	
1.1	RV01208010002	TAIL SIEVE SUPPORT WELDMENT		1	
1.2	DG2004.18.2b-02	TOOTHED PLATE		25	
1.3	GBT6177.1-M6-8-A2L	HEXAGON FLANGE NUT		50	
1.4	DG2004.18.2b-03	UPPER REINFORCED PLATE		1	
1.5	DG2004.18.2b-04	DOWN REINFORCED PLATE		1	
1.6	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		1	
1.7	GBT93-8-A3L	STANDARD SPRING WASHER		1	
1.8	GBT96.1-8-A3L	BIG WASHER		2	
1.9	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		1	
1.10	DG2002.18.3-05	WIRE PIECE		1	
2	GBT5783-M6X20-8.8-A2L	HEXAGON BOLT		2	
3	GBT96.1-6-A3L	BIG WASHER		4	
4	DG2002.18-16	SPACING SLEEVE		2	
5	GBT93-6-A3L	STANDARD SPRING WASHER		26	
6	GBT6170-M6-8-A2L	HEXAGON NUT, TYPE-1		13	
7	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		36	
8	GBT93-8-A3L	STANDARD SPRING WASHER		52	
9	GBT97.1-8-A3L	FLAT WASHER		32	
10	GBT5783-M10X25-8.8-A3L	HEXAGON BOLT		1	

NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com

NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com

LOVOL
9ZR D22327

RV01208010000 SIEVE BOX ASSEMBLY-6



RV01208010000 SIEVE BOX ASSEMBLY-6

No.	Part No.	Description	Version	QTY.	Remark
	RV01208010000	SIEVE BOX ASSEMBLY		1	
1	RV01208040004	SIEVE BOX DRIVE WELDMENT		1	
1. 1	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		3	
1. 2	GBT93-8-A3L	STANDARD SPRING WASHER		2	
1. 3	GBT97. 1-8-A3L	FLAT WASHER		2	
1. 4	DG2002. 18. 4-06	BALANCING BLOCK		1	
1. 5	DG2002. 18. 4. 1a	DRIVE PULLEY WELDMENT		1	
1. 6	GBT5783-M8X65-8. 8-A2L	HEXAGON BOLT		2	
1. 7	JBT7940. 1-M6	STRAIGHT FORCED FILLING OIL CUP		2	
1. 8	GBT5782-M12X75-8. 8-A3L	HEXAGON BOLT		4	
1. 9	RGV3208030002	ROCKER		2	
1. 10	DG2002. 18. 4-07	BEARING 61913-2RLD		2	
1. 11	DG2002. 18. 4-02	ECCENTRIC WHEEL		2	
1. 12	GBT821-M8X25-33H	TIGHTENING SCREW, W/ SQUARE HEAD FLAT END		1	
1. 13	GBT3882-UEL205	BEARING		1	
1. 14	GBT3882-UB205	BEARING		1	
1. 15	DG2002. 18. 4-05a	BEARING SEAT		2	
1. 16	GBT93-12-A3L	STANDARD SPRING WASHER		8	
1. 17	GBT6170-M12-8-A3L	HEXAGON NUT, TYPE-1		4	
1. 18	GBT1096-8X7X45	FLAT KEY		1	
1. 19	GBT1096-8X7X36	FLAT KEY		2	
1. 20	DG2002. 18. 4-01a	DRIVING WHEEL SHAFT		1	
1. 21	DV01102000149	DUSTPROOF CAP OF OIL CUP		2	


RV01208010000 SIEVE BOX ASSEMBLY-6 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
1. 22	GBT5786-M12X1.25X40-10.9-A2L	HEXAGON BOLT		4	
1. 23	RGV3208030003	BEARING SEAT		2	
1. 24	GBT97.1-12-A3L	FLAT WASHER		4	
1. 25	GBT893.1-90	CIRCLIPS FOR HOLE		2	
2	DV01208000043	SPACER BUSH 2		1	
3	DV01208000042	SPACER BUSH 1		1	

LOVOL
9ZR D22327

DV01214030000 MAIN ENGINE TRANSMISSION ASSEMBLY

LOVOL
9ZR D22327




DV01214030000 MAIN ENGINE TRANSMISSION ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	DV01214030000	MAIN ENGINE TRANSMISSION ASSEMBLY		1	
1	DG2002K. 11-02	V-BELT SB75		1	
2	DV01214000005	V-BELT SB138		1	
3	DV01214030003	V-BELT		3	
4	DV01214000009	TRANSMITTE BRING 3 HBJ1570		1	
5	DV01214000006	V-BELT SB45		1	
6	DG2007. 11-01a	V-BELT SC54		1	

LOVOL
9ZR D22327


DV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-1



DV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-1

序号	零件图号	零件名称	版本	数量	备注
	DV01215000000	滚筒传动箱总成	008	1	
1	GBT5783-M8X25-8.8-A2L	六角头螺栓		4	
2	GBT93-8-A3L	标准型弹簧垫圈		4	
3	GBT97.1-8-A3L	平垫圈		4	
4	DV01215000003	托板焊合		1	
5	GBT96.1-8-A3L	大垫圈		1	
6	DV01215000002	调整垫		2	
7	DV01215000001	滚筒传动箱装配		1	
8	GBT93-12-A3L	标准型弹簧垫圈		8	
9	GBT5783-M12X35-8.8-A3L	六角头螺栓		2	
10	GBT5783-M12X40-8.8-A3L	六角头螺栓		6	
11	DG2001.28.3-01	制动回位弹簧		1	
12	DV01215000006a	托架焊合		1	

DV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-2



DV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-2


序号	零件图号	零件名称	版本	数量	备注
	DV01215000000	滚筒传动箱总成		1	
	DV01215000001	滚筒传动箱装配		1	
1	GBT6171-M16X1.5-8-A3L	1型六角螺母		1	
2	GBT93-16-A0P	标准型弹簧垫圈		1	
3	DV01215000017	垫圈 I		1	
4	GBT1096-8X7X30	平键		1	
5	DV01215000012	反转皮带轮		1	
6	DV01215000031	轴用挡圈100		1	
7	DV01215000016	手柄		1	
8	DV01215000030	反转支架调整垫片		999	
9	DV01215000018	反转支架		1	
10	DV01214010010	密封圈		1	
11	GBT893.1-80	孔用弹性挡圈		1	
12	DV01214010009	调整垫		999	
13	GBT276-6307	深沟球轴承		2	
14	DV01215000010	反转传动轴		1	
15	GBT5783-M10X30-8.8-A3L	六角头螺栓		6	
16	GBT93-10-A0P	标准型弹簧垫圈		6	
17	DV01215000037	反转箱体		1	
18	GBT3452.1-87.5X3.55G	液压气动用O形橡胶密封圈		1	

DV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-2 (cont'd.)

序号	零件图号	零件名称	版本	数量	备注
19	DV01215000040	反转锥齿轮		1	
20	GBT894.1-35	轴用弹性挡圈		1	
21	DV01215000036	传动箱体		1	
22	GBT894.1-15	轴用弹性挡圈		2	
23	DV01215000026	反转箱张紧轮		1	
24	GBT276-6202-2RS	深沟球轴承		1	

LOVOL
9ZR D22327

DV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-3




DV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-3

序号	零件图号	零件名称	版本	数量	备注
	DV01215000001	滚筒传动箱装配		1	
	DV01215000000	滚筒传动箱总成		1	
1	DV01214010018	通气管		1	
2	Q673B12	钢带型弹性环箍		1	
3	DV01214010019	螺塞		1	
4	GL05501010121	组合垫圈		1	
5	GBT3452.1-34.5X3.55G	液压气动用O形橡胶密封圈		1	
6	GBT9877.1-FB45X70X8D	内包骨架旋转轴唇形密封圈		1	
7	GBT276-6209	深沟球轴承		1	
8	DV01215000009	输出轴		1	
9	DV01215000039	被动锥齿轮		1	
10	DL13402010138	调整垫		999	
11	GBT276-6307	深沟球轴承		1	
12	GBT3452.1-132X3.55G	液压气动用O形橡胶密封圈		1	
13	DV01215000013	端盖		1	
14	JBT982-10	组合密封垫圈		2	
15	DV01215000029	螺塞		2	
16	GBT93-10-A0P	标准型弹簧垫圈		6	
17	GBT5783-M10X25-8.8-A3L	六角头螺栓		6	

LOVOL
9ZR D22327

DV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-4



DV01215000000 ROLLER TRANSMISSION BOX ASSEMBLY-4

序号	零件图号	零件名称	版本	数量	备注
	DV01215000001	滚筒传动箱装配		1	
	DV01215000000	滚筒传动箱总成		1	
1	GBT894. 1-40	轴用弹性挡圈		1	
2	DV01215000038	主动锥齿轮		1	
3	GBT276-6308	深沟球轴承		2	
4	DV01215000041	输入轴		1	
5	GBT1096-10X8X40	平键		1	
6	DV01215000027	张紧轮支架调整垫片		999	
7	DV01215000033	孔用挡圈90		1	
8	DV01215000028	输入轴油封		1	
9	DV01215000022	张紧轮支架		1	
10	DV01215000032	轴用挡圈110		1	
11	GBT5783-M8X16-8. 8-A2L	六角头螺栓		1	
12	GBT93-8-A0P	标准型弹簧垫圈		1	
13	GBT96. 1-8-A0P	大垫圈		1	
14	DV01215000015	张紧轮轴		1	
15	GBT893. 1-35	孔用弹性挡圈		2	
16	GBT276-6202-2RS	深沟球轴承		1	
17	DV01215000014	张紧轮		1	
18	DV01215000011	皮带轮		1	


DV0121500000 ROLLER TRANSMISSION BOX ASSEMBLY-4 (cont'd.)

序号	零件图号	零件名称	版本	数量	备注
19	DV01215000034	垫圈 II		1	
20	GBT93-20-A0P	标准型弹簧垫圈		1	
21	GBT6171-M20X1.5-8-A3L	1型六角螺母		1	

LOVOL
9ZR D22327

LOVOL
9ZR D22327

RV01301020000 GRAIN CLIMB MACHINE ASSEMBLY-1




RV01301020000 GRAIN CLIMB MACHINE ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RV01301020000	GRAIN CLIMB MACHINE ASSEMBLY	006	1	
1	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		17	
2	RV01302010017K	端盖焊合		1	
3	GBT93-8-A3L	STANDARD SPRING WASHER		33	
4	RV01302010011K	205外球面轴承座		1	
5	RV01301040009	INSTALLATION SEAT		1	
6	GBT5783-M8X30-8.8-A2L	HEXAGON BOLT		3	
7	RV01301020006K	籽粒壳体组件		1	
7.1	GBT93-6-A3L	STANDARD SPRING WASHER		6	
7.2	GBT93-8-A3L	STANDARD SPRING WASHER		12	
7.3	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		12	
7.4	BA150B2.111.7-02	WASHER 7X22X2		6	
7.5	GBT97.1-8-A3L	FLAT WASHER		12	
7.6	GBT6170-M6-8-A2L	HEXAGON NUT, TYPE-1		6	
7.7	GBT819.2-M6X16-8.8-A2L	SCREW		6	
7.8	RV01301020001K	VERTICAL COVER WELDMENT		1	
7.9	DV01301020006	LINER PLATE		1	
7.10	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		4	
7.11	DV01301000149	SHELL WELDMENT		1	
7.12	DV01301000004	SHELL WELDMENT		1	
7.13	DV01301000039	SHUTTER		1	
8	DV01301000065	GRAIN MOUTH SEAL STRIP		2	
9	GBT96.1-8-A3L	BIG WASHER		5	

RV01301020000 GRAIN CLIMB MACHINE ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
10	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		14	
11	GBT97.1-8-A3L	FLAT WASHER		5	
12	RV01301020002K	VERTICAL AUGER		1	
12.1	HE2001.17.2a-06	BALANCING BLOCK		1	
12.2	GBT12-M8X20-8.8-A2L	BOLT		4	
12.3	DG2003.17-04	VANE		2	
12.4	GBT889.1-M8-8	NUT		4	
12.5	RV01301020003K	VERTICAL AUGER WELDMENT		1	
13	GBT97.1-6-A3L	FLAT WASHER		6	
14	GBT1096-C8X7X22	FLAT KEY		2	
15	G15.10.19-09	RETAINER RING		2	
16	DV01301000018	SPROCKET 15 TEETH		1	
17	GBT70.1-M8X30-8.8-A2L	INNER HEXAGON SCREW		4	
18	GBT1096-8X7X25	FLAT KEY		1	
19	DV01301020013	TRANSMISSION BOX ASSEMBLY		1	
20	RV01302010011K	205外球面轴承座		1	
21	DV01301000071	SEAL SLEEVE		1	
22	GBT70.1-M6X16-8.8-A2L	INNER HEXAGON SCREW		1	
23	GBT93-6-A3L	STANDARD SPRING WASHER		6	
24	JBT7940.1-M6	STRAIGHT FORCED FILLING OIL CUP		1	
25	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	

RV01301020000 GRAIN CLIMB MACHINE ASSEMBLY-2




RV01301020000 GRAIN CLIMB MACHINE ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RV01301020000	GRAIN CLIMB MACHINE ASSEMBLY		1	
1	DV01301020008	GRAIN HORIZONTAL AUGER INSTALLATION		1	
2	GBT1096-C8X7X22	FLAT KEY		2	
3	DV01301000090	RIGHT INSTALLATION SEAT		1	
4	GBT276-6206-2RS	DEEP GROOVE BALL BEARING		1	
5	GBT893. 1-62	CIRCLIPS FOR HOLE		1	
6	RV01301020005	CHAIN 08B		1	
7	DV01301000114	SPROCKET 19 TEETH		1	
8	DV01301000029	SPROCKET DOWN COVER		1	
9	DG2001. 20-05	INNER ADJUSTING WASHER		1	
10	G15. 10. 19-09	RETAINER RING		2	
11	GBT93-8-A3L	STANDARD SPRING WASHER		33	
12	GBT5783-M8X25-8. 8-A2L	HEXAGON BOLT		4	
13	GBT5783-M6X16-8. 8-A2L	HEXAGON BOLT		2	
14	GBT97. 1-6-A3L	FLAT WASHER		6	
15	GBT5783-M6X12-8. 8-A2L	HEXAGON BOLT		3	
16	DV01301000031	SPROCKET TOP COVER		1	
17	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		17	
18	GBT96. 1-8-A3L	BIG WASHER		5	
19	GBT12-M8X45-8. 8-A2L	BOLT		1	
20	DV01301000108	TENSIONER		1	
21	DV01301000119	WASHER		1	
22	DV01301000109	MIDDLE SPACER BUSH		1	

LOVOL
9ZR D22327


RV01301020000 GRAIN CLIMB MACHINE ASSEMBLY-3



RV01301020000 GRAIN CLIMB MACHINE ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RV01301020000	GRAIN CLIMB MACHINE ASSEMBLY		1	
	DV01301020008	GRAIN HORIZONTAL AUGER INSTALLATION		1	
1	GBT6171-M14X1.5-8-A3L	HEXAGON NUT, TYPE-1		1	
2	GBT93-14-A3L	STANDARD SPRING WASHER		1	
3	DV01301000173	垫圈15X42X6		1	
4	DV01301000057	DRIVE BELT PULLEY		1	
5	G15.2-14	ADJUSTING GASKET		3	
6	GBT5783-M6X16-8.8-A2L	HEXAGON BOLT		3	
7	GBT93-6-A3L	STANDARD SPRING WASHER		3	
8	DV01301000055	BEARING COVER		1	
9	GBT276-6206-RS	DEEP GROOVE BALL BEARING		1	
10	JBT7940.1-M6	STRAIGHT FORCED FILLING OIL CUP		1	
11	DV01301000051	BEARING SEAT		1	
12	GBT13871-FB038052	LIP-TYPE SEAL RING OF ROTATING SHAFT		1	
13	DV01301000067	RUBBER SLEEVE		1	
14	DV01301000063	LEFT CONNECTING PLATE		1	
15	GBT1096-C8X7X32	FLAT KEY		1	
16	DV01301000162K	HORIZONTAL AUGER WELDMENT		1	
17	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	

RV01301020000 GRAIN CLIMB MACHINE ASSEMBLY-4



RV01301020000 GRAIN CLIMB MACHINE ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RV01301020000	GRAIN CLIMB MACHINE ASSEMBLY		1	
	DV01301020013	TRANSMISSION BOX ASSEMBLY		1	
1	DV01306000057	CONNECTING PLATE		1	
2	GBT13871-FB038052	LIP-TYPE SEAL RING OF ROTATING SHAFT		1	
3	GBT276-6305	DEEP GROOVE BALL BEARING		1	
4	GBT893.1-62	CIRCLIPS FOR HOLE		1	
5	DV01301000066	20 TEETH BEVEL GEAR		1	
6	DV01301020014	TRANSMISSION CASE		1	
6.1	DV01301000059	TRANSMISSION BOX		1	
6.2	DV01301000066	20 TEETH BEVEL GEAR		1	
6.3	DV01301000017	TRANSMISSION SHAFT		1	
6.4	GBT276-6205	DEEP GROOVE BALL BEARING		1	
6.5	GBT276-6205-RS	DEEP GROOVE BALL BEARING		1	
6.6	DV01301000016	BEARING SEAT		1	
6.7	GBT93-8-A3L	STANDARD SPRING WASHER		3	
6.8	GBT70.1-M8X20-8.8-A2L	INNER HEXAGON SCREW		3	
6.9	GBT1096-8X7X22	FLAT KEY		1	
7	JBT7940.1-M6	STRAIGHT FORCED FILLING OIL CUP		2	
8	DV01102000149	DUSTPROOF CAP OF OIL CUP		2	
9	GBT93-10-A3L	STANDARD SPRING WASHER		3	
10	GBT5783-M10X25-8.8-A3L	HEXAGON BOLT		3	

LOVOL
9ZR D22327

LOVOL
9ZR D22327




RV01302010000K ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF-1

No.	Part No.	Description	Version	QTY.	Remark
	RV01302010000K	ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF	007	1	
1	RV01302010001aK	MIXED REMNANT HOUSING BODY		1	
1.1	GBT819. 2-M6X16-8. 8-A2L	SCREW		9	
1.2	DV01302000032	LINER PLATE		1	
1.3	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		6	
1.4	GBT97. 1-8-A3L	FLAT WASHER		6	
1.5	GBT93-8-A3L	STANDARD SPRING WASHER		6	
1.6	BA150B2. 111. 7-02	WASHER 7X22X2		9	
1.7	GBT93-6-A3L	STANDARD SPRING WASHER		9	
1.8	GBT6170-M6-8-A2L	HEXAGON NUT, TYPE-1		9	
1.9	DV01302000089	SHUTTER COVER PLATE		1	
1.10	RV01302010002aK	VERTICAL HOUSE BODY WELDMENT		1	
1.11	DV01302010006	LINER PLATE 2		1	
2	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		17	
3	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		3	
4	GBT97. 1-8-A3L	FLAT WASHER		19	
5	GBT93-8-A3L	STANDARD SPRING WASHER		26	
6	DV01302000131K	VERTICAL AUGER WELDMENT		1	
6.1	GBT889. 1-M8-8-A2L	NUT		4	
6.2	GBT12-M8X16-8. 8-A2L	BOLT		4	
6.3	DG2001. 21-12	CONNECTING PLATE		2	
6.4	DV01302000132K	VERTICAL AUGER WELDMENT		1	
7	GBT5783-M8X16-8. 8-A2L	HEXAGON BOLT		7	

RV01302010000K ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
8	RV01302010012K	TOP COVER PLATE		1	
8.1	GBT5783-M8X30-8.8-A2L	HEXAGON BOLT		3	
8.2	RV01302010013K	TOP COVER PLATE		1	
9	GBT3882-UE205	BEARING		1	
10	RV01302010011K	BEARING SEAT		1	
11	RV01302010017K	END COVER		1	
12	GBT5783-M10X25-8.8-A3L	HEXAGON BOLT		4	
13	GBT1096-6X6X20	FLAT KEY		1	
14	DV01302000113	16-TOOTH CHAIN PULLEY		1	
15	GBT894.1-20	CIRCLIP FOR SHAFT		1	
16	RV01302010010K	GEARBOX ASSEMBLY		1	
17	GBT93-10-A3L	STANDARD SPRING WASHER		7	
18	JBT7940.1-M6	STRAIGHT FORCED FILLING OIL CUP		2	
19	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	

RV01302010000K ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF-2




RV01302010000K ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF-2

No.	Part No.	Description	Version	QTY.	Remark
	RV01302010000K	ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF		1	
1	GBT6171-M14X1.5-8-A3L	HEXAGON NUT, TYPE-1		1	
2	GBT93-14-A3L	STANDARD SPRING WASHER		1	
3	DV01301000173	WASHER		1	
4	DV01302000060	BELT PULLEY		1	
5	G15.2-14	ADJUSTING GASKET		1	
6	DV01301000055	BEARING COVER		1	
7	GBT276-6206-RS	DEEP GROOVE BALL BEARING		1	
8	DV01301000051	BEARING SEAT		1	
9	GBT5783-M6X16-8.8-A2L	HEXAGON BOLT		8	
10	GBT93-6-A3L	STANDARD SPRING WASHER		8	
11	GBT5783-M8X25-8.8-A2L	HEXAGON BOLT		4	
12	GBT93-8-A3L	STANDARD SPRING WASHER		26	
13	GBT97.1-8-A3L	FLAT WASHER		19	
14	JBT7940.1-M6	STRAIGHT FORCED FILLING OIL CUP		2	
15	GBT13871-FB038052	LIP-TYPE SEAL RING OF ROTATING SHAFT		2	
16	DV01301000067	RUBBER SLEEVE		2	
17	GBT1096-C8X7X40	FLAT KEY		1	
18	DV01302000125K	HORIZONTAL AUGER INSTALLATION		1	
19	GBT1096-C8X7X25	FLAT KEY		1	
20	GBT12-M8X45-8.8-A2L	BOLT		1	
21	DG2004.21-06	CHAIN WHEEL CASE COVER		1	
22	GBT96.1-8-A3L	BIG WASHER		1	

RV01302010000K ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	DV01301000108	TENSIONER		1	
24	GBT5783-M8X30-8.8-A2L	HEXAGON BOLT		3	
25	DV01302000019	COMBINATION COVER WELDMENT		1	
26	GBT97.1-10-A3L	FLAT WASHER		3	
27	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		3	
28	DV01302000076	RIGHT INSTALLATION SEAT		1	
29	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		17	
30	GBT276-6206-2RS	DEEP GROOVE BALL BEARING		1	
31	DV01302000077	WASHER 1		1	
32	DV01302000111	SPROCKET DOWN COVER		1	
33	RV01302010001	CHAIN		1	
34	DV01302000052	17-TOOTH CHAIN PULLEY		1	
35	G15.10.19-09	RETAINER RING		1	
36	DV01301000119	WASHER		1	
37	GBT97.1-6-A3L	FLAT WASHER		5	
38	DV01301000109	MIDDLE SPACER BUSH		1	

RV01302010000K ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF-3




RV01302010000K ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF-3

No.	Part No.	Description	Version	QTY.	Remark
1	DV01302000125K	HORIZONTAL AUGER INSTALLATION		1	
	RV01302010000K	ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF		1	
	BA150B2. 89. 7	BOLT M8X20		8	
2	DV01302000040	WELDED REFRESHING BOARD 1		2	
3	DV01302000042	WELDED REFRESHING BOARD 2		2	
4	HE2001. 17. 2a-06	BALANCING BLOCK		1	
5	DV01302000126K	HORIZONTAL AUGER WELDMENT		1	

LOVOL
9ZR D22327

RV01302010000K ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF-4



RV01302010000K ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF-4

No.	Part No.	Description	Version	QTY.	Remark
	RV01302010000K	ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF		1	
	RV01302010010K	GEARBOX ASSEMBLY		1	
1	GBT70. 1-M8X20-8. 8-A2L	INNER HEXAGON SCREW		3	
2	GBT93-8-A3L	STANDARD SPRING WASHER		9	
3	D20010. 17. 7a-09	END COVER		1	
4	GBT9877. 1-B25X40X7D	SEAL RING		2	
5	DG2004. 21. 5-01	ADJUSTING GASKET 1		1	
6	GBT297-30205	TAPERED ROLLER BEARING		3	
7	D1681. 17. 4-14	BEVEL GEAR		2	
8	DV01302000083	TANK BODY		1	
9	D1681. 17. 4-11	SCREW PLUG		2	
10	JBT982-8	COMBINED SEAL GASKET		2	
11	DG2002. 10. 1-18	AIR VENT		1	
12	Q673B12	STEEL STRIP ELASTIC HOOP		1	
13	DV01302000084	SCREW PLUG		1	
14	JBT982-12	COMBINED SEAL GASKET		1	
15	GBT894. 1-20	CIRCLIP FOR SHAFT		2	
16	D20010. 17. 7-06	ADJUSTING GASKET		1	
17	DV01302000099	BEARING SEAT		1	
18	GBT1096-6X6X16	FLAT KEY		2	
19	D20010. 17. 7-04	SHAFT		1	
20	D20010. 17. 7-02	ADJUSTING GASKET		1	
21	D20010. 17. 7-03	END COVER		1	


RV01302010000K ELEVATOR ASSEMBLY OF TAILINGS AND CHAFF-4 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
22	GBT5783-M8X30-8.8-A2L	HEXAGON BOLT		3	
23	D20010.17.7a-08	SPLINE SHAFT		1	
24	D1681.17.4-02	LONG SPACER BUSH		1	
25	GBT297-30204	TAPERED ROLLER BEARING		1	
26	D1681.17.4-13	ADJUSTING GASKET 3		1	
27	D20010.17.7a-07	BEARING COVER		1	
28	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		3	
29	GBT9877.1-FB25X40X7D	SEAL RING		1	

LOVOL
9ZR D22327

LOVOL
9ZR D22327


RGV1303030000K GRAIN TANK ASSEMBLY-1



RGV1303030000K GRAIN TANK ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV1303030000K	GRAIN TANK ASSEMBLY	004	1	
1	GBT5789-M8X16-8. 8-A2L	HEXAGON FLANGE NUT		17	
2	RGV1303030001K	RAIN TANK UNIT		1	
3	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		1	
4	GBT6170-M12-8-A3L	HEXAGON NUT, TYPE-1		2	
5	RGV1303030010K	UPPER COVER UNIT		1	
6	GBT12618-4X12	RIVET		8	
7	RV01303100055	LONG PREEURE PLATE		2	
8	RV01303100056	FRONT UP SIGHT WINDOW		1	
9	GBT5783-M12X40-8. 8-A3L	HEXAGON BOLT		2	
10	GBT96. 1-12-A3L	BIG WASHER		4	
11	DV01303060114	RIGHT SIGHT WINDOW		1	
12	DC2382. 42. 3	BOLT		3	
13	RV01303100040	SHIELD		1	
14	RGV3303040045	LOCKING MECHANISM ASSEMBLY		1	
15	DV01303060071	SHAFT SEAT		2	
16	DV01303060025	FORK WELDMENT		1	
17	DV01303060115	RETAINER RING		1	
18	RGV1303030019K	GRAIN CONVEYING PORT WELDMENT		1	
19	GBT93-12-A3L	STANDARD SPRING WASHER		2	

RGV1303030000K GRAIN TANK ASSEMBLY-2




RGV1303030000K GRAIN TANK ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV1303030000K	GRAIN TANK ASSEMBLY		1	
	RGV3303040045	LOCKING MECHANISM ASSEMBLY		1	
1	GBT5783-M10X25-8. 8-A3L	HEXAGON BOLT		8	
2	GBT93-10-A3L	STANDARD SPRING WASHER		8	
3	GBT96. 1-10-A3L	BIG WASHER		8	
4	RGV3303040046a	FIXING SEAT WELDMENT		1	
5	DV01303060107	PULL ROD		1	
6	GBT5783-M6X12-8. 8-A2L	HEXAGON BOLT		1	
7	GBT93-6-A3L	STANDARD SPRING WASHER		1	
8	GBT96. 1-6-A3L	BIG WASHER		1	
9	GBT97. 1-12-A3L	FLAT WASHER		2	
10	DG2007. 14A. 7-01a	HANDLE		1	
11	GBT97. 1-8-A3L	FLAT WASHER		1	
12	GBT91-2. 5X20-A3L	SPLIT PIN		2	
13	DG2007. 14A. 7. 1	LOCKING SEAT WELDMENT		1	
14	DG2007. 14A. 7-04	TENSION SPRING		1	

LOVOL
9ZR D22327

RGV1303030000K GRAIN TANK ASSEMBLY-3




RGV1303030000K GRAIN TANK ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RGV1303030000K	GRAIN TANK ASSEMBLY		1	
	RGV1303030001K	RAIN TANK UNIT		1	
1	RV02303000097	ADJUSTING PLATE		2	
2	DV01303060034	FLASHBOARD WELDMENT		2	
3	RV02303000091	SPLITTER PLATE		1	
4	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		2	
5	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		8	
6	RGV3303040080	BRACKET WELDING OF ALARM		1	
7	GBT5789-M8X16-8. 8-A2L	HEXAGON FLANGE NUT		10	
8	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		4	
9	GBT6172. 1-M8-04-A2L	HEXAGON THIN NUT		4	
10	RGV1303030002K	GRAIN TANK WELDMENT		1	
11	GBT5789-M6X12-8. 8-A2L	HEXAGON FLANGE NUT		8	
12	GBT96. 1-8-A3L	BIG WASHER		2	
13	DV01303060022	LONG PULL ROD		2	
14	RDL1303000063	COVER PLATE		1	

LOVOL
9ZR D22327

RGV1303030000K GRAIN TANK ASSEMBLY-4




RGV1303030000K GRAIN TANK ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
1	RGV1303030000K	GRAIN TANK ASSEMBLY		1	
	RGV1303030010K	UPPER COVER UNIT		1	
	RGV1303030011K	UPPER COVER		1	
	RV02303000122	UPPER COVER PLATE WELDMENT		1	
1.1	RGV1303030012K	UPPER COVER		1	
1.2	Q32208	NUT		2	
1.3	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		4	
2	DV01303060070	SPRING PIECE		2	
3					

LOVOL
9ZR D22327

LOVOL
9ZR D22327


RGV1305010000K UNLOADING BOTTOM AUGER ASSEMBLY-1



RGV1305010000K UNLOADING BOTTOM AUGER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV1305010000K	UNLOADING BOTTOM AUGER ASSEMBLY	001	1	
1	RV02305000001	UNLOADING AUGER		1	
2	RV01305030010	ECCENTRIC WHEEL		1	
3	GBT276-61908-2RZ	DEEP GROOVE BALL BEARING		1	
4	GBT894. 1-40	CIRCLIP FOR SHAFT		1	
5	RV01305050001	TRANSMISSION CASE		1	
6	GBT93-10-A3L	STANDARD SPRING WASHER		4	
7	GBT5783-M10X30-8. 8-A3L	HEXAGON BOLT		4	
8	DV01305060033	INPUT BELT PULLEY		1	
9	GBT1096-C6X6X36	FLAT KEY		1	
10	GBT96. 1-12-A3L	BIG WASHER		1	
11	GBT93-12-A3L	STANDARD SPRING WASHER		1	
12	GBT6170-M12-8-A3L	HEXAGON NUT, TYPE-1		1	

RGV1305010000K UNLOADING BOTTOM AUGER ASSEMBLY-2



RGV1305010000K UNLOADING BOTTOM AUGER ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RV01305050001	TRANSMISSION CASE		1	
	RGV1305010000K	UNLOADING BOTTOM AUGER ASSEMBLY		1	
1	GBT276-6006-2RS	DEEP GROOVE BALL BEARING		1	
2	GBT893.1-55	CIRCLIPS FOR HOLE		1	
3	DV01305060038	LIP-TYPE SEAL RING OF ROTATING SHAFT		1	
4	GBT893.1-68	CIRCLIPS FOR HOLE		1	
5	DV01305060040	ADJUSTING WASHER		1	
6	DV01305060039	ADJUSTING WASHER		1	
7	GBT276-6008	DEEP GROOVE BALL BEARING		1	
8	DV01305060024	BIG TAPER GEAR		1	
9	Q72126	PLUG PIECE		1	
10	DV01305060030	COVER		1	
11	GBT893.1-47	CIRCLIPS FOR HOLE		1	
12	GBT276-6204	DEEP GROOVE BALL BEARING		1	
13	DV01305060026	INPUT SHAFT		1	
14	DV01305060023	TANK BODY		1	
15	HE2001.25.5.1-01	BOX COVER		1	
16	GBT93-8-A3L	STANDARD SPRING WASHER		6	
17	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		6	
18	DV01305060025	PINION		1	
19	GBT276-6007	DEEP GROOVE BALL BEARING		1	
20	DV01306060113	ADJUSTING WASHER		1	
21	HE2001.25.5-03	ADJUSTING WASHER		1	

RGV1305010000K UNLOADING BOTTOM AUGER ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
22	GBT893. 1-62	CIRCLIPS FOR HOLE		1	
23	HE2001. 25. 5-07	LIP-TYPE SEAL RING OF ROTATING SHAFT		1	
24	GBT97. 1-8-A3L	FLAT WASHER		6	
25	DV01305060034	GUM COVER		1	

LOVOL
9ZR D22327

NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com

NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com


NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com

NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com

LOVOL

9ZR D22327

RGV1306030000K UNLOADING CANISTER ASSEMBLY-1




RGV1306030000K UNLOADING CANISTER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV1306030000K	UNLOADING CANISTER ASSEMBLY	001	1	
1	RGV1306020004K	UPPER BOX ASSEMBLY		1	
2	RV01306050055	VERTICAL AUGER WELDMENT		1	
3	RV01306050001	UNLOADING CANISTER WELDMENT		1	
4	GBT5783-M10X30-8.8-A3L	HEXAGON BOLT		13	
5	GBT93-10-A3L	STANDARD SPRING WASHER		58	
6	RGV1306020001K	UPPER BOX		1	
7	GBT5783-M10X25-8.8-A3L	HEXAGON BOLT		30	
8	GBT97.1-10-A3L	FLAT WASHER		24	
9	DV01303000096	WASHER		6	
10	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		2	
11	GBT5783-M8X16-8.8-A2L	HEXAGON BOLT		5	
12	GBT93-8-A3L	STANDARD SPRING WASHER		7	
13	RV01306050124	RETAINING CLIP		5	
14	RV01306050077	REAR BRACKET WELDMENT		1	
15	GBT96.1-10-A3L	BIG WASHER		26	
16	RV01306050209	BRACKET WELDMENT		1	
17	RV01306050215	FIXING SEAT		1	
18	GBT5782-M10X90-8.8-A3L	HEXAGON BOLT		2	
19	GBT5782-M10X110-8.8-A1L	HEXAGON BOLT		2	
20	RV01306050262	SUPPORT BEAM WELDMENT		1	
21	GBT5782-M10X75-8.8-A2L	HEXAGON BOLT		2	
22	RGV1306030008K	STAY BAR WELDMENT		1	

RGV1306030000K UNLOADING CANISTER ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	RGV1306030001K	REAR BEAM		1	
24	GBT5783-M6X16-8.8-A2L	HEXAGON BOLT		15	
25	GBT93-6-A3L	STANDARD SPRING WASHER		15	
26	GBT97.1-6-A3L	FLAT WASHER		6	
27	RV01306050090	BOTTOM PLATE WELDMENT		1	
28	RV01306050011	SHIELD		1	
29	RV01306050202	SIDE COVER BOARD		1	
30	RV01306050272	MOTOR PEDESTAL		1	
31	JBT7940.2-45dM6	JOINT FILL OIL CUP		1	
32	DV01102000149	DUSTPROOF CAP OF OIL CUP		2	
33	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		4	
34	GBT96.1-8-A3L	BIG WASHER		2	
35	GBT96.1-6-A3L	BIG WASHER		9	

RGV1306030000K UNLOADING CANISTER ASSEMBLY-2



RGV1306030000K UNLOADING CANISTER ASSEMBLY-2


No.	Part No.	Description	Version	QTY.	Remark
	RGV1306030000K	UNLOADING CANISTER ASSEMBLY		1	
1	GBT5783-M10X30-10.9-A3L	HEXAGON BOLT		6	
2	GBT93-10-A3L	STANDARD SPRING WASHER		58	
3	RV01306050223	LEADER UNIT		1	
4	GBT5783-M10X25-8.8-A3L	HEXAGON BOLT		30	
5	GBT96.1-10-A3L	BIG WASHER		26	
6	DV01102000149	DUSTPROOF CAP OF OIL CUP		2	
7	JBT7940.1-M6	STRAIGHT FORCED FILLING OIL CUP		1	
8	RGV3306010006	HOOP		1	
9	GBT97.1-10-A3L	FLAT WASHER		24	
10	RV01306050219	FIXED SEAT		1	
11	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		2	
12	GBT93-8-A3L	STANDARD SPRING WASHER		7	
13	GBT91-5X36-A3L	SPLIT PIN		1	
14	RV01306050048	SCREW BUSH		1	
15	RV01306050124	RETAINING CLIP		5	
16	GBT5783-M8X16-8.8-A2L	HEXAGON BOLT		5	
17	RV01306050212	ROCK ARM		1	
18	GBT882-B20X70-A3L	PIN SHAFT		1	
19	GBT6177.1-M10-10-A3L	HEXAGON FLANGE NUT		7	
20	RV01306050113	WASHER		1	
21	GBT91-5X50-A3L	SPLIT PIN		1	
22	GBT5783-M10X35-10.9-A3L	HEXAGON BOLT		7	

RGV1306030000K UNLOADING CANISTER ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	RV02306000067	HORIZONTAL UNLOADING CANISTER		1	
24	GBT6170-M10-10-A3L	HEXAGON NUT, TYPE-1		15	
25	GBT5783-M10X30-8.8-A3L	HEXAGON BOLT		13	
26	RGV1306030002K	UNLOADING CANISTER ASSEMBLY		1	
27	GBT6177.1-M8-8-A2L	HEXAGON FLANGE NUT		5	
28	RV01306050110	LAMPSHADE		1	
29	GBT5783-M6X16-8.8-A2L	HEXAGON BOLT		15	
30	GBT93-6-A3L	STANDARD SPRING WASHER		15	
31	GBT96.1-6-A3L	BIG WASHER		9	
32	RV01306050102	RETAINING CLIP		1	
33	RV01306050101	STRAW OUTLET COVER		1	
34	RV01306050103	LOCKING CLAMP-LONG		1	
35	RV01306050248	RETAINER RING		1	
36	RV01306050173	GEAR 12TEETH		1	
37	GBT97.1-20-A3L	FLAT WASHER		1	
38	GBT5783-M10X25-10.9-A3L	HEXAGON BOLT		1	
39	RV01306050264	UNLOADING CANISTER BRACKET		1	
40	GBT5789-M6X12-8.8-A2L	HEXAGON FLANGE NUT		6	
41	RV02306000069	SHIELD		1	
42	RV02306000062	SHIELD		1	

LOVOL
9ZR D22327

RGV1306030000K UNLOADING CANISTER ASSEMBLY-3



RGV1306030000K UNLOADING CANISTER ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RGV1306030000K	UNLOADING CANISTER ASSEMBLY		1	
	RGV1306020004K	UPPER BOX ASSEMBLY		1	
1	GBT5783-M10X30-8.8-A3L	HEXAGON BOLT		2	
2	GBT93-10-A3L	STANDARD SPRING WASHER		8	
3	GBT97.1-10-A3L	FLAT WASHER		5	
4	GBT5783-M10X16-8.8-A3L	HEXAGON BOLT		2	
5	GBT5783-M10X25-8.8-A3L	HEXAGON BOLT		2	
6	RV01306050027	THRUST BODY		1	
7	RGV1306020005K	LOWER BOX		1	
7.1	GBT5783-M8X16-8.8-A2L	HEXAGON BOLT		3	
7.2	GBT93-8-A3L	STANDARD SPRING WASHER		3	
7.3	GBT96.1-8-A3L	BIG WASHER		1	
7.4	RV01306050042	SIGHT WINDOW		1	
7.5	GBT97.1-8-A3L	FLAT WASHER		2	
7.6	RV01306050036	INSPECTION WINDOW		1	
7.7	DV01102000149	DUSTPROOF CAP OF OIL CUP		1	
7.8	JBT7940.1-M6	STRAIGHT FORCED FILLING OIL CUP		1	
7.9	RV01306050033	SEAL COVER		1	
7.10	RV01306050052	LOWER BOX BODY		1	
7.11	RV01306050022	15 TEETH BEVEL GEAR		2	
7.12	GBT276-6007-2RS	DEEP GROOVE BALL BEARING		2	
7.13	RV01306050031	WASHER		1	

RGV1306030000K UNLOADING CANISTER ASSEMBLY-3 (cont'd.)


No.	Part No.	Description	Version	QTY.	Remark
7.14	GBT893.1-62	CIRCLIPS FOR HOLE		2	
7.15	RV01306050032	WASHER		1	

NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com

NanJing TianYu Machinery Co., Ltd. www.njtymachinery.com

LOVOL
9ZR D22327

RGV1306030000K UNLOADING CANISTER ASSEMBLY-4



RGV1306030000K UNLOADING CANISTER ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RGV1306030000K	UNLOADING CANISTER ASSEMBLY		1	
	RGV1306020001K	UPPER BOX		1	
1	RGV1306020003K	LEVEL BOX BODY		1	
1.1	GBT5783-M8X16-8.8-A2L	HEXAGON BOLT		2	
1.2	GBT93-8-A0P	STANDARD SPRING WASHER		2	
1.3	GBT96.1-8-A0P	BIG WASHER		2	
1.4	RV01306050042	SIGHT WINDOW		2	
1.5	RV01306050054	LEVEL BOX BODY		1	
1.6	RV01306050033	SEAL COVER		1	
1.7	RV01306050022	15 TEETH BEVEL GEAR		2	
1.8	GBT276-6007-2RS	DEEP GROOVE BALL BEARING		2	
1.9	RV01306050032	WASHER		1	
1.10	GBT893.1-62	CIRCLIPS FOR HOLE		2	
1.11	RV01306050031	WASHER		1	
2	RV01306050170	O-SEAL RING 210		1	
3	RV01306050062	AUGER		1	
4	RGV1306020002K	UPPER BOX		1	
4.1	GBT5783-M8X16-8.8-A2L	HEXAGON BOLT		1	
4.2	GBT93-8-A3L	STANDARD SPRING WASHER		1	
4.3	GBT96.1-8-A3L	BIG WASHER		1	
4.4	RV01306050042	SIGHT WINDOW		1	
4.5	GBT12613.1-P28X25X30	SLEEVE		1	
4.6	RV01306050033	SEAL COVER		1	

RGV1306030000K UNLOADING CANISTER ASSEMBLY-4 (cont'd.)


No.	Part No.	Description	Version	QTY.	Remark
4. 7	DV01102000149	DUSTPROOF CAP OF OIL CUP		2	
4. 8	JBT7940. 1-M6	STRAIGHT FORCED FILLING OIL CUP		2	
4. 9	RV01306050051	UPPER BOX		1	
4. 10	RV01306050022	15 TEETH BEVEL GEAR		2	
4. 11	GBT276-6007-2RS	DEEP GROOVE BALL BEARING		2	
4. 12	RV01306050032	WASHER		1	
4. 13	GBT893. 1-62	CIRCLIPS FOR HOLE		2	
4. 14	RV01306050031	WASHER		1	
5	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		2	
6	GBT93-8-A3L	STANDARD SPRING WASHER		6	
7	RV01306050111	PRESSING PLATE		1	
8	GBT5783-M8X35-8. 8-A2L	HEXAGON BOLT		2	
9	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		2	
10	GBT5783-M8X30-8. 8-A2L	HEXAGON BOLT		4	
11	RV01306050116	CONNECTING PLATE		4	
12	GBT5782-M10X70-8. 8-A3L	HEXAGON BOLT		1	
13	RV01306050114	RETAINER BODY		2	
14	RV01306050197	CONNECTING PLANK		1	
15	RV01306050100	CONNECTING PLATE		1	
16	RV01306050118	PAD BOARD (1)		1	
17	RV01306050119	PAD BOARD		2	
18	RV01306050120	PAD BOARD		2	

RGV1306030000K UNLOADING CANISTER ASSEMBLY-4 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
19	RV01306050117	RETAINER BODY		1	
20	GBT93-10-A3L	STANDARD SPRING WASHER		3	
21	GBT5782-M10X85-8.8-A2L	HEXAGON BOLT		2	

LOVOL
9ZR D22327

RGV1306030000K UNLOADING CANISTER ASSEMBLY-5



RGV1306030000K UNLOADING CANISTER ASSEMBLY-5


No.	Part No.	Description	Version	QTY.	Remark
	RGV1306030000K	UNLOADING CANISTER ASSEMBLY		1	
1	RV02306000067	HORIZONTAL UNLOADING BARREL BACK-END		1	
1.1	RV02306000068	HORIZONTAL UNLOADING BARREL BACK-END		1	
1.2	RV01306050239	HORIZONTAL AUGER WELDMENT		1	
1.3	GBT276-6304-2RS	DEEP GROOVE BALL BEARING		1	
1.4	GBT893.1-52	CIRCLIPS FOR HOLE		1	
2	RV01306050264	UNLOADING CANISTER BRACKET		1	
2.1	RV01306050265	SUPPORT SEAT WELDMENT		1	
2.2	GBT97.1-10-A3L	FLAT WASHER		4	
2.3	GBT93-10-A3L	STANDARD SPRING WASHER		4	
2.4	GBT5783-M10X25-8.8-A3L	HEXAGON BOLT		4	
2.5	Q50108	LOCK PIN		1	
2.6	GBT96.1-8-A3L	BIG WASHER		2	
2.7	GBT882-B8X45-A3L	PIN SHAFT		1	
2.8	RV01306050278	BRACKET WELDMENT		1	
2.8.1	RV01306050281	ARC PLATE WELDMENT		1	
2.8.2	RV01306050279	BRACKET WELDMENT		1	
2.8.3	GBT93-10-A3L	STANDARD SPRING WASHER		2	
2.8.4	GBT70.1-M8X20-8.8-A2L	INNER HEXAGON SCREW		2	
3	RGV1306030002K	UNLOADING CANISTER ASSEMBLY		1	
3.1	RGV1306030003K	UNLOADING CYLINDER WELDMENT		1	
3.2	RV01306050104	HORIZONTAL STIRRED DRAGON BACK-END		1	
3.3	RV01306050127	BEARING SEAT		1	

RGV1306030000K UNLOADING CANISTER ASSEMBLY-5 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
3.4	GBT276-6004-2RS	DEEP GROOVE BALL BEARING		1	
3.5	GBT893.1-42	CIRCLIPS FOR HOLE		1	
3.6	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		2	
3.7	GBT93-8-A3L	STANDARD SPRING WASHER		2	
3.8	GBT97.1-8-A3L	FLAT WASHER		2	

LOVOL
9ZR D22327

DG2001. 31A REARVIEW MIRROR ASSEMBLY




DG2001. 31A REARVIEW MIRROR ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	DG2001. 31A	REARVIEW MIRROR ASSEMBLY		1	
1	DG2001. 31. 2	LEFT REAR MIRROR ASSEMBLY		1	
1. 1	DG2001. 31. 2. 1	BRACKET WELDMENT OF LEFT REARVIEW MIRROR		1	
1. 2	DG2001. 31. 2. 2	LEFT BRACKET WELDMENT		1	
1. 3	GBT96. 1-8-A0P	BIG WASHER		1	
1. 4	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		1	
2	GBT97. 1-8-A0P	FLAT WASHER		2	
3	GBT93-8	STANDARD SPRING WASHER		2	
4	GBT5783-M8X25-8. 8-A2L	HEXAGON BOLT		2	
5	DG2001. 31A. 1	RIGHT REAR MIRROR ASSEMBLY		1	
5. 1	DG2001. 31. 1-01	REARVIEW MIRROR		1	
5. 2	DG2001. 31A. 1-01	RIGHT REAR VIEW MIRROR BRACKET		1	
6	GBT97. 1-6-A0P	FLAT WASHER		4	
7	GBT93-6	STANDARD SPRING WASHER		4	
8	GBT818-M6X16-4. 8-A2L	HEXAGON BOLT		4	

LOVOL
9ZR D22327


RGV1401080000K WHEEL SYSTEM ASSEMBLY-1



RGV1401080000K WHEEL SYSTEM ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV1401080000K	WHEEL SYSTEM ASSEMBLY	006	1	
1	D1681. 26-05	LOCK PIN		2	
2	DG2003K. 26-03	LOCKING PLATE		2	
3	DG2003K. 26-01	IDLING ROD		2	
4	DV01401020001	PUSHING BLOCK		2	
5	RGV1401050003K	RIGHT TENSIONER COMBINATION		1	
6	RGV3401000003a	SUPPORTING WHEEL INSTALLATION		2	
7	GBT5785-M14X1. 5X60-8. 8-A3L	HEX HEAD BOLTS		8	
8	GBT93-14-A3L	STANDARD SPRING WASHER		16	
9	GBT97. 1-14-A3L	FLAT WASHERS		16	
10	RGV1401050004K	BEARING WHEEL INSTALLATION		10	
11	RGV3401000032	REAR GUIDE		2	
12	RGV3401000031	FRONT GUIDE		2	
13	RGV1401080001K	RUBBER PEDRAIL		2	
14	RGV1401050002K	TENSIONER COMBINATION		1	
15	RGV3401000015	BALANCING WHEEL ASSEMBLY		2	
16	GBT5785-M14X1. 5X80-8. 8-A3L	HEX HEAD BOLTS WITH FINE TEETH		8	
17	GBT93-12-A3L	STANDARD SPRING WASHER		12	
18	GBT5786-M12X1. 5X25-8. 8-A3L	HEX HEAD BOLTS		12	
19	GBT93-10-A3L	STANDARD SPRING WASHER		2	
20	GBT5786-M10X1. 25X25-8. 8-A2L	HEX HEAD BOLTS		2	

RGV1401080000K WHEEL SYSTEM ASSEMBLY-2




RGV1401080000K WHEEL SYSTEM ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV1401080000K	WHEEL SYSTEM ASSEMBLY		1	
	RGV1401050004K	BEARING WHEEL INSTALLATION		10	
1	GBT5783-M6X16-8. 8-A2L	HEX HEAD BOLTS		3	
2	GBT93-6-A3L	STANDARD SPRING WASHER		3	
3	RV01401090004	END COVER		1	
4	GBT3452. 1-71. 0X2. 65G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
5	DG2003K. 26. 1-10	ADJUSTMENT MATS		1	
6	GBT65-M6X8-4. 8-A2L	SLOTTED COLUMN HEAD SCREW		1	
7	DG2003K. 26. 1-01	RETAINING RING		2	
8	GBT276-6306	DEEP GROOVE BALL BEARING		2	
9	RV01401130005	ROLLERS		1	
10	DG2003K. 26. 1-11	SPACER		1	
11	DV01401060010	OIL SEAL		1	
11. 1	DV01401060004	OIL SEAL		1	
11. 2	DV01401060011	OIL SEAL SEAT		1	
12	RV01401130006	BEARING WHEEL SHAFT		1	
13	GBT93-12-A3L	STANDARD SPRING WASHER		1	
14	GBT5786-M12X1. 5X25-8. 8-A3L	HEX HEAD BOLTS		1	

LOVOL
9ZR D22327

RGV1401080000K WHEEL SYSTEM ASSEMBLY-3




RGV1401080000K WHEEL SYSTEM ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RGV1401080000K	WHEEL SYSTEM ASSEMBLY		1	
	RGV3401000003a	SUPPORTING WHEEL INSTALLATION		2	
1	GBT5783-M6X16-8. 8-A2L	HEX HEAD BOLTS		3	
2	GBT93-6-A3L	STANDARD SPRING WASHER		3	
3	RGV3401000006	END COVER		1	
4	GBT3452. 1-61. 5X2. 65G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
5	GBT65-M6X8-4. 8-A2L	SLOTTED COLUMN HEAD SCREW		1	
6	GBT93-10-A3L	STANDARD SPRING WASHER		1	
7	DG2003K. 26. 3-01	RETAINING RING		2	
8	RGV3401000007	BEARING		2	
9	RGV3401000005	SPACER		1	
10	RGV3401000004a	CHAINWHEEL		1	
11	RGV3401000014	OIL SEAL		1	
12	GBT5786-M10X1. 25X25-8. 8-A2L	HEX HEAD BOLTS		1	
13	RV01401130009	SUPPORTING WHEEL SHAFT		1	
14	RGV3401000010	RETAINING RING		1	

LOVOL
9ZR D22327

RGV1401080000K WHEEL SYSTEM ASSEMBLY-4




RGV1401080000K WHEEL SYSTEM ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RGV1401080000K	WHEEL SYSTEM ASSEMBLY		1	
	RGV3401000015	BALANCING WHEEL ASSEMBLY		2	
1	GBT5783-M6X16-8. 8-A2L	HEX HEAD BOLTS		3	
2	GBT93-6-A3L	STANDARD SPRING WASHER		3	
3	RGV3401000006	END COVER		1	
4	GBT3452. 1-61. 5X2. 65G	O-RING RUBBER SEAL FOR HYDRAULIC AND PNEUMATIC		1	
5	GBT5786-M12X1. 5X25-8. 8-A3L	HEX HEAD BOLTS		1	
6	GBT65-M6X8-4. 8-A2L	SLOTTED COLUMN HEAD SCREW		1	
7	DG2003K. 26. 1-01	RETAINING RING		2	
8	RGV3401000018	BEARING		2	
9	RGV3401000016	BALANCING WHEEL		1	
10	RGV3401000017	SPACER		1	
11	RGV3401000019	OIL SEAL		1	
12	RV01401130006	BEARING WHEEL SHAFT		1	
13	GBT93-12-A3L	STANDARD SPRING WASHER		1	

LOVOL
9ZR D22327

RGV1401080000K WHEEL SYSTEM ASSEMBLY-5




RGV1401080000K WHEEL SYSTEM ASSEMBLY-5

No.	Part No.	Description	Version	QTY.	Remark
	RGV1401080000K	WHEEL SYSTEM ASSEMBLY		1	
	RGV1401050003K	RIGHT TENSIONER COMBINATION		1	
	RGV1401050002K	TENSIONER COMBINATION		1	
1	RGV1402050004K	TENSIONER		1	
1.1	GBT802-M20-6	COMBINED COVER NUT		2	
1.2	GBT93-20-A3L	STANDARD SPRING WASHER		2	
1.3	DV01401000048	RETAINING RING		2	
1.4	DV01401060010	OIL SEAL		2	
1.5	GBT67-M6X10-4.8-A2L	SLOTTED PAN HEAD SCREW		1	
1.6	GBT276-6306	DEEP GROOVE BALL BEARING		2	
1.7	DV01401000051a	TENSIONER SHAFT		1	
1.8	RV03401000039a	GUIDE WHEEL		1	
2	RV03401000041b	PUSH ROD B		1	
3	RV03401000040b	PUSH ROD A		1	

LOVOL
9ZR D22327

RGV1403160000K CHASSIS FRAME ASSEMBLY



RGV1403160000K CHASSIS FRAME ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV1403160000K	CHASSIS FRAME ASSEMBLY	001	1	
1	DV01403160087	FIXED PLATE		1	
2	GBT93-10-A3L	STANDARD SPRING WASHER		8	
3	GBT5783-M12X25-8.8-A3L	HEXAGON BOLT		1	
4	RGV1403130015K	COVER PLATE		1	
5	GBT6170-M10-10-A3L	HEXAGON NUT, TYPE-1		8	
6	GBT5783-M6X16-8.8-A2L	HEXAGON BOLT		10	
7	GBT93-6-A3L	STANDARD SPRING WASHER		10	
8	GBT97.1-6-A3L	FLAT WASHER		10	
9	DV01403160144	MUD GUARD ASSEMBLY		1	
10	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		10	
11	GBT93-8-A3L	STANDARD SPRING WASHER		10	
12	GBT97.1-8-A3L	FLAT WASHER		2	
13	RGV1403130014K	SUPPORT PLATE		1	
14	RGV1403130001K	CHASSIS WELDMENT		1	
15	GBT96.1-8-A3L	BIG WASHER		8	
16	RGV1403080009K	FOOT PEDAL		1	
17	RV01403030022K	LADDER		1	
17.1	RV01403030023K	LADDER WELDMENT -UPPER		1	
17.2	RV01403030027K	LADDER WELDMENT -LOWER		1	
17.3	DG2007.27.1.2-01	BUSH		2	
17.4	GBT5789-M8X20-10.9-A2L	HEXAGON FLANGE NUT		2	
17.5	GBT97.1-10-A3L	FLAT WASHER		2	


RGV1403160000K CHASSIS FRAME ASSEMBLY (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
18	JBT1700-M12X1.25	HEXAGON SCREW PLUG		1	
19	JBT982-12	COMBINED SEAL GASKET		1	
20	DG2004.27-04	GADGET1		2	
21	DG2007.27-06	CONNECTING PLATE		1	
22	GBT5783-M12X30-8.8-A3L	HEXAGON BOLT		8	
23	GBT93-12-A3L	STANDARD SPRING WASHER		9	
24	HE2001.27-02	UPPER COVER OF DRIVING AXLE SUPPORT SEAT		2	
25	DG2007.27.4	BONNET SUPPORT ROD WELDMENT		3	
26	DG2002.27A.2a	BONNET SUPPORT ROD WELDMENT		1	
27	DG2002.27-10	PIN SHAFT		1	
28	GBT97.1-20-A3L	FLAT WASHER		3	
29	GBT91-5X50-A3L	SPLIT PIN		1	
30	GBT6170-M12-8-A3L	HEXAGON NUT, TYPE-1		1	
31	RV01403130021	SEAL STRIP		2	
32	RV01403130037	SEAL STRIP		1	
33	DV01403160141	CONNECTINGSEAT		1	
34	RV01403130026	ORIENTATION PIN		1	
35	GBT91-1.6X25-A3L	SPLIT PIN		1	
36	GBT5789-M6X16-8.8-A2L	HEXAGON FLANGE NUT		5	
37	RGV1403080003K	FOOT PEDAL		1	
38	GBT5789-M8X20-8.8-A2L	HEXAGON FLANGE NUT		4	
39	GBT6177.1-M8-8-A2L	HEXAGON FLANGE NUT		4	

LOVOL
9ZR D22327

RGV1405020000K STEERING LIFTING CONTROL UNIT

LOVOL
9ZR D22327




RGV1405020000K STEERING LIFTING CONTROL UNIT

No.	Part No.	Description	Version	QTY.	Remark
	RGV1405020000K	STEERING LIFTING CONTROL UNIT		1	
1	RV01405010001	转向手柄球		1	
2	DG2001.33-03	FLEX RUBBER		1	
3	DG2009.33.1b	STEERING HANDLE WELDMENT		1	
4	DG2009.33-01a	PULL ROD		1	
5	GBT91-3.2X25-A3L	SPLIT PIN		1	
6	GBT97.1-14-A3L	FLAT WASHER		1	
7	HE2001.33-02a	CONNECTING PLATE		1	
8	GBT882-B6X28-A3L	PIN SHAFT		3	
9	D168B.5.8.14	FORK HEAD WELDMENT		3	
10	GBT97.1-6-A3L	FLAT WASHER		3	
11	GBT91-2X16-A3L	SPLIT PIN		8	
12	GBT882-B5X22-A3L	PIN SHAFT		4	
13	DG2009.33-03	PULL ROD		2	
14	GBT97.1-5-A3L	FLAT WASHER		5	
15	DG2001.33-02	SEAL SLEEVE		4	
16	GBT16674.1-M8X20-8.8-A2L	HEXAGON FLANGE NUT		2	
17	DG2001.33.5	SUPPORT PLATE		1	
18	GBT6177.1-M8-8-A2L	HEXAGON FLANGE NUT		2	
19	GBT882-B5X28-A3L	PIN SHAFT		1	
20	RGV3405010001	HANDLE WELDMENT		1	
21	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		1	
22	RV03405000047	HANDLEBALL		1	

RGV1405020000K STEERING LIFTING CONTROL UNIT (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	RGV3405010003	ROTARY SHAFT WELDMENT		1	
24	DG2009.33.5a	HANDLE WELDMENT II		1	
25	DG2009.33.2	STEERING PUSHING ROD UNIT		1	
25.1	DG2001.35.2-01a	LEFT-HAND SELF-LUBRICATION BALL CONNECTOR		1	
25.2	GBT6171-M10X1.25-LH-8-A2L	HEXAGON NUT, TYPE-1		1	
25.3	DG2009.33.2-01a	PULL ROD		1	
25.4	GBT6171-M10X1.25-8-A2L	HEXAGON NUT, TYPE-1		1	
25.5	D1681.35.2-01a	SELF LUBRICATING BALL JOINT		1	

RGV340600000 SPEED CHANGING CONTROL ASSEMBLY




RGV3406000000 SPEED CHANGING CONTROL ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3406000000	VARIABLE SPEED STEERING ASSEMBLY	001	1	
1	GBT91-3. 2X25-A3L	COTTER PIN		1	
2	GBT97. 1-10-A3L	FLAT WASHERS		1	
3	RV01406000016	CONNECTING JOINT WELDMENT		1	
4	GBT882-B10X26-A3L	PIN		1	
5	RGV3406000003	PULL ROD UNIT		1	
5.1	GBT6171-M10X1. 25-LH-8-A2L	TYPE 1 HEX NUT		2	
5.2	RGV3406000005	LONG PULL ROD		1	
5.3	RGV3406000006	ADJUSTING NUT		1	
5.4	GBT6171-M10X1. 25-8-A2L	TYPE 1 HEX NUT		2	
5.5	RGV3406000004	TIE ROD		1	
5.6	D1681. 35. 2-01a	SELF LUBRICATING BALL JOINT		1	
6	RGV3406000001	SPEED CHANGING CONTROL HANDLE WELDMENT		1	
7	GBT6170-M12-8-A3L	TYPE 1 HEX NUT		1	
8	RV01406000019	HANDLEBALL		1	

DV0141000000 HANDLE THROTTLE ASSEMBLY

LOVOL
9ZR D22327




DV0141000000 HANDLE THROTTLE ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	DV0141000000	HANDLE THROTTLE ASSEMBLY		1	
1	GBT6172. 1-M14-04-A3L	HEXAGON THIN NUT		2	
2	GBT97. 1-14-A0P	FLAT WASHER		3	
3	DV0141000001	SPRING		2	
4	DG2001. 34-01	HANDLESLEEVE		1	
5	DV0141000005	HANDLE WELDMENT		1	
6	GBT91-3. 2X14-A0P	SPLIT PIN		1	
7	GBT97. 1-8-A0P	FLAT WASHER		1	
8	DV0141000002	LIMITING ROD		1	
9	GBT882-B6X16-A0P	PIN SHAFT		1	
10	GBT97. 1-6-A0P	FLAT WASHER		1	
11	GBT91-2X12-A0P	SPLIT PIN		1	
12	DV0141000009	FOOT THROTTLE WIRE ASSEMBLY		1	

DV01411000000 FLAMEOUT MECHANISM

LOVOL
9Zr D22327




DV01411000000 FLAMEOUT MECHANISM

No.	Part No.	Description	Version	QTY.	Remark
	DV01411000000	FLAMEOUT MECHANISM		1	
1	GBT5783-M6X12-8.8	HEX HEAD BOLTS		3	
2	DV01411000002	FIXING PLATE 1		2	
3	DV01411000003	FIXING PLATE 2		1	
4	GBT93-6-A0P	STANDARD SPRING WASHER		3	
5	GBT6170-M6-8-A2L	TYPE 1 HEX NUT		2	
6	GBT5783-M10X20-8.8	HEX HEAD BOLTS		1	
7	GBT93-10-A0P	STANDARD SPRING WASHER		1	
8	DV01411000004	FIXING PLATE 3		1	
9	DV01411000001	FLAMEOUT MECHANISM WIRE ASSEMBLY		1	

LOVOL
9ZR D22327

RV01412010000 CLUTCH CONTROL ASSEMBLY-1



RV01412010000 CLUTCH CONTROL ASSEMBLY-1


No.	Part No.	Description	Version	QTY.	Remark
	RV01412010000	CLUTCH CONTROL ASSEMBLY	003	1	
1	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		7	
2	GBT93-8-A3L	STANDARD SPRING WASHER		8	
3	DG2004. 37-01	HANDLE SLEEVE		1	
4	DV01412000001	THRESHING CLUTCH WELDMENT		1	
5	GBT97. 1-10-A3L	FLAT WASHER		2	
6	GBT91-3. 2X20-A3L	SPLIT PIN		2	
7	DV01412000006	SPRING		1	
8	DV01412000007	PULL ROD		1	
9	GBT6170-M10-10-A3L	HEXAGON NUT, TYPE-1		2	
10	DG2004. 37. 2b	WELDED FRAME		1	
11	RV01412010002	MAIN TENSION PULLEY ASSEMBLY		1	

RV01412010000 CLUTCH CONTROL ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RV01412010002	MAIN TENSION PULLEY ASSEMBLY		1	
	RV01412010000	CLUTCH CONTROL ASSEMBLY		1	
1	DG2002. 37. 3-06	LONG SHAFT SLEEVE		1	
2	GBT893. 1-52	CIRCLIPS FOR HOLE		2	
3	GBT276-6205-RS	DEEP GROOVE BALL BEARING		2	
4	DG2002. 37. 3-07	SPACER BUSH 3		1	
5	DG2004. 37. 3a-01	TENSIONER		1	
6	DG2002. 37. 3-05	SPACER BUSH 2		1	
7	DG2004. 37. 3a-02	SUPPORTINGSHAFT		1	
8	GBT93-12-A3L	STANDARD SPRING WASHER		2	
9	GBT6170-M12-8-A3L	HEXAGON NUT, TYPE-1		2	
10	DG2004. 37. 3a. 1	WELDED FRAME		1	
11	DG2004. 37. 3a-03	SUPPORTINGSHAFT		1	
12	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		5	
13	GBT93-10-A3L	STANDARD SPRING WASHER		4	
14	RV01412020011	AXLE SEAT UNIT		2	
14. 1	DG2002. 37. 3-01	SHAFT SEAT		1	
14. 2	HE2001. 37. 3-03	SHAFT SLEEVE		1	
15	GBT97. 1-10-A3L	FLAT WASHER		4	
16	DG2002. 37. 3-09	LIMIT ROD		1	
17	HE2001. 37. 3-04	SPACER BUSH 1		1	
18	GBT5783-M10X35-8. 8-A3L	HEXAGON BOLT		3	

LOVOL
9ZR D22327

RV01413020000 UNLOADING CLUTCH CONTROL-1




RV01413020000 UNLOADING CLUTCH CONTROL-1

No.	Part No.	Description	Version	QTY.	Remark
	RV01413020000	UNLOADING CLUTCH CONTROL ASSY		1	
1	GBT882-B14X60-A3L	PIN SHAFT		1	
2	GBT5783-M6X16-8.8-A2L	HEXAGON BOLT		3	
3	GBT93-6-A3L	STANDARD SPRING WASHER		3	
4	GBT96.1-6-A3L	BIG WASHER		3	
5	DG2007.41A.3	UNLOADING SUPPORT PLATE WELDMENT-1		1	
6	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		3	
7	GBT93-8-A3L	STANDARD SPRING WASHER		3	
8	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		3	
9	DG2007.41A.4	UNLOADING SUPPORT PLATE WELDMENT-2		1	
10	GBT97.1-14-A3L	FLAT WASHER		1	
11	GBT91-3.2X32-A3L	SPLIT PIN		2	
12	DG2001.34-01	HANDLESLEEVE		1	
13	DG2007.41A.1	HANDLE WELDMENT		1	
14	GBT882-B8X22-A3L	PIN SHAFT		1	
15	GBT97.1-8-A3L	FLAT WASHER		1	
16	DV01413020011	WIRE RPOE OF UNLOADING		1	
16.1	D20012.36.3-03	CONNECTING FORK - I		1	
16.2	D20012.36.3-09	SLEEVE TUBE		1	
16.3	GBT6172.1-M10-04-A3L	HEXAGON THIN NUT		4	
16.4	GBT97.1-10-A0P	FLAT WASHER		1	
16.5	GBT96.1-10-A0P	BIG WASHER		1	

RV01413020000 UNLOADING CLUTCH CONTROL-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
16.6	DG2007.41A.2-01	FLEXIBLE CABLE SLEEVE		1	
16.7	D20012.36.3-08	RUBBER SLEEVE		1	

RV01413020000 UNLOADING CLUTCH CONTROL-2



RV01413020000 UNLOADING CLUTCH CONTROL-2

No.	Part No.	Description	Version	QTY.	Remark
	RV01413020000	UNLOADING CLUTCH CONTROL ASSY		1	
1	DG2004. 23-02	BELT SEAT		1	
2	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		2	
3	GBT97. 1-10-A3L	FLAT WASHER		6	
4	DV01413020012	CLUTCH SPRING		1	
5	DV01504000039	PULLEY BRACKET WEDMENT		1	
6	GBT97. 1-8-A3L	FLAT WASHER		2	
7	GBT93-8-A3L	STANDARD SPRING WASHER		2	
8	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		2	
9	DG2007. 23. 2. 2	TENSIONER COMBINATION		1	
9. 1	GBT893. 1-52	CIRCLIPS FOR HOLE		2	
9. 2	GBT276-6205-2RS	DEEP GROOVE BALL BEARING		1	
9. 3	DG2007. 23. 2. 2-01	TENSIONER		1	
10	GBT894. 1-25	CIRCLIP FOR SHAFT		1	
11	RV01413020002	BRACKET WELDMENT		1	
12	GBT91-3. 2X32-A3L	SPLIT PIN		1	
13	DV01413020014	SHORT SHAFT 2		1	
14	D1682. 37. 3-03	RETAINER RING		1	
15	GBT894. 1-20	CIRCLIP FOR SHAFT		1	
16	DV01413020001	UNLOADING SEAT		1	
17	GBT5783-M10X25-8. 8-A3L	HEXAGON BOLT		4	
18	GBT93-10-A3L	STANDARD SPRING WASHER		4	
19	GBT97. 1-16-A3L	FLAT WASHER		1	


RV01413020000 UNLOADING CLUTCH CONTROL-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
20	GBT93-16-A3L	STANDARD SPRING WASHER		1	
21	GBT6170-M16-8-A3L	HEXAGON NUT, TYPE-1		1	
22	DG2007.41A-01	PULLING PLATE		1	
23	DV01413020010	BELT SEAT		1	
24	RV01413020001	V-BELT SC75		1	

LOVOL
9ZR D22327

DV01414020000 MAIN TRANSMISSION ASSEMBLY

LOVOL
9ZR D22327



DV01414020000 MAIN TRANSMISSION ASSEMBLY


No.	Part No.	Description	Version	QTY.	Remark
	DV01414020000	MAIN TRANSMISSION ASSEMBLY	003	1	
1	GBT6171-M16X1.5-8-A3L	HEXAGON NUT, TYPE-1		1	
2	DG2002.29-04b	AXLE GASKET		1	
3	DV01414020001	BELT PULLEY		1	
4	GBT5783-M12X50-8.8-A3L	HEXAGON BOLT		8	
5	GBT93-12-A3L	STANDARD SPRING WASHER		8	
6	GBT7810-UELFC208	EXTERNAL SPHERICAL BALL BEARING WITH BEARING BLOCK		1	
7	GBT1096-C10X8X56	FLAT KEY		1	
8	DG2002.29-02d	MIDDLE SHAFT		1	
9	GBT1096-10X8X70	FLAT KEY		1	
10	DV01414000001	PLASTIC FASTENING STRIP		4	
11	DG2002.29.3	PIPE		1	
12	DG2002.29.2	BEARING UELFC208		1	
13	GBT5783-M10X60-8.8-A3L	HEXAGON BOLT		1	
14	GBT93-10-A3L	STANDARD SPRING WASHER		1	
15	GBT6170-M10-10-A3L	HEXAGON NUT, TYPE-1		1	
16	GBT93-16-A3L	STANDARD SPRING WASHER		2	
17	GBT6173-M16X1.5-05-A3L	HEXAGON THIN NUT		1	
18	DV01414000010	BRACKET		1	
19	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		3	
20	GBT93-8-A3L	STANDARD SPRING WASHER		3	
21	GBT97.1-8-A3L	FLAT WASHER		5	

DV01414020000 MAIN TRANSMISSION ASEMBLY (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
22	DV01414010001	PIPE CLAMP		1	
23	DV01414000013	BRACKET		1	
24	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		3	
25	DV01414000021	BELT PULLEY		1	

RV01416000000K HEADER CLUTCH CONTROL ASSEMBLY

LOVOL
9ZR D22327




RV01416000000K HEADER CLUTCH CONTROL ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RV01416000000K	HEADER CLUTCH CONTROL ASSEMBLY		1	
1	DG2004. 37-01	HANDLE SLEEVE		1	
2	GBT91-3. 2X25-A3L	SPLIT PIN		1	
3	GBT97. 1-10-A3L	FLAT WASHER		1	
4	DV01416000010	COMBINE CLUTCH HANDLE		1	
5	DV01416000001	CLUTCH SUPPORT SHAFT		1	
6	GBT91-3. 2X18-A3L	SPLIT PIN		1	
7	GBT97. 1-8-A3L	FLAT WASHER		1	
8	DV01416000008	COMBINE STEEL WIRE ASSEMBLY		1	
8.1	D20012. 36. 3-09	SLEEVE TUBE		2	
8.2	GBT6172. 1-M10-04-A3L	HEXAGON THIN NUT		4	
8.3	DV01416000009	FLEXIBLE CABLE SLEEVE		1	
8.4	D20012. 36. 3-08	RUBBER SLEEVE		2	
9	Q67405200	PLASTIC FASTENING STRIP		2	
10	DV01414000001	PLASTIC FASTENING STRIP		1	
11	GBT97. 1-6-A3L	FLAT WASHER		1	
12	DV01416000022	LOCK PIN		1	
13	DV01416000006	FIXING PLATE WELDMENT		1	
14	DV01416000012	SPRING		1	

LOVOL
9ZR D22327


RGV1205010000K AXIAL FLOW ROLLER ASSEMBLY-1



RGV1205010000K AXIAL FLOW ROLLER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV1205010000K	AXIAL FLOW ROLLER ASSEMBLY	001	1	
1	GBT894. 1-50	RETAINING RING FOR SHAFT		1	
2	RGV1205010001K	FRONT RETAINER RING INSTALLATION		1	
2.1	RGV1903160003K	BEARING 6210		1	
2.2	HG2201. 15. 2. 1a	FRONT RETAINER RING WELDMENT		1	
3	DV01205000050a	CYLINDER INSTALLATION		1	
4	DV01205000069	REAR RETAINER RING WELDMENT		1	
5	DV01205000039	BEARING		1	
5.1	DV01102000150	DUSTPROOF CAP OF OIL CUP		1	
5.2	JBT7940. 1-M8X1	STRAIGHT-THROUGH PRESSURE OIL CUP		1	
5.3	DG2003. 15A-02	BEARING SEAT		1	
5.4	GBT3882-UEL207-E207	BEARING		1	
5.5	G40. 14. 6-01	ECCENTRIC SLEEVE 207		1	
6	GBT818-M5X16-4. 8-A2L	CROSS RECESSED PAN HEAD SCREWS		2	
7	GBT93-12-A3L	STANDARD SPRING WASHER		4	
8	GBT5783-M12X35-8. 8-A3L	HEX HEAD BOLTS		4	
9	GBT93-5-A3L	STANDARD SPRING WASHER		2	
10	GBT97. 1-5-A3L	FLAT WASHERS		2	
11	DV01205000014	SHIELD		1	

RGV1205010000K AXIAL FLOW ROLLER ASSEMBLY-2




RGV1205010000K AXIAL FLOW ROLLER ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV1205010000K	AXIAL FLOW ROLLER ASSEMBLY		1	
	DV01205000050a	CYLINDER INSTALLATION		1	
1	DV01205000051	FEED TAPER BODY WELDMENT		1	
2	GBT5783-M10X35-10.9-A3L	HEX HEAD BOLTS		6	
3	GBT93-10-A3L	STANDARD SPRING WASHER		14	
4	DV01205000065	SPLINE BUSH		1	
5	Q72142	PLUG PIECE		1	
6	GBT70.1-M10X25-8.8-A3L	HEXAGON SOCKET HEAD CAP SCREW		2	
7	DG2003.15.1-01	COUNTERWEIGHT		2	
8	GBT97.1-8-A3L	FLAT WASHERS		16	
9	GBT93-8-A3L	STANDARD SPRING WASHER		16	
10	GBT5783-M8X25-8.8-A2L	HEX HEAD BOLTS		16	
11	DV01205000053a	TOOTH BAR CYLINDER INSTALLATION		1	
12	GBT5783-M10X25-8.8-A3L	HEX HEAD BOLTS		6	
13	GBT97.1-10-A3L	FLAT WASHERS		6	
14	DV01205000066	SHAFT EMD		1	

LOVOL
9ZR D22327

RGV1205010000K AXIAL FLOW ROLLER ASSEMBLY-3




RGV1205010000K AXIAL FLOW ROLLER ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RGV1205010000K	AXIAL FLOW ROLLER ASSEMBLY		1	
	DV01205000050a	CYLINDER INSTALLATION		1	
	DV01205000051	FEED TAPER BODY WELDMENT		1	
1	GBT70. 1-M8X16-8. 8-A2L	HEXAGON SOCKET HEAD CAP SCREW		28	
2	DV01205000008	OUTER VANE		2	
3	DG2002. 15. 1. 2-02	CONNECTINGSEAT		14	
4	DV01205000052	FEED TAPER BODY WELDMENT		1	

LOVOL
9ZR D22327

RGV1205010000K AXIAL FLOW ROLLER ASSEMBLY-4




RGV1205010000K AXIAL FLOW ROLLER ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RGV1205010000K	AXIAL FLOW ROLLER ASSEMBLY		1	
	DV01205000050a	CYLINDER INSTALLATION		1	
	DV01205000053a	TOOTH BAR CYLINDER INSTALLATION		1	
1	GBT5783-M8X25-8. 8-A2L	HEX HEAD BOLTS		36	
2	RV01205000011	RACK BAR WELDMENT		3	
3	DV01205000054a	CYLINDER SPOKE DISK WELDMENT		1	
4	GBT97. 1-8-A3L	FLAT WASHERS		36	
5	GBT93-8-A3L	STANDARD SPRING WASHER		36	
6	GBT6170-M8-8-A2L	TYPE 1 HEX NUT		24	
7	RV01205000012	RACK BAR WELDMENT		3	

LOVOL
9ZR D22327

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-0




RV01501190000 ENGINE ASSEMBLY-0

No.	Part No.	Description	Version	QTY.	Remark
	RV01501190000	ENGINE ASSY		1	
1	GBT5783-M10X40-10.9-A3L	HEX HEAD BOLTS		8	
2	GBT93-10-A3L	STANDARD SPRING WASHER		16	
3	GBT97.1-10-A3L	FLAT WASHERS		16	
4	DG2003K.45.3	RIGHT FRONT SUPPORT SEAT WELDMENT		1	
5	RV01501060001	DISELENGINE		1	
6	GBT5782-M16X100-10.9-A2L	HEX HEAD BOLTS		4	
7	W24392	WASHER		8	
8	W24395	DAMPINGMAT		8	
9	W24394	SHOCKABSORPTIONGASKETSEAT		8	
10	W24393	SPACE PIPE		4	
11	DG2007.45A-02	OIL DRAIN HOSE		1	
12	GBT6170-M16-10-A3L	TYPE 1 HEX NUT		8	
13	DG2003K.45.4	LEFT FRONT SUPPORT SEAT WELDMENT		1	
14	DG2003K.45.1a	LEFT BACK SEAT		1	
15	GBT5783-M10X25-10.9-A3L	HEX HEAD BOLTS		8	
16	DG2003K.45.2	RIGHT BACK SUPPORT SEAT WELDMENT		1	
17	GBT97.1-12-A3L	FLAT WASHERS		6	
18	GBT93-12-A3L	STANDARD SPRING WASHER		6	
19	GBT5783-M12X40-10.9-A3L	HEX HEAD BOLTS		6	
20	DG2007.45A-01	PULLEY - POWER OUTPUT		1	
21	DG2002.45.7	UPPER LIMITING ROD WELDMENT		1	
22	Q67632	B TYPE WORM DRIVE TYPE HOSE HOOP		2	

RV01501190000 ENGINE ASSEMBLY-0 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	GBT5783-M8X25-10.9-A2L	HEX HEAD BOLTS		4	
24	GBT93-8-A3L	STANDARD SPRING WASHER		4	
25	GBT97.1-8-A3L	FLAT WASHERS		4	
26	DG2007.45A.2	ROD		1	
27	RV01501190001	ROD		1	

RV01501190000 ENGINE ASSEMBLY-1



RV01501190000 ENGINE ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
1	RV01501060001	DISELENGINE			
	CQ1460820	BOLT		2	
2	1001066-X88	REAR HANGING EAR		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-2

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
1	1002026-X2	CYLINDER BUSH		4	
2	Q5280812	ELASTIC CYLINDRICAL PIN		2	
3	1002013-X2	PLUG PIECE		1	
4	1002031-X2	PLUG PIECE		2	
5	1305010AS001	DRAIN SWITCH ASSEMBLY		1	
6	Q5220614	CYLINDRICAL PIN		2	
7	Q5221020	CYLINDRICAL PIN		2	
8	1011048-X2	SCREW PLUG		1	
9	1002010-X2B1	CYLINDER BLOCK ACHA0277		1	
10	CQ61803	PLUG		1	
11	Q61901	SCREW PLUG		1	
12	Q5221026	CYLINDRICAL PIN		2	
13	CQ34008	HEXAGON NUT M8		4	
14	4001001-G025	HYDRAULIC PUMP GEAR		1	
15	CQ1480885A	BOLT		4	
16	CQ1480875A	BOLT		1	
17	CQ1480845B	BOLT		2	
18	CQ1480840B	BOLT		1	
19	CQ1480850B	BOLT		1	
20	1002028AX2	NUT		1	
21	1002065AX2	COVER PLATE ASSEMBLY-GEAR CHAMBER		1	
22	CQ1480820A	BOLT		8	
23	CQ1480860B	BOLT		2	

RV01501190000 ENGINE ASSEMBLY-2 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
24	1002069-C012	GASKET		1	
25	1002061-G025	GEAR CHAMBER HOUSING COVER		1	
26	1002076-X2	SEAL RING		1	
27	1002073-X2	RECTANGULAR SEAL RING		1	
28	1002074-X2	SEAL RING		1	
29	1002080AG025	GEAR CHAMBER SPACER PLATE		1	
30	1002082AX2	SPACER PLATE MAT		1	
31	CQ1201075	STUD		2	
32	1002027AX2	STUD		1	
33	1011021-X2	SLEEVE-OIL PUMP BODY		1	
34	CQ1480820A	BOLT		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-3

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
1	1003040AX2/A	CYLINDER COVER HOUSING COVER		1	
2	1003046-X2	SEAL GASKET-CYLINDER COVER		1	
3	1003036-C012	CYLINDER COVER BOLT		18	
4	CQ61304	SCREW PLUG		3	
5	1003027AX2	PLUG PIECE		2	
6	1003020AX2	CYLINDER COVER		1	
7	1003028-X2	PLUG PIECE		7	
8	1003030AX2	CYLINDER COVER GASKET		1	
9	1003023-X2	SYPHON		4	
10	1003022-X2	COPPER BUSH		4	
11	1003024-X2	PLUG M10X1		2	
12	1003047-X2	SLEEVE-SEAL GASKET		10	
13	CQ1460625	BOLT		10	
14	1003105-X2/A	FILLER CAP		1	
15	1003044-X2	SEAL GASKET-FILLER CAP		1	
16	1014030-X12	OIL AIR SEPARATOR		1	
17	1014022BX2	BREATHING HOSE		1	
18	1014029-X2	HOSE CLIP		2	
19	1014038-5X4	OIL RETURN PIPE		1	
20	1014049-5X4	HOSE CLIP		1	
21	CQ34006	HEXAGON HEAD NUT		2	
22	CQ1460630	BOLT		2	

RV01501190000 ENGINE ASSEMBLY-3 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	1014034-C122	CONNECTING HOSE		1	
24	CQ67629	CLIP HOOP		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-4

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
1	1004110AX3	PISTON RING ASSEMBLY		4	
2	1004016-X3	PISTON		4	
3	1004045-X3	CONNECTING ROD ASSEMBLY		4	
4	1004100-X2	CONNECTING ROD BEARING		4	
5	1004001-X3	PISTON COOLING NOZZLE		4	
6	1004085-X2	SCREW		4	
7	1004022-X3	RETAINING RING FOR HOLE		8	
8	1004021-X3	PISTON PIN		4	
9	1004062-X2	CONNECTING ROD BOLT		4	
10	1004067-X2	CONNECTING ROD NUT		8	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-5

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-5

No.	Part No.	Description	Version	QTY.	Remark
1	1005051-X2	NUT-CRANKSHAFT BELT PULLEY		1	
2	1005040-G034	SHOCKABSORBER		1	
3	1002960-G025/A	SEAL RING		1	
4	1005031-X12	TENSIONING ROLLER-CRANKSHAFT		1	
5	Q5500516	SEMICIRCLE KEY		1	
6	1005150-X2	MAIN BEARING ASSEMBLY		5	
7	1005160-X2	THRUST SHIM ASSEMBLY		2	
8	1005115-G009	FLYWHEEL GEAR RING		1	
9	1005118-X12	FLYWHEEL BOLT		6	
10	1005021-X12	CRANKSHAFT		1	
11	1005078-X2	BOLT-CRANKSHAFT MAIN BEARING COVER		10	
12	Q5221018	CYLINDRICAL PIN		1	
13	1005102-X2	SEAL WASHER		1	
14	1005950AX2	REAR OIL SEAL		1	
15	1005128-X2	BOLT-FLYWHEEL COVER		1	
16	CQ1480825A	BOLT		6	
17	1005121-G009	FLYWHEEL HOUSING		1	
18	Q5211024	CYLINDRICAL PIN		2	

RV01501190000 ENGINE ASSEMBLY-6

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-6

No.	Part No.	Description	Version	QTY.	Remark
1	1006016-X2A1	CAMSHAFT		1	
2	1006057-X2	SLEEVE-CAMSHAFT 5		1	
3	1006056-X2	SLEEVE-CAMSHAFT 4		1	
4	1006053-X2	SLEEVE-CAMSHAFT 3		1	
5	1006052-X2	SLEEVE-CAMSHAFT 2		1	
6	1006051-X2	SLEEVE-CAMSHAFT 1		1	
7	Q5500416	SEMICIRCLE KEY		1	
8	1006019-X2	GEASKET		1	
9	CQ1460620	BOLT		2	
10	1006018-X2/A	TENSIONING ROLLER-CAMSHAFT		1	
11	1006022-X2	WASHER		1	
12	Q40310	SPRING WASHER		1	
13	1006021-X2	BOLT-CAMSHAFT TIMING GEAR		1	
14	1006041-X12	TENSIONING MIDDLE GEAR SHAFT		1	
15	1006030AX2	MIDDLE TENSIONING ROLLER		1	
16	1006032-X2	BEARING-MIDDLE TENSIONING ROLLER		1	
17	1006043-X2	COVER PLATE-FASTENING TENSIONING ROLLER		1	
18	CQ1480850B	BOLT		2	
19	1006060-X12	NOZZLE		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-7

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-7

No.	Part No.	Description	Version	QTY.	Remark
0	1007090-X2	ROCKER ASSEMBLY			
1	CQ1480860B	BOLT		8	
2	1007155-X2	EXHUST ROCKER		4	
3	1007091-X2	ROCKER SEAT		1	
4	1007099-X2	RETAINER PIECE-LOCATING SPRING		6	
5	1007097-X2	MIDDLE LOCATING SPRING		3	
6	1007159-X2	LOCKING NUT		8	
7	GBT78-M8X15-Zn. D	SCREW		1	
8	1007158-X2	BPLT-VALVE ROCKER		8	
9	1007050-X2A1	PUSH ROD		8	
10	1007061AX2	TAPPET		8	
11	QC/T-388-12-DZN13	PLUG PIECE		2	
12	1007131-X2	ROCKER SHAFT		1	
13	1007028-X2	COLLET-AIR INLET VALVE		8	
14	1007029-B1	COLLET-AIR OUT VALVE		8	
15	1007022-X2	SPRING SEAT		8	
16	1007021-X2	VALVE OUTER SPRING		8	
17	1007035-X2	OIL SEAL		8	
18	1007024-X2	SPRING SEAT		8	
19	1007032-X2	AIR INLET VALVE GUIDE PIPE		8	
20	1007081-X2A1	AIR INLET VALVE SEAT		4	
21	1007011-X2	AIR INLET VALVE		4	
22	1007082-X2A1	EXHAUST VALVE SEAT		4	

RV01501190000 ENGINE ASSEMBLY-7 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	1007012-X2	EXHAUST VALVE		4	
24	1007145-X2	INTAKEVALVEROCKERARMASSEMBLY		4	
25	Q43120	RETAINER RING 20		4	
26	1007092-X2	MIDDLE ROCKER SHAFT SUPPORT SEAT		2	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-8

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-8

No.	Part No.	Description	Version	QTY.	Remark
1	CQ1460865	BOLT		4	
2	1008014-C206	AIR PREHEATING FITTING SEAT		1	
3	1008013AX3/A	GASKET-AIR PREHEATING FITTING		2	
4	3750010-X97	PREHEATING FITTING		1	
5	1008011-C289	AIR INTAKE MANIFOLD		1	
6	CQ1460825	BOLT		6	
7	CQ39608	HEXAGON NUT		2	
8	CQ1200822	STUD		2	
9	1008051-X2/A	GASKET-AIR INLET PIPE		1	
10	1008055-X2	GASKET-AIR OUT PIPE		4	
11	1008021-G009	AIR EXHAUST MANIFOLD		1	
12	CQ1201030	STUD		8	
13	CQ41910	WASHER		8	
14	CQ34010	HEXAGON NUT		8	
15	1008061-G009	CASE		1	
16	CQ1460612TF36	BOLT		5	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-9

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-9

No.	Part No.	Description	Version	QTY.	Remark
1	1009012-X2	SEAL		1	
2	1009010-G031	OIL PLATE		1	
3	Q40106	WASHER		26	
4	Q40406	SPRING WASHER		26	
5	CQ1500616	BOLT		23	
6	10090119CB1	WASHER		1	
7	1009018CB1	OIL DISCHARGING PLUG		1	
8	1009030-X162	OIL DIPSTICK ASSY		1	
9	1009025-X2	SCALEPLATE PIPE		1	
10	1009022-X2/A	O-RING		1	
11	Q34006	NUT		3	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-10



RV01501190000 ENGINE ASSEMBLY-10

No.	Part No.	Description	Version	QTY.	Remark
1	CQ1460820	BOLT		2	
2	1010010-X2/A	OILCOLLECTORASSEMBLY		1	
3	Q7342425	O-RING		1	
4	CQ1460816TF36	BOLT		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-11

RV01501190000 ENGINE ASSEMBLY-11

No.	Part No.	Description	Version	QTY.	Remark
1	1011010-C617	OIL PUMP ASSEMBLY		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-12

RV01501190000 ENGINE ASSEMBLY-12

No.	Part No.	Description	Version	QTY.	Remark
1	1012064AX2	SEAL GASKET		1	
2	1012005-X2	BASE SEAT-OIL FILTER		1	
3	1012010-X2	OIL FILTER ASSEMBLY		1	
4	CQ1460830	BOLT		4	
5	CQ1460616	BOLT		2	
6	1012063-X2	INSULATION COVER		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-13

RV01501190000 ENGINE ASSEMBLY-13

No.	Part No.	Description	Version	QTY.	Remark
1	CQ61304	SCREW PLUG		2	
2	CQ34008	HEXAGON NUT		4	
3	Q40408	WASHER		4	
4	Q40108	WASHER		4	
5	CQ1460845	BOLT		1	
6	CQ1460825	BOLT		10	
7	1013011-X2	OIL COOLER ASSEMBLY COVER PLATE		1	
8	1013033-X2	PRESSURE LIMITING VALVE		1	
9	1013037-X2	SPRING		1	
10	1013038-X2	WASHER		2	
11	1013032-X2	SCREW PLUG		2	
12	Q9661405	STEEL BALL		1	
13	1013036-X2	SPRING		1	
14	1013029-X2	WASHER		2	
15	1013028-X2	SEAL RING		2	
16	1013031AX2	GASKET		1	
17	1013034-X2	O-RING		2	
18	CQ1200818	STUD		3	
19	CQ1200835	STUD		1	
20	1013020-C012/A	OIL COOLER ASSEMBLY		1	
21	1013030-C012/A	OIL COOLER ASSEMBLY		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-14

RV01501190000 ENGINE ASSEMBLY-14

No.	Part No.	Description	Version	QTY.	Remark
1	1104101-X2	RUBBER HOSE		1	
2	1104305-X2	HOOP		11	
3	1104102-X2	OIL RETURN PIPE-OIL INJECTOR NOZZLE		3	
4	1118068-Y06	OIL RETURN PIPE-TURBOCHARGER		2	
5	1104205-X2	CLAMPASS' Y		2	
6	1104031-X26	OIL RETURN PIPE		1	
7	CQ1420812	BOLT		1	
8	1104030-X26	OIL INLET PIPE		1	
9	1104050-G034	OIL RETURN PIPE ASSEMBLY		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-15


LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-15

No.	Part No.	Description	Version	QTY.	Remark
1	1111010-G036	OIL INJECTION PUMP		1	
2	1111014-X2	WASHER		3	
3	Q40308	SPRING WASHER		3	
4	CQ34008	HEXAGON NUT M8		3	
5	1111103FX03	BRACKET		1	
6	CQ1420830	BOLT		1	
7	Q40208	WASHER		1	
8	CQ1461070	BOLT		2	
9	1111201-X03	GASKET-OIL INJECTION PUMP		1	
10	1111216-C650	TRANS GEAR		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-16



RV01501190000 ENGINE ASSEMBLY-16

No.	Part No.	Description	Version	QTY.	Remark
1	CQ1421045	BOLT		4	
2	1112022-X2	WASHER		4	
3	1112021-X2	OIL INJECTOR PRESSURE PLATE		4	
4	1112010-C017	OIL INJECTOR ASSEMBLY		4	
5	1112013-X2	O-RING		4	
6	1112033-F51Q	GASKET		4	

RV01501190000 ENGINE ASSEMBLY-17

RV01501190000 ENGINE ASSEMBLY-17

No.	Part No.	Description	Version	QTY.	Remark
1	1008073-C012	NUT-TURBOCHARGER		5	
2	1118022-Y01	SEAL GASKET-TURBOCHARGER TO AIR OUT PIPE		1	
3	1118010-G009	TURBOCHARGER ASSEMBLY		1	
4	1118035-G009	OIL INLET PIPE ASSEMBLY-TURBOCHARGER		1	
5	1008074-C012	STUD-TURBOCHARGER		5	
6	1118045-G009/A	OIL RETURN PIPE ASSEMBLY		1	
7	1118046-Y01	OIL RETURN PIPE JOINT-TURBOCHARGER		1	
8	1118016-Y01	STUD		4	
9	1118011-Y01	SEAL GASKET-AIR OUT PIPE TO TURBOCHARGER		4	
10	1118038AY01	INLET PIPE JOINT-CYLINDER BLOCK		1	
11	1002039-D1	WASHER-LOCATING BOLT		2	
12	1118032-G011	CONNECTING JOINT 1		1	
13	1008012-Y01	RUBBER HOSE		2	
14	1118014-G009	AIR OUT SYPHON		1	
15	CQ67660B	CLAMP HOOP		4	
16	1118068-Y06	OIL RETURN PIPE-TURBOCHARGER		1	
17	1118090-Y06/A	OILRETURNCONNECTORASSEMBLY		2	
18	3551093-X2	HOOP		2	
19	1118036-Y01	INLET PIPE JOINT-TURBOCHARGER		2	
20	1104087-D1	COPPER WASHER		1	
21	1104089-D1	GASKET		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-18


LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-18

No.	Part No.	Description	Version	QTY.	Remark
1	1117061-D6	HOLLOW BOLT		2	
2	3509326-A27	GASKET		4	
3	CQ1461035	BOLT		2	
4	1117020AX21	BASE SEAT		1	
5	CQ34010	HEXAGON NUT		2	
6	1117012AX21	FUEL FILTER		1	
7	1104035-X97	OIL CONVEYING PIPE ASSEMBLY-PUMP TO FILTER		1	
8	1104040-X97	OIL CONVEYING PIPE ASSEMBLY-FILTER TO PUMP		1	
9	1117010AX21	FUEL FILTER ASSEMBLY		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-19



RV01501190000 ENGINE ASSEMBLY-19

No.	Part No.	Description	Version	QTY.	Remark
1	CQ1420625	BOLT		1	
2	1129030-X2	HIGH PRESSURE OIL PIPE PRESSURE PLATE		1	
3	1129100BX97	HIGH PRESSURE OIL PIPE		1	
4	1129070-C289	PIPE CLAMP ASSEMBLY		1	
5	CQ1420830	BOLT		1	
6	1129070-C289	PIPE CLAMP		2	
7	CQ1420816	BOLT		1	
8	1129040-X2	HIGH PRESSURE OIL PIPE BOTTOM PLATE		1	

LOVOL
9ZR D22327


RV01501190000 ENGINE ASSEMBLY-20

RV01501190000 ENGINE ASSEMBLY-20

No.	Part No.	Description	Version	QTY.	Remark
1	Q40108	WASHER		3	
2	Q40308	SPRING WASHER		3	
3	1303041-X2	BOLT		1	
4	CQ1460830	BOLT		2	
5	1303012-C752	OUTLET PIPE		1	
6	1303022-X2	SEAL WASHER-WATER OUT PIPE		1	
7	1306010-X2	TEMPERATURE ADJUSTING MECHANISM		1	
8	CQ1480850B	BOLT		1	
9	CQ61803	PLUG		2	
10	1303017-G009	WATER INLET PIPE		1	
11	CQ1200880	STUD		1	
12	CQ34008	HEXAGON NUT M8		2	
13	1303042-X2	STUD-WATER INTER PIPE		1	
14	CQ1460820TF36	BOLT		2	
15	1303026-X2	WASHER-WATER IN PIPE		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-21



RV01501190000 ENGINE ASSEMBLY-21

No.	Part No.	Description	Version	QTY.	Remark
1	1307018-X2	MAT-WATER PUMP		1	
2	1307010-G034/B	WATER PUMP ASSEMBLY		1	
3	CQ1420822	BOLT		5	
4	CQ1200845	STUD		4	
5	Q40308	SPRING WASHER		4	
6	CQ34008	HEXAGON NUT M8		4	
7	1308010-G009	FAN ASSEMBLY		1	
8	CQ34010	HEXAGON NUT		2	
9	Q40310	SPRING WASHER		2	
10	AV13-1119	V-BELT		1	


RV01501190000 ENGINE ASSEMBLY-22

RV01501190000 ENGINE ASSEMBLY-22

No.	Part No.	Description	Version	QTY.	Remark
1	1307071-X2	GASKET		10	
2	1104082-X2	HOLLOW BOLT		3	
3	4001025-X12	MIDDLE GEAR SHAFT LUBRICATING OIL PIPE		1	
4	CQ1481020A	BOLT		2	
5	4001031-X12	PLUG COVER-GEAR ROOM		1	
6	4001032-X97	WASHER-PLUG COVER		1	
7	CQ1480820A	BOLT		1	
8	4001028-X12	TRANSITION JOINT		1	
9	4001001-G025	HYDRAULIC PUMP DRIVING GEAR		1	
10	CQ15008120	BOLT		2	
11	4001910-X12	HYDRAULIC PUMP MIDDLE GEAR		1	
12	CQ2181040	HEXAGON SOCKET HEAD CAP SCREW		1	
13	Q68610	PIPE CLAMP		1	
14	4001017-X12	HYDRAULIC PUMP MIDDLE GEAR SHAFT		1	
15	CQ1480835B	BOLT		1	
16	4001011-X12	DRIVING GEAR		1	
17	4001029-X12	PIPE JOINT		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-23




RV01501190000 ENGINE ASSEMBLY-23

No.	Part No.	Description	Version	QTY.	Remark
1	3701341-G034	BRACKET		1	
2	CQ1420830	BOLT		1	
3	Q40208	WASHER		1	
4	CQ1481020A	BOLT		2	
5	CQ1461030	BOLT		2	
6	3701010-A249/A	ALTERNATOR ASSY		1	
7	CQ1421030	BOLT		3	
8	3701321-G034/B	GENERATOR BRACKET		1	

LOVOL
9ZR D22327

RV01501190000 ENGINE ASSEMBLY-24




RV01501190000 ENGINE ASSEMBLY-24

No.	Part No.	Description	Version	QTY.	Remark
1	3708010-2B5	STARTOR ASSEMBLY		1	
2	CQ1481035A	BOLT		2	

LOVOL
9ZR D22327

DV01502000000 RADIATOR ASSEMBLY

LOVOL
9ZR D22327




DV01502000000 RADIATOR ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	DV01502000000	RADIATOR ASSEMBLY		1	
1	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		4	
2	GBT93-8-A0P	STANDARD SPRING WASHER		4	
3	GBT97. 1-8-A0P	FLAT WASHER		4	
4	DV01502000002	SUPPORT WELD		1	
5	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		2	
6	DV01502000001	REAR SUPPORT WELDMENT		1	
7	Q67664	B-TYPE WORM TRANSMISSION HOSE CLAMP		4	
8	DG2003K. 47-03	WATER TANK WATER INLET HOSE		1	
9	DG2007. 47-01	WATER TANK OUTLET HOSE		1	
10	DG2007. 47. 1a	WATER TANK ASSEMBLY		1	
11	GBT14-M12X80-4. 8-A3L	BIG CUP HEAD SQUARE NECK BOLT		2	
12	DG2002. 47-05	RUBBER WASHER		4	
13	D20010. 47-05	WASHER		2	
14	GBT97. 1-12-A0P	FLAT WASHER		2	
15	GBT6182-M12	HEXAGON LOCKING NUT, TYPE-2		2	

LOVOL
9ZR D22327


RV01503010000 DUST REMOVAL COVER ASSEMBLY-1



RV01503010000 DUST REMOVAL COVER ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RV01503010000	DUST REMOVAL COVER ASSEMBLY	003	1	
1	BA150B2. 6. 7	HANDLE		1	
2	RV01503020005	WATER TANK BONNET		1	
3	GBT93-8-A3L	STANDARD SPRING WASHER		18	
4	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		12	
5	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		6	
6	D1681. 43. 3	AGRAFFE		2	
7	DG2007. 43. 3	WIRE COMBINATION		1	
8	GBT97. 1-8-A3L	FLAT WASHER		6	
9	GBT91-3. 2X14-A3L	SPLIT PIN		2	
10	GBT5783-M8X25-8. 8-A2L	HEXAGON BOLT		4	
11	DV01503000055	REAR CONNECTING SEAT WELDED PART		1	
12	DV01503000016	CONNECTING PLATE		2	
13	RV01503010001	ENGINE SHIELD ASSEMBLY		1	
14	RV01503040002	REAR CONNECTING SEAT WELDED PART		1	

RV01503010000 DUST REMOVAL COVER ASSEMBLY-2




RV01503010000 DUST REMOVAL COVER ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RV01503010000	DUST REMOVAL COVER ASSEMBLY		1	
	RV01503010001	ENGINE SHIELD ASSEMBLY		1	
1	DV01503000006	RUBBER BLOCK		7	
2	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		6	
3	GBT93-8-A3L	STANDARD SPRING WASHER		6	
4	GBT97. 1-8-A3L	FLAT WASHER		6	
5	DV01503010014	STRIP SEAL		2	
6	DV01503000063	SPONGE SEAL PIECE		1	
7	RV01503010002	WELDED ENGINE BONNET		1	
8	HE2001. 43A. 2-02	INNER UPPER SPONGE SEAL		2	
9	HE2001. 43A. 2-01	INNER LOWER SPONGE SEAL		4	
10	D20012. 32-04	HOOK		3	
11	DV01503000032	SPONGE 7		1	
12	DV01503000030	SPONGE 1		1	

LOVOL
9ZR D22327

LOVOL
9ZR D22327


RGV1504030000K FUEL SUPPLY COMBINATION-1



RGV1504030000K FUEL SUPPLY COMBINATION-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV1504030000K	FUEL SUPPLY COMBINATION	001	1	
1	RV01504130004	ELEC. VALVE CONNECTING HOSE		1	
2	Q676B16	C-TYPE WORM TRANSMISSION HOSE CLAMP		8	
3	RV01504130002	OIL OUTLET PIPE ASSEMBLY		1	
3.1	RV01504130003	OIL OUTLET PIPE UNIT		1	
3.2	DG2001. 46. 3-01	O-RING		1	
3.3	GBT5649-M12X1. 5D	WASHER		1	
3.4	GBT5649-M12X1. 5L	LOCKING NUT		1	
4	DV01504050001	FUEL TANK INSTALLATION		1	
5	RGV1504030001K	ENGINE OIL INLET PIPE		1	
6	Q67405200	PLASTIC FASTENING STRIP		5	
7	DV01504050030	RUBBER WASHER		2	
8	DV01504050031	HOOP BELT WELDMENT		2	
9	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		2	
10	GBT5783-M10X130-8. 8-A3L	HEXAGON BOLT		2	
11	GBT97. 1-10-A3L	FLAT WASHER		4	
12	GBT5783-M10X30-8. 8-A3L	HEXAGON BOLT		4	
13	GBT93-10-A3L	STANDARD SPRING WASHER		4	
14	RGV1504030002K	ENGINE OIL RETURN PIPE		1	
15	GBT96. 1-10-A3L	BIG WASHER		2	
16	DG2001. 46. 4	DIESEL OIL FILTER ASSEMBLY FTZ0810		1	

RGV1504030000K FUEL SUPPLY COMBINATION-2




RGV1504030000K FUEL SUPPLY COMBINATION-2

No.	Part No.	Description	Version	QTY.	Remark
	DV01504050001	FUEL TANK INSTALLATION		1	
	RGV1504030000K	FUEL SUPPLY COMBINATION		1	
1	DV01504050002	FUEL TANK		1	
2	DC2003K. 46. 1. 2	OIL TANK FILLING PORT COVER ASSEMBLY		1	
3	DC2003K. 46. 1. 3	FILTER MESH ASSEMBLY		1	
4	DV01504050007	INDICATOR CONNECTING PIPE , OIL QTY		1	
5	DV01504050046	AIR OUTLET PIPE		1	
6	JBT982-18	COMBINED SEAL GASKET		1	
7	Q617B18	HEXAGON PLUG		1	
8	Q676B16	C-TYPE WORM TRANSMISSION HOSE CLAMP		3	

LOVOL
9ZR D22327

DV01505000000 MANIFOLDS & INDUCTION SYSTEM


LOVOL
9ZR D22327



DV01505000000 MANIFOLDS & INDUCTION SYSTEM

No.	Part No.	Description	Version	QTY.	Remark
	DV01505000000	MANIFOLDS & INDUCTION SYSTEM	003	1	
1	GBT96. 1-8-A3L	BIG WASHER		4	
2	DG2007. 48. 2	AIR FILTER BRACKET WELDMENT		1	
3	GBT97. 1-10-A3L	FLAT WASHER		4	
4	GBT93-10-A3L	STANDARD SPRING WASHER		4	
5	GBT5783-M10X25-8. 8-A3L	HEXAGON BOLT		4	
6	DV01505000001	AIR FILTER		1	
6. 1	DG2007. 48A. 1a-02	PRIMARY FILTER		1	
6. 2	DV01505000002	SECONDARY FILTER		1	
6. 21	DV01505000003	MAIN FILTER ELEMENT		1	
6. 22	DV01505000004	SECURITY FILTER ELEMENT		1	
7	GBT97. 1-8-A3L	FLAT WASHER		4	
8	GBT93-8-A3L	STANDARD SPRING WASHER		12	
9	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		4	
10	Q676102	B-TYPE WORM TRANSMISSION HOSE CLAMP		2	
11	DV01505000006	AIR INLET CONNECTING PIPE		1	
12	GBT5783-M8X16-8. 8-A2L	HEXAGON BOLT		8	
13	RV01505000003	SEAT PLATE		1	
14	Q67676	B-TYPE WORM TRANSMISSION HOSE CLAMP		1	
15	DG2007. 48B-01	INTAKE CONNECTOR 2		1	
16	Q67689	B-TYPE WORM TRANSMISSION HOSE CLAMP		1	

RV01506000000K MANIFOLDS & EXHAUST SYSTEM




RV01506000000K MANIFOLDS & EXHAUST SYSTEM

No.	Part No.	Description	Version	QTY.	Remark
	RV01506000000K	MANIFOLDS & EXHAUST SYSTEM		1	
1	DV01506010003	LONG HOOP		2	
2	GBT5783-M8X30-8.8-A2L	HEXAGON BOLT		6	
3	DV01506000001	EXHAUST SILENCER		1	
4	DV01506000002	EXHAUST PIPE WELDMENT 1		1	
5	GBT96.1-8-A3L	BIG WASHER		6	
6	DG2002.49.4	SEAL GASKET UNIT		1	
7	RV01506030001	EXHUST PIPE WELDMENT II		1	
8	GBT97.1-8-A3L	FLAT WASHER		4	
9	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		6	
10	GBT5783-M8X25-8.8-A2L	HEXAGON BOLT		2	
11	GBT93-8-A3L	STANDARD SPRING WASHER		11	
12	DG2003K.49-02a	CONDOLE EAR		2	

D1681. 53 FIRE EXTINGUISHER

LOVOL
9ZR D22327




D1681. 53 FIRE EXTINGUISHER

No.	Part No.	Description	Version	QTY.	Remark
	D1681. 53	FIRE EXTINGUISHER		1	
1	D1681. 53. 1	FIREEXTINGUISHER		1	
2	D1681. 53. 2	BRACKET WELDMENT		1	
3	GBT97. 1-5-A0P	FLAT WASHERS		2	
4	GBT93-5-A0P	STANDARD SPRING WASHER		2	
5	GBT818-M5X12-4. 8-A2L	CROSS RECESSED PAN HEAD SCREWS		2	

DV01601000000 HEADER HYDRAULIC PRESSURE ASSEMBLY

LOVOL
9ZR D22327




DV01601000000 HEADER HYDRAULIC PRESSURE ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	DV01601000000	HEADER HYDRAULIC PRESSURE ASSEMBLY	007	1	
1	GBT882-B12X50-A0P	PIN SHAFT		2	
2	DV01601000009	REEL CYLINDER ASSY.		2	
3	Q50112	LOCK PIN		2	
4	DV01601000002	REEL CYLINDER PIN		2	
5	RV03601010001	LOCK PIN		4	
6	DV01603050003	CONNECTING JOINT		2	
7	DV01601000008	REEL PIPE		2	
8	GBT5783-M8X35-8.8-A2L	HEXAGON BOLT		3	
9	GBT93-8-A0P	STANDARD SPRING WASHER		3	
10	F600209	SINGLE HOLE PIPE CLAMP		6	
11	DV01601000010	LEFT OIL PIPE ASSEMBLY		1	
12	GBT5789-M6X20-8.8-A2L	HEXAGON FLANGE NUT		2	
13	DC2003K.50-03	PIPE CLAMP		1	
14	DC2003K.50-02	DIFFERENT DIAMETER TEE JOINT 14-18		1	
15	GBT97.1-8-A0P	FLAT WASHER		3	
16	DV01601000006	RIGHT OIL PIPE ASSEMBLY		1	
17	GBT6177.1-M6-8-A2L	HEXAGON FLANGE NUT		2	

DV0160200000 STEERING HYDRAULIC PRESSURE ASSEMBLY

LOVOL
9ZR D22327




DV01602000000 STEERING HYDRAULIC PRESSURE ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	DV01602000000	STEERING HYDRAULIC PRESSURE ASSEMBLY	004	1	
1	Q67632	B-TYPE WORM TRANSMISSION HOSE CLAMP		2	
2	HE2001. 50. 2-04	STEERING VALVE OIL RETURN HOSE		1	
3	DV01602000003	HEADER OIL PIPE ASSY.		1	
4	HE2001. 50. 2-01	TRANSITION JOINT		3	
5	JBT982-18	COMBINED SEAL GASKET		7	
6	DV01602000001	HEADER CYLINDER ASSEMBLY		1	
7	DV01603000010	PLASTIC FASTENING STRIP		5	
8	HE2001. 50. 2. 6	CONNECTING JOINT		1	
9	HE2001. 50. 2-03	TRANSITION JOINT		1	
10	SZ25	STEERING OIL CYLINDER		1	
11	GBT93-8-A3L	STANDARD SPRING WASHER		4	
12	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		4	
13	GBT5789-M6X12-8. 8-A2L	HEXAGON FLANGE NUT		4	
14	HE2001. 50. 2. 4	STEERING OIL PIPE ASSEMBLY 2		1	
15	DG2009. 50. 2	OIL RETURN PIPE ASSEMBLY		1	
16	DG2009. 50. 1	VALVE		1	
17	HE2001. 50. 2-02	TRANSITION JOINT		3	
18	HE2001. 50. 2. 5	JOINT		3	
19	HE2001. 50. 2. 3	STEERING OIL PIPE ASSEMBLY 1		1	

LOVOL
9ZR D22327


RGV3603080000 MULTI-WAY VALVE ASSEMBLY-1



RGV3603080000 MULTI-WAY VALVE ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RGV3603080000	MULTI-WAY VALVE ASSEMBLY	001	1	
1	GBT5789-M6X12-8. 8-A2L	HEXAGON FLANGE NUT		8	
2	DG2001. 50. 11	FUEL TANK FIXING STRIP WELDMENT		1	
3	DV01603000007	HYDRAULIC OIL TANK INSTALLATION		1	
4	DG2009. 50. 6	MULTI-WAY VALVE		1	
5	JBT982-18	COMBINED SEAL GASKET		6	
6	HE2001. 50. 2-02	TRANSITION JOINT		2	
7	RGV3603080003	RUBBER TUBE		1	
8	DV01603000010	PLASTIC FASTENING STRIP		6	
9	HE2001. 50. 2. 5	CONNECTING JOINT -PIPE 8		2	
10	DV01603050003	CONNECTING JOINT		5	
11	DV01603050050	CYLINDER		1	
12	Q617B18	HEXAGON PLUG		1	
13	GBT70. 1-M10X100-8. 8-A3L	INNER HEXAGON SCREW		1	
14	DG2001. 50-09	RUBBER STRIP		1	


RGV3603080000 MULTI-WAY VALVE ASSEMBLY-2



RGV3603080000 MULTI-WAY VALVE ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
	RGV3603080000	MULTI-WAY VALVE ASSEMBLY		1	
1	HE2001. 50. 3. 11	OIL TUBE		1	
2	HE2001. 50. 2-01	TRANSITION JOINT		2	
3	JBT982-18	COMBINED SEAL GASKET		6	
4	HE2001. 50. 2-02	TRANSITION JOINT		2	
5	HC1801. 50. 3. 5	OIL PIPE ASSEMBLY		1	
6	Q67632	B-TYPE WORM TRANSMISSION HOSE CLAMP		4	
7	HE2001. 50. 3-01	OIL RETURNING RUBBER PIPE OF MUTI-WAY VALVE		1	
8	HE2001. 50. 2. 6	CONNECTING JOINT		1	
9	HE2001. 50. 2-03	TRANSITION JOINT		1	
10	GBT70. 1-M8X20-8. 8-A2L	INNER HEXAGON SCREW		2	
11	GBT93-8-A3L	STANDARD SPRING WASHER		7	
12	GBT97. 1-8-A3L	FLAT WASHER		3	
13	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		3	
14	HF2902. 50. 3. 12	HYDRAULIC OIL TANK BREATHER		1	
15	Q67627	B-TYPE WORM TRANSMISSION HOSE CLAMP		1	
16	HF2902. 50. 3-04	BREATH CONNECTING TUBE		1	
17	DV01603020013	BREATH OIL PIPE		1	

RGV3603080000 MULTI-WAY VALVE ASSEMBLY-3




RGV3603080000 MULTI-WAY VALVE ASSEMBLY-3

No.	Part No.	Description	Version	QTY.	Remark
	RGV3603080000	MULTI-WAY VALVE ASSEMBLY		1	
1	GBT70. 1-M12X40-8. 8-A3L	INNER HEXAGON SCREW		4	
2	GBT93-12-A3L	STANDARD SPRING WASHER		4	
3	RV01603040010	ROTARY MOTOR		1	
4	GBT70. 1-M8X25-8. 8-A2L	INNER HEXAGON SCREW		4	
5	GBT93-8-A3L	STANDARD SPRING WASHER		7	
6	RV01603040021	FLANGE JOINT		2	
7	GBT3452. 1-23. 6X1. 80G	RUBBER O-SEAL RING		2	
8	RV01603040011	OIL TUBE 1		1	
9	RV01603040013	OIL TUBE 2		1	
10	GBT5783-M8X30-8. 8-A2L	HEXAGON BOLT		1	
11	RV01603040020	OIL PIPE FIXING CLAMP		2	
12	RGV3603080002	CONNECTING RUBBER TUBE ASSEMBLY 2		1	
13	RGV3603080001	CONNECTING RUBBER TUBE ASSEMBLY 1		1	
14	DV01603050003	CONNECTING JOINT		5	
15	GBT5789-M6X12-8. 8-A2L	HEXAGON FLANGE NUT		8	
16	3203505D9-L	TIE		3	
17	RV01603040002	CONTROL VALVE ASSEMBLY		1	
18	RV01603090005	ONE WAY VALVE OIL RETURN OIL PIPE ASSEMBLY		1	
19	Q676B25	C-TYPE WORM TRANSMISSION HOSE CLAMP		2	
20	RV01603090002	ONE WAY VALVE OIL RETURN RUBBER HOSE ASSEMBLY		1	
21	HE2001. 50. 2. 5	CONNECTING JOINT -PIPE 8		2	

LOVOL
9ZR D22327

RGV3603080000 MULTI-WAY VALVE ASSEMBLY-4




RGV3603080000 MULTI-WAY VALVE ASSEMBLY-4

No.	Part No.	Description	Version	QTY.	Remark
	RGV3603080000	MULTI-WAY VALVE ASSEMBLY		1	
	DV01603000007	HYDRAULIC OIL TANK INSTALLATION		1	
1	GBT70. 1-M5X16-8. 8-A2L	INNER HEXAGON SCREW		6	
2	GBT93-5-A0P	STANDARD SPRING WASHER		6	
3	TA700. 55A. 7-01a	OIL FILLING SCREW PLUG		1	
4	JBT982-33	COMBINED SEAL GASKET		1	
5	DV01603020009	FILLING CAP		1	
6	DV01603020008	RUBBER WASHER		1	
7	DV01603020002b	HYDRAULIC OIL TANK WELDMENT		1	
8	WU-40X80	OIL SUCTION FILTER		2	
9	GBT3452. 1-50. 0X2. 65G	RUBBER O-SEAL RING		2	
10	DG2001. 50. 1. 4	OIL SUCTION JOINT WELDMENT		1	
11	GBT93-6-A0P	STANDARD SPRING WASHER		8	
12	GBT5783-M6X20-8. 8-A2L	HEXAGON BOLT		8	
13	Q617B12	HEXAGON PLUG		1	
14	JBT982-12	COMBINED SEAL GASKET		1	
15	HE2001. 50. 3. 1. 13	OIL SUCTION JOINT WELDMENT		1	
16	Q676B16	C-TYPE WORM TRANSMISSION HOSE CLAMP		2	
17	RV01603070012	PIPE		1	

LOVOL
9ZR D22327

RV03604030000 STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY-1




RV03604030000 STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY-1

No.	Part No.	Description	Version	QTY.	Remark
	RV03604030000	STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY		1	
1	HF2901.50.4-01	FILTER OIL OUTLET		2	
2	JBT982-33	COMBINATION GASKET		2	
3	GBT5783-M10X20-8.8-A3L	HEX HEAD BOLTS		2	
4	GBT93-10-A3L	STANDARD SPRING WASHER		4	
5	GBT97.1-10-A3L	FLAT WASHERS		4	
6	DV01604000004	FILTER INSTALL BOARD		1	
7	HF2901.50.4.9	HIGH PRESSURE FILTER		1	
8	GBT5783-M10X30-8.8-A3L	HEX HEAD BOLTS		2	
9	HG2201.50.4.11	HST OIL INPUT HOSE		1	
10	DV01604000003	HST FILTER HOSE		1	
11	HF2901.50.4.6	HST slippage pump		2	
11.1	HF2901.50.4.6-01	HST slippage pump		1	
11.2	HF2901.50.4.6-02	O-RING 17.8X2.4		1	
12	DV01604000002	HST OUTPUT PIPE ASSEMBLY		1	
13	HF2901.50.4.7	HST JOINT		1	
13.1	HF2901.50.4.7-01	HST OIL INLET JOINT		1	
13.2	HF2901.50.4.7-02	O RING 13.8X2.4		1	
14	HF2901.50.4.2	HST OIL SUCTION JOINT		1	
14.1	HF2901.50.4.2-02	O RING 23.7X3.5		1	
14.2	HF2901.50.4.2-01	HST OIL SUCTION		1	
15	RV01604050001	HYDRAULIC STEPLESS SPEED CHANGING ASSEMBLY		1	

RV03604030000 STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY-1 (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
16	DV01604000001	HST OIL SUCTION PIPE		1	
17	Q67632	B TYPE WORM DRIVE TYPE HOSE HOOP		1	

RV03604030000 STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY-2




RV03604030000 STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY-2

No.	Part No.	Description	Version	QTY.	Remark
1	RV03604030000	STEPLESS SPEED HYDRAULIC PRESSURE ASSEMBLY		1	
2	HE2001. 50. 4-01	OIL RETURN RUBBER HOSE OF RADIATOR		1	
3	DV01603000010	PLASTIC FASTENING STRIP		4	
4	Q67632	B TYPE WORM DRIVE TYPE HOSE HOOP		3	
5	RV03604000002	RADIATOR ASSEMBLY		1	

LOVOL
9ZR D22327


RV01605050000 HYDRAULIC PRESSURE ASSEMBLY OF GEAR PUMP



RV01605050000 HYDRAULIC PRESSURE ASSEMBLY OF GEAR PUMP

No.	Part No.	Description	Version	QTY.	Remark
	RV01605050000	HYDRAULIC PRESSURE ASSEMBLY OF GEAR PUMP		1	
1	GBT70. 1-M8X25-8. 8-A2L	INNER HEXAGON SCREW		10	
2	GBT93-8-A3L	STANDARD SPRING WASHER		10	
3	GBT97. 1-8-A3L	FLAT WASHER		10	
4	D1681. 50-01	OIL DRAINAGE CONNECTOR		2	
5	GBT3452. 1-16. 0X2. 65G	RUBBER O-SEAL RING		2	
6	RV01605050001	DUALPUMP		1	
7	HG2201. 50B. 5-01	OIL SUCTION HOSE OF GEAR PUMP		1	
8	GBT70. 1-M10X40-8. 8-A3L	INNER HEXAGON SCREW		2	
9	GBT93-10-A3L	STANDARD SPRING WASHER		2	
10	RV01605050004	BACK PUMP OIL OUTLET PIPE		1	
11	Q67632	B-TYPE WORM TRANSMISSION HOSE CLAMP		2	
12	HG2201. 50B. 5. 1	OIL PIPE , PUMP VALVE		1	
13	RV01605050002	OIL SUCTION JOINT WELDMENT		1	
14	GBT3452. 1-18. 0X1. 80G	RUBBER O-SEAL RING		1	

RGV1701050000 ELECTRICAL ASSEMBLY OF CAB




RGV1701050000 ELECTRICAL ASSEMBLY OF CAB

No.	Part No.	Description	Version	QTY.	Remark
	RGV1701050000	ELECTRICAL ASSEMBLY OF CAB	006	1	
1	GBT96. 1-6-A3L	BIG WASHER		3	
2	GBT16674. 1-M6X20-8. 8-A2L	HEXAGON FLANGE NUT		7	
3	RGV1701070005	IGNITIONLOCK		1	
4	DV01701070005	4-GANG MEMBRANE SWITCH		1	
5	RGV1701050004	CENTRAL ELECTRICAL BOX ASSEMBLY		1	
5.1	RGV4701020003	BOX		1	
5.2	RGV4701020004	RELAY		1	
5.3	RGV4701020005	Mini型12V-70A功率继电器		1	
5.4	RGV4701020006	Mini型12V-40A功率继电器		1	
5.5	RGV4701020007	RELAY		3	
5.6	TD9600002300	FUSE		3	
5.7	TD9600001800	FUSE		7	
5.8	TD9600001900	FUSE		6	
5.9	TD9600002100	FUSE		5	
5.10	TD9600002200	FUSE		3	
5.11	TD9600001200	FUSE 30A		2	
6	GBT818-M6X12-4. 8-A2L	CROSS SCREW		2	
7	RGV3701030002	HANDLEBALL		1	
8	RGV3701030003a	WORK LAMP		1	
9	DG2002. 51. 2. 3	REVERSE ALARM ASSEMBLY		1	
9.1	GBT5783-M6X16-8. 8-A2L	HEXAGON BOLT		1	
9.2	GBT93-6-A0P	STANDARD SPRING WASHER		1	

RGV1701050000 ELECTRICAL ASSEMBLY OF CAB (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
9.3	GBT95-6-A0P	FLAT WASHER		1	
9.4	DG2002.51.2.3-01	ASTERN LAMP ALARMER		1	
10	DV01603000010	PLASTIC FASTENING STRIP		2	
11	DG2007.51.2.3	OVERCURRENTTRIPCOIL		1	
12	RGV1701050005b	DRIVER' S PANEL HARNESS		1	
13	RGV1701050003	COMBINATION INSTRUMENT		1	
14	DG200A7.51.1.4	HORN BUTTON		1	
15	BA150B2.29.2.8	CLUTCH OPEN PROTECE SWITCH		1	
16	RV03701000007	SWITCH OF NORMAL CLOSE		1	
17	FT300.48.055	STARTING RELAY		1	
18	TC03483010002	HORN ASSEMBLY		1	
19	GBT16674.1-M8X20-8.8-A2L	HEXAGON FLANGE NUT		1	
20	GBT93-6-A3L	STANDARD SPRING WASHER		2	
21	GBT16674.1-M6X16-8.8-A2L	HEXAGON FLANGE NUT		2	
22	3203505D9-L	TIE		1	
23	DV01701050005	SWITCH		2	


RGV1702060000 ELECTRICAL ASSEMBLY OF BODY



RGV1702060000 ELECTRICAL ASSEMBLY OF BODY

No.	Part No.	Description	Version	QTY.	Remark
	RGV1702060000	ELECTRICAL ASSEMBLY OF BODY	001	1	
1	CR3D806010008	SOLENOID PUMP		1	
2	D238. 51. 7	FRONT HEAD LAMP		1	
3	DG2002. 51. 1. 8	WORK LAMP		1	
4	RV01702020004	CONNECTING LINE		1	
5	DG2002. 51. 2. 3	REVERSE ALARM ASSEMBLY		1	
5. 1	GBT5783-M6X16-8. 8-A2L	HEXAGON BOLT		1	
5. 2	GBT93-6-A0P	STANDARD SPRING WASHER		1	
5. 3	GBT95-6-A0P	FLAT WASHER		1	
5. 4	DG2002. 51. 2. 3-01	ASTERN LAMP ALARMER		1	
6	DG2007. 51. 2. 3	OVERCURRENTTRIPCOIL		2	
7	DV01603000010	PLASTIC FASTENING STRIP		17	
8	RGV1702060001	CYLINDER BLOCK HARNESS		1	
9	DV01704000002	BRACKET		1	
10	FT800A. 48L. 106	HARNESS CLAMP		1	
11	DV01702030006	WORK LAMP		1	
12	G20D1. 34-09	RUBBER WASHER 9		1	
13	G25A3. 29. 1-01	WIRE FASTENER		1	
14	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		2	
15	GBT5789-M8X20-8. 8-A2L	HEXAGON FLANGE NUT		2	
16	GF38B1. 29. 5-05	WIRE FASTENER		1	
17	GBT5789-M6X16-8. 8-A2L	HEXAGON FLANGE NUT		1	


RGV1703010000 ELECTRICAL ASSEMBLY OF GRAIN BOX



RGV1703010000 ELECTRICAL ASSEMBLY OF GRAIN BOX

No.	Part No.	Description	Version	QTY.	Remark
	RGV1703010000	ELECTRICAL ASSEMBLY OF GRAIN BOX	001	1	
1	RGV1703010001	HARNESS		1	
2	GBT93-6-A3L	STANDARD SPRING WASHER		4	
3	GBT97. 1-6-A3L	FLAT WASHERS		4	
4	YP4. 30. 3. 11	GRAIN TANK FULL SENSOR		1	
5	DV01603000010	PLASTIC FASTENING STRIP		1	


DV01704020000 HARNESS ASSEMBLY



DV01704020000 HARNESS ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
1	DV01704020000	HARNESS ASSEMBLY		1	
1	DV01704020001	HARNESS OF HEADER		1	
2	DG2002. 51. 1. 8	WORK LAMP		2	
3	Q67405200	PLASTIC FASTENING STRIP		7	

RGV1705020000 ELECTRICAL ASSEMBLY OF ENGINE




RGV1705020000 ELECTRICAL ASSEMBLY OF ENGINE

No.	Part No.	Description	Version	QTY.	Remark
	RGV1705020000	发动机电器总成		1	
1	GK30A6. 29. 3-01	WATER TEMPERATURE SENSOR		1	
2	FT800A. 48L. 106	HARNESS CLAMP		1	
3	DV01705000002	OIL PRESSURE ALARM		1	
4	GF38B1. 29. 3-01	RPM SENSOR		1	
5	DV01603000010	PLASTIC FASTENING STRIP		12	
6	GBT5789-M8X20-8. 8-A2L	HEXAGON FLANGE NUT		1	
7	GBT6177. 1-M8-8-A2L	HEXAGON FLANGE NUT		1	
8	GBT5789-M10X25-8. 8-A2L	HEXAGON FLANGE NUT		1	
9	RGV1705020001	ENGINE WIRE HARNESS		1	
10	RGV1705020002	扁铜搭铁线		1	

RGV1706000000 ACCUMULATOR ASSEMBLY


LOVOL
9ZR D22327



RGV1706000000 ACCUMULATOR ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV1706000000	ACCUMULATOR ASSEMBLY		1	
1	D1681.51.4-06	BATTERY BOTTOM PLATE		1	
2	RGV3706010003	负极电缆线		1	
3	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		4	
4	HG2201.51A.7-01	PULL ROD		2	
5	HG2201.51A.7-02	PRESSURE PLATE		1	
6	DV01603000010	PLASTIC FASTENING STRIP		6	
7	RGV1706000001	正极电缆线装配总成		1	
8	TG1204.485.1	BATTERY ASSEMBLY		1	
9	G20D1.34.12	MAIN POWER SWITCH INSTALLATION		1	
9.1	GBT6177.1-M8-8-A2L	HEXAGON FLANGE NUT		2	
9.2	F700020	POWER SWITCH		1	
9.3	GBT5789-M8X30-10.9-A2L	HEXAGON FLANGE NUT		2	
10	RGV1706000004	BATTERY COVER PLATE		1	
11	RGV3706010001	搭铁支架焊合		1	
12	GBT5789-M10X25-8.8-A2L	HEXAGON FLANGE NUT		1	


RGV3709020000 AWNING FAN ASSEMBLY



RGV3709020000 AWNING FAN ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3709020000	AWNING FAN ASSEMBLY	001	1	
1	GBT6177. 1-M6-8-A2L	HEXAGON FLANGE NUT		4	
2	RGV3709020005	AWNING FAN		1	
3	3203505D9-L	CABLE TIE		2	
4	RGV3709020003	FAN HARNESS		1	
5	RGV3709020006	SWITCH		1	
6	GBT16674. 1-M6X16-8. 8-A2L	HEX FLANGE BOLTS		4	
7	Q67405200	PLASTIC FASTENING STRIP		2	


RGV3801020000K AWNING ASSEMBLY



RGV3801020000K AWNING ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV3801020000K	AWNING ASSEMBLY	001	1	
1	GBT5782-M6X40-8. 8-A2L	HEX HEAD BOLTS		4	
2	GBT5782-M6X60-8. 8-A2L	HEX HEAD BOLTS		8	
3	GBT96. 1-6-A3L	LARGE WASHER		16	
4	DB20031. 42-03	RUBBER MAT		6	
5	HE2001. 42A-01	TOP COVER		2	
6	RGV3801170001	BRACKET WELDMENT		1	
6. 1	GBT882-B16X45-A3L	PIN		1	
6. 2	GBT91-4X40-A3L	COTTER PIN		2	
6. 3	RGV3801170002	ADJUSTABLE SUPPORT WELDMENT		1	
6. 4	RGV3801000034	CONNECTING SPAN		2	
6. 5	GBT97. 1-16-A3L	FLAT WASHERS		1	
7	GBT889. 1-M6-8-A2L	HEXAGON LOCK NUTS WITH NON-METALLIC INSERT TYPE 1		2	
8	RGV3801000045b	AWNING BRACKET WELDMENT		1	
9	Q50110	LOCK PIN		8	
10	RGV3801000056	PLUG PIN WELDMENT		2	
11	GBT16674. 1-M10X45-8. 8-A3L	HEX FLANGE BOLTS		2	
12	GBT16674. 1-M10X20-8. 8-A2L	HEX FLANGE BOLTS		7	
13	GBT16674. 1-M10X30-8. 8-A2L	HEX FLANGE BOLTS		2	
14	GBT6177. 1-M10-8-A3L	HEXAGON FLANGE NUT		2	
15	GBT97. 1-10-A3L	FLAT WASHERS		2	

RGV1802050000K DRIVER' S PANEL ASSEMBLY




RGV1802050000K DRIVER' S PANEL ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV1802050000K	DRIVER' S PANEL ASSEMBLY	003	1	
1	DV01802000025	AUTO PRETECTED STRIPE		1	
2	GBT5789-M8X20-8.8-A2L	HEXAGON FLANGE NUT		19	
3	D1681.43.3	AGRAFFE		1	
4	GBT5789-M10X25-8.8-A3L	HEXAGON FLANGE NUT		3	
5	RV01802010001	LEFT CONSOLE WELDMENT		1	
6	DV01802000007	LIMIT PLATE		1	
7	RGV3802020016	CONNECTING PLATE		1	
8	DV01802000011	SUPPORT PLATE WELDMENT		1	
9	GBT5789-M6X16-8.8-A2L	HEXAGON FLANGE NUT		20	
10	GBT5789-M8X25-8.8-A2L	HEXAGON FLANGE NUT		1	
11	GBT96.1-6-A3L	BIG WASHER		18	
12	RV01802010002K	PLATE		1	
13	RV01802130001	BRACKET WELDMENT		1	
14	RGV3802020001	DRIVER' S PANEL WELDMENT		1	
15	RGV3802020019	RETAINER PLATE		1	
16	RV01802160010	PLATE		1	
17	GBT5783-M6X12-8.8-A2L	HEXAGON BOLT		2	
18	GBT6177.1-M6-8-A2L	HEXAGON FLANGE NUT		9	
19	DV01802000027	SUPPORT BENDING PLATE		1	
20	DG2001.32-03	STELPLESS SPEED CHANGING LIMIT PLATE		1	
21	GBT6177.1-M8-8-A2L	HEXAGON FLANGE NUT		14	
22	DG2001.32.2a	LEFT POLE WELDMENT		1	

RGV1802050000K DRIVER' S PANEL ASSEMBLY (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	DG2001.32-07	SPRINGWASHER		1	
24	DG2001.32-10	SWITCH CONTACT		1	
25	GBT6177.1-M10-8-A3L	HEXAGON FLANGE NUT		1	
26	DV01802000033	SUPPORT WELD		1	
27	GBT5789-M8X16-8.8-A2L	HEXAGON FLANGE NUT		7	
28	RV01802160019	ARMREST		1	
29	RV01802160038	BRACKET WELDMENT		1	
30	GBT16674.1-M8X20-8.8-A2L	HEXAGON FLANGE NUT		2	
31	GBT93-6-A3L	STANDARD SPRING WASHER		2	

RGV1803030000K SEAT ASSEMBLY




RGV1803030000K SEAT ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RGV1803030000K	SEAT ASSEMBLY	001	1	
1	RGV3803000001	SEAT		1	
2	RGV1803030001K	BRACKET WELDMENT		1	
3	GBT96. 1-8-A3L	LARGE WASHER		8	
4	GBT6177. 1-M8-10-A2L	HEXAGON FLANGE NUT		8	
5	GBT5789-M8X20-8. 8-A2L	HEX FLANGE BOLTS		4	

RV01804060000 COVER ASSEMBLY

LOVOL
9ZR D22327




RV01804060000 COVER ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RV01804060000	COVER ASSEMBLY		1	
1	GBT5783-M8X20-8. 8-A2L	HEXAGON BOLT		10	
2	GBT93-8-A3L	STANDARD SPRING WASHER		12	
3	GBT97. 1-8-A3L	FLAT WASHER		14	
4	DV01804000051	BACK LIMIT ROD		1	
5	DV01804000009	SHOCK ABSORBER		2	
6	DV01804000050	FRONT LIMIT ROD		1	
7	GBT97. 1-10-A3L	FLAT WASHER		4	
8	GBT91-2. 5X20-A3L	SPLIT PIN		2	
9	GBT818-M6X45-4. 8-A1L	CROSS SCREW		4	
10	DV01804000041	HANDLE		2	
11	DV01804000056	MOUNTINGS 2		1	
12	GBT97. 1-6-A3L	FLAT WASHER		8	
13	GBT93-6-A3L	STANDARD SPRING WASHER		6	
14	GBT6170-M10-8-A3L	HEXAGON NUT, TYPE-1		7	
15	BA150B2. 118. 1. 2	HANDLE		4	
16	RV01804010009	LOWER REAR BONNET WELDMENT, LEFT		1	
17	RV01804010003	LOWER FRONT BONNET WELDMENT, LEFT		1	
18	DV01804000024	PNEUMATIC SPRING		2	
19	GBT6170-M8-8-A2L	HEXAGON NUT, TYPE-1		5	
20	GBT882-B8X20-A3L	PIN SHAFT		2	
21	RV01804060001	FRONT COVER WELDMENT		1	
22	DV01804000052	SUPPORT WELD		1	

RV01804060000 COVER ASSEMBLY (cont'd.)

No.	Part No.	Description	Version	QTY.	Remark
23	GBT5783-M6X16-8.8-A2L	HEXAGON BOLT		2	
24	DG2004.9.14b	BONNET SUPPORT PLATE WELDMENT		1	
25	GBT6170-M6-8-A2L	HEXAGON NUT, TYPE-1		6	
26	RV01804060003	LEFT UPPER COVER UNIT		1	
26.1	GBT5783-M8X20-8.8-A2L	HEXAGON BOLT		4	
26.2	GBT93-8-A3L	STANDARD SPRING WASHER		4	
26.3	GBT97.1-8-A3L	FLAT WASHER		4	
26.4	DV01804000030	HINGE 1		2	
26.5	GBT882-B10X75-A3L	PIN SHAFT		2	
26.6	DV01804000012	HINGE 2		1	
26.7	GBT97.1-10-A3L	FLAT WASHER		2	
26.8	GBT91-2.5X20-A3L	SPLIT PIN		2	
26.9	RV01804010005	UPPER BONNET WELDMENT		1	
26.10	DV01804000055	HINGE WELDMENT 3		1	

RV01806030000 REAR TAIL LADDER ASSEMBLY



RV01806030000 REAR TAIL LADDER ASSEMBLY

No.	Part No.	Description	Version	QTY.	Remark
	RV01806030000	REAR TAIL LADDER ASSEMBLY		1	
1	DV01901000015	SIGN		1	
2	GBT5783-M10X25-8. 8-A3L	HEXAGON BOLT		4	
3	GBT93-10-A3L	STANDARD SPRING WASHER		4	
4	GBT96. 1-10-A3L	BIG WASHER		4	
5	RV01806030001	REAR TAIL BONNET WELDMENT		1	